C950 Series

User's Guide

October 2014 **www.lexmark.com**

Machine type(s):

5058

Model(s):

030

Contents

Safety information....6

Learning about the printer....8

Finding information about the printer....8
Selecting a location for the printer....9
Printer configurations....10
Using the printer control panel....13

Understanding the home screen....14

Understanding the home screen....14
Using the touch-screen buttons....15

Setting up and using the home screen applications....17

Accessing the Embedded Web Server....17
Showing or hiding icons on the home screen....17
Activating the home screen applications....18
Setting up Remote Operator Panel....19
Exporting and importing a configuration....20

Additional printer setup....21

Turning on the printer....21
Installing internal options....22
Installing hardware options....36
Attaching cables....39
Verifying printer setup....40
Setting up the printer software....41
Networking....42

Minimizing your printer's environmental impact....50

Saving paper and toner....50
Saving energy....51
Recycling....53

Loading paper and specialty media....55

Setting the paper size and type....55

Configuring Universal paper settings....55
Loading the standard or optional 520-sheet tray....55
Loading the optional 850- and 1,150-sheet trays....58
Loading the 2000-sheet high-capacity feeder....61
Loading the multipurpose feeder....63
Linking and unlinking trays....66

Paper and specialty media guide....68

Paper guidelines....68
Storing paper....71
Supported paper sizes, types, and weights....72

Printing....79

Printing a document....79
Printing from a mobile device....80
Printing from a flash drive....81
Printing on specialty media....83
Printing confidential and other held jobs....85
Printing information pages....86
Canceling a print job....87

Understanding the printer menus....88

Menus list....88
Supplies menu....89
Paper menu....91
Reports menu....100
Network/Ports menu....101
Security menu....114
Settings menu....118
Help menu....138

Securing the hard disk and other installed memory....139

Statement of Volatility....139
Erasing volatile memory....139
Erasing non-volatile memory....140
Erasing printer hard disk memory....140
Configuring printer hard disk encryption....141

Maintaining the printer.....142
Cleaning the exterior of the printer.....142
Cleaning the printhead lenses.....142
Emptying the hole punch box.....146
Storing supplies.....148
Checking the status of parts and supplies.....148
Ordering parts and supplies.....149
Replacing parts and supplies.....151
Moving the printer.....172

Administrative support.....173
Finding advanced networking and administrator information.....173
Checking the virtual display.....173
Checking the status of the printer.....173
Setting up e-mail alerts.....173
Viewing reports.....174
Restoring factory default settings.....174

Clearing jams.....175
Avoiding jams.....175
Understanding jam numbers and locations.....175
201–202 paper jams.....177
203 paper jam.....178
230 paper jam.....180
231 paper jam.....180
24x paper jam.....182
250 paper jam.....188
281 paper jam.....188
4yy.xx paper jams.....190
455 staple jam.....195

Troubleshooting.....198
Solving basic printer problems.....198
Understanding the printer messages.....198
Solving printing problems.....212
Solving home screen application problems.....215

Solving option problems....218
Solving paper feed problems....221
Solving print quality problems....222
Solving color quality problems....233
Embedded Web Server does not open....236
Contacting customer support....237

Notices....238

Product information....238
Edition notice....238
Power consumption....242

Index....250

Safety information

Connect the power cord directly to an appropriately rated and properly grounded electrical outlet that is near the product and easily accessible.

CAUTION—POTENTIAL INJURY: Do not use this product with extension cords, multioutlet power strips, multioutlet extenders, or other types of surge or UPS devices. The power rating capacity of these types of accessories can be easily overloaded by a laser printer and may result in poor printer performance, property damage, or potential fire.

Do not place or use this product near water or wet locations.

This product uses a printing process that heats the print media, and the heat may cause the media to release emissions. You must understand the section in your operating instructions that discusses the guidelines for selecting print media to avoid the possibility of harmful emissions.

CAUTION—POTENTIAL INJURY: The lithium battery in this product is not intended to be replaced. There is a danger of explosion if a lithium battery is incorrectly replaced. Do not recharge, disassemble, or incinerate a lithium battery. Discard used lithium batteries according to the manufacturer's instructions and local regulations.

CAUTION—HOT SURFACE: The inside of the printer might be hot. To reduce the risk of injury from a hot component, allow the surface to cool before touching.

CAUTION—POTENTIAL INJURY: The printer weight is greater than 18 kg (40 lb) and requires two or more trained personnel to lift it safely.

CAUTION—POTENTIAL INJURY: Before moving the printer, follow these guidelines to avoid personal injury or printer damage:

- Turn the printer off using the power switch, and then unplug the power cord from the wall outlet.
- Disconnect all cords and cables from the printer before moving it.
- Lift the printer off the optional drawer, and set it aside instead of trying to lift the drawer and printer at the same time.

  Note: Use the handholds located on both sides of the printer to lift it off the optional drawer.

Use only the power cord provided with this product or the manufacturer's authorized replacement.

CAUTION—POTENTIAL INJURY: To reduce risk of fire, use only the telecommunications (RJ-11) cord provided with this product or a UL Listed 26 AWG or larger replacement when connecting this product to the public switched telephone network.

CAUTION—SHOCK HAZARD: If you are accessing the system board or installing optional hardware or memory devices sometime after setting up the printer, then turn the printer off, and unplug the power cord from the wall outlet before continuing. If you have any other devices attached to the printer, then turn them off as well, and unplug any cables going into the printer.

CAUTION—SHOCK HAZARD: Make sure that all external connections (such as Ethernet and telephone system connections) are properly installed in their marked plug-in ports.

This product is designed, tested, and approved to meet strict global safety standards with the use of specific manufacturer's components. The safety features of some parts may not always be obvious. The manufacturer is not responsible for the use of other replacement parts.

CAUTION—POTENTIAL INJURY: Do not cut, twist, bind, crush, or place heavy objects on the power cord. Do not subject the power cord to abrasion or stress. Do not pinch the power cord between objects such as furniture and walls. If any of these things happen, a risk of fire or electrical shock results. Inspect the power cord regularly for signs of such problems. Remove the power cord from the electrical outlet before inspecting it.

Refer service or repairs, other than those described in the user documentation, to a professional service person.

CAUTION—SHOCK HAZARD: To avoid the risk of electric shock when cleaning the exterior of the printer, unplug the power cord from the wall outlet and disconnect all cables from the printer before proceeding.

CAUTION—SHOCK HAZARD: Do not use the fax feature during a lightning storm. Do not set up this product or make any electrical or cabling connections, such as the fax feature, power cord, or telephone, during a lightning storm.

CAUTION—TIPPING HAZARD: Floor-mounted configurations require additional furniture for stability. You must use either a printer stand or printer base if you are using a high-capacity input tray, a duplex unit and an input option, or more than one input option. If you purchased a multifunction printer (MFP) that scans, copies, and faxes, you may need additional furniture. For more information, see **www.lexmark.com/multifunctionprinters**.

CAUTION—POTENTIAL INJURY: To reduce the risk of equipment instability, load each paper drawer or tray separately. Keep all other drawers or trays closed until needed.

SAVE THESE INSTRUCTIONS.

Learning about the printer

Finding information about the printer

What are you looking for?	Find it here
Initial setup instructions: • Connecting the printer • Installing the printer software	Setup documentation—The setup documentation came with the printer and is also available at **http://support.lexmark.com**.
Additional setup and instructions for using the printer: • Selecting and storing paper and specialty media • Loading paper • Configuring printer settings • Viewing and printing documents and photos • Setting up and using the printer software • Configuring the printer on a network • Caring for and maintaining the printer • Troubleshooting and solving problems	*User's Guide* and *Quick Reference Guide*—The guides are available at **http://support.lexmark.com**. **Note:** These guides are also available in other languages.
Information on setting up and configuring the accessibility features of your printer	*Lexmark Accessibility Guide*—This guide is available at **http://support.lexmark.com**.
Help using the printer software	Windows or Mac Help—Open a printer software program or application, and then click **Help**. Click to view context-sensitive information. **Notes:** • Help is automatically installed with the printer software. • The printer software is located in the printer program folder or on the desktop, depending on your operating system.

What are you looking for?	Find it here
The latest supplemental information, updates, and customer support: • Documentation • Driver downloads • Live chat support • E-mail support • Voice support	Lexmark support Web site—http://support.lexmark.com **Note:** Select your country or region, and then select your product to view the appropriate support site. Support telephone numbers and hours of operation for your country or region can be found on the support Web site or on the printed warranty that came with your printer. Record the following information (located on the store receipt and at the back of the printer), and have it ready when you contact customer support so that they may serve you faster: • Machine Type number • Serial number • Date purchased • Store where purchased
Warranty information	Warranty information varies by country or region: • **In the U.S.**—See the Statement of Limited Warranty included with this printer, or go to http://support.lexmark.com. • **In other countries and regions**—See the printed warranty that came with this printer.

Selecting a location for the printer

CAUTION—POTENTIAL INJURY: The printer weight is greater than 18 kg (40 lb) and requires two or more trained personnel to lift it safely.

When selecting a location for the printer, leave enough room to open trays, covers, and doors. If you plan to install any options, then leave enough room for them also. It is important to:

- Set up the printer near a properly grounded and easily accessible electrical outlet.
- Make sure airflow in the room meets the latest revision of the ASHRAE 62 standard or the CEN Technical Committee 156 standard.
- Provide a flat, sturdy, and stable surface.
- Keep the printer:
  - Away from the direct airflow of air conditioners, heaters, or ventilators
  - Free from direct sunlight, humidity extremes, or temperature fluctuations
  - Clean, dry, and free of dust
  - Away from stray staples and paper clips
- Allow the following recommended amount of space around the printer for proper ventilation:



1	Right side	307.34 mm (12.1 in.)
2	Front	444.5 mm (17.5 in.)
3	Left side	374.65 mm (14.75 in.)
4	Rear	100 mm (3.9 in.)
5	Top	152.4 mm (6 in.)

Printer configurations

Basic model



1	Printer control panel
2	Exit tray 2 **Note:** Exit tray 2 is supported in any configuration except when a finisher is installed.
3	Standard exit bin
4	Front door
5	Standard 520-sheet tray
6	Multipurpose feeder

Configured models

You can configure your basic printer by adding optional trays. A 2,000-sheet high-capacity feeder and a finisher bin can also be added.



1	Optional 520-sheet tray
2	Optional 520-sheet trays
3	Optional 520-sheet tray
4	2,000-sheet tandem-tray module • 850-sheet tray (Tray 3) • 1,150-sheet tray (Tray 4)

Fully configured model



1	Finisher bin The finisher bin can either be one of the following: • Standard finisher (Punch/Stapler) • Booklet finisher (Punch/Stapler/Booklet)
2	2,000-sheet high-capacity feeder

CAUTION—TIPPING HAZARD: Floor-mounted configurations require additional furniture for stability. You must use either a printer stand or printer base if you are using a high-capacity input tray, a duplex unit and an input option, or more than one input option. If you purchased a multifunction printer (MFP) that scans, copies, and faxes, you may need additional furniture. For more information, see **www.lexmark.com/multifunctionprinters**.

Using the printer control panel



Use		To
1	Display	View printing options as well as status and error messages.
2	Home	Navigate back to the home screen.
3	Keypad	Enter numbers, letters, or symbols.
4	Sleep button	Enable Sleep Mode or Hibernate Mode. • A short press will enable Sleep Mode. • A long press will enable Hibernate Mode. **Note:** Touching the screen or pressing any hard button will cause the printer to wake from Sleep Mode or Hibernate Mode.
5	Indicator light	View the status of the printer. • Off—The printer is off. • Blinking green—The printer is warming up, processing data, or printing. • Solid green—The printer is on, but idle. • Solid red—Operator intervention is needed. • Amber—The printer enters Sleep Mode or Hibernate Mode.
6	Stop/Cancel	Stop all printer activity. **Note:** A list of options is displayed once **Stopped** appears on the display.
7	USB port	Connect a flash drive into the printer USB port. **Note:** Only the front USB port supports flash drives.

Understanding the home screen

Understanding the home screen

When the printer is turned on, the display shows a basic screen, referred to as the home screen. Use the home screen buttons and icons to initiate an action.

Note: Your home screen, icons, and the buttons may vary depending on your home screen customization settings, administrative setup, and active embedded solutions.

Touch		To
1	Change Language	Change the primary language of the printer.
2	Bookmarks	Create, organize, and save a set of bookmarks (URLs) into a tree view of folders and file links. **Note:** The tree view does not include bookmarks created within Forms and Favorites, and the ones in the tree are not usable in Forms and Favorites.
3	Held Jobs	Display all current held jobs.
4	USB or USB Thumbdrive	View, select, or print photos and documents from a flash drive. **Note:** This icon appears only when you return to the home screen while a memory card or flash drive is connected to the printer.
5	Menus	Access printer menus. **Note:** These menus are available only when the printer is in the Ready state.
6	Status message bar	• Show the current printer status such as **Ready** or **Busy**. • Show printer conditions such as **Fuser missing** or **Cartridge Low**. • Show intervention messages and the instructions on how to clear them.
7	Status/Supplies	• Display a warning or error message whenever the printer requires intervention to continue processing. • Access the messages screen for more information on the message, and how to clear it.
8	Tips	Open a context-sensitive Help information on the touch screen.

This may also appear on the home screen:

Touch	To
Search Held Jobs	Search current held jobs.

Features

Feature	Description
Attendance message alert	If an attendance message affects a function, then this icon appears and the red indicator light blinks.
Warning	If an error condition occurs, then this icon appears.
Printer IP address Sample: `123.123.123.123.123`	The IP address of your network printer is located at the top left corner of the home screen and appears as four sets of numbers separated by periods. You can use the IP address when accessing the Embedded Web Server so you can view and remotely configure printer settings even when you are not physically near the printer.

Using the touch-screen buttons

Note: Your home screen, icons, and buttons may vary depending on your home screen customization settings, administrative setup, and active embedded solutions.

Sample touch screen



	Touch	To
1	Up arrow	Scroll up.

	Touch	To
2	Delete folder	Delete the file you selected.
3	Left arrow	Scroll to the left.
4	Right arrow	Scroll to the right.
5	Right scroll increase	Scroll to another value in increasing order.
6	Left scroll decrease	Scroll to another value in decreasing order.
7	Down arrow	Scroll down.
8	Accept	Save a setting.
9	Cancel	• Cancel an action or a selection. • Cancel out a screen and return to the previous screen.
10	Back	Navigate back to the previous screen.

Setting up and using the home screen applications

Notes:

- Your home screen may vary depending on your home screen customization settings, administrative setup, and active embedded applications. Some applications are supported only in some printer models.
- There may be additional solutions and applications available for purchase. For more information, go to **www.lexmark.com** or contact the place where you purchased the printer.

Accessing the Embedded Web Server

The Embedded Web Server is the printer Web page that lets you view and remotely configure printer settings even when you are not physically near the printer.

1. Obtain the printer IP address:
   - From the printer control panel home screen
   - From the TCP/IP section in the Network/Ports menu
   - By printing a network setup page or menu settings page, and then finding the TCP/IP section

   Note: An IP address appears as four sets of numbers separated by periods, such as `123.123.123.123`.
2. Open a Web browser, and then type the printer IP address in the address field.
3. Press **Enter**.

   Note: If you are using a proxy server, then temporarily disable it to load the Web page correctly.

Showing or hiding icons on the home screen

1. Open a Web browser, and then type the printer IP address in the address field.

   Note: View the printer IP address on the printer control panel home screen. The IP address appears as four sets of numbers separated by periods, such as 123.123.123.123.
2. Click **Settings** > **General Settings** > **Home screen customization**.

   A list of basic printer functions appears.
3. Select the check boxes to specify which icons appear on the printer home screen.

   Note: Cleared check box items are hidden.
4. Click **Submit**.

Activating the home screen applications

Your printer comes with preinstalled home screen applications. You can activate and set up these applications using the Embedded Web Server. To access the Embedded Web Server, see "Accessing the Embedded Web Server" on page 17.

For detailed information about configuring and using the home screen applications, go to the Lexmark support Web site at **http://support.lexmark.com**.

Using Background and Idle Screen

Icon	Description
	The application lets you customize the background and idle screen of your printer home screen.

1. From the home screen, navigate to:

   Change Background > select background to use

2. Touch .

Setting up Forms and Favorites

Icon	Description
	The application helps you simplify and streamline work processes by letting you quickly find and print frequently used online forms directly from the home screen. **Note:** The printer must have permission to access the network folder, FTP site, or Web site where the bookmark is stored. From the computer where the bookmark is stored, use sharing, security, and firewall settings to allow the printer at least a *read* access. For help, see the documentation that came with your operating system.

1. Open a Web browser, and then type the printer IP address in the address field.

   Note: View the printer IP address on the printer control panel home screen. The IP address appears as four sets of numbers separated by periods, such as 123.123.123.123.

2. Click **Settings** > **Device Solutions** > **Solutions (eSF)** > **Forms and Favorites**.

3. Define the bookmarks, and then customize the settings.

4. Click **Apply**.

To use the application, touch **Forms and Favorites** on the printer home screen, and then navigate through form categories, or search for forms based on a form number, name, or description.

Understanding Eco-Settings

Icon	Description
	The application lets you easily manage energy consumption, noise, toner, and paper usage settings to help reduce the environmental impact of your printer.

Understanding Showroom

Icon	Description
	The application lets you create and display a customized slide show on the touch screen of your printer. You can load images either from a flash drive or through the printer Embedded Web Server.

Setting up Remote Operator Panel

This application shows the printer control panel on your computer screen and lets you interact with the printer control panel, even when you are not physically near the network printer. From your computer screen, you can view the printer status, release held print jobs, create bookmarks, and do other print-related tasks you might normally do while standing at the network printer.

1. Open a Web browser, and then type the printer IP address in the address field.

   Note: View the printer IP address on the printer control panel home screen. The IP address appears as four sets of numbers separated by periods, such as 123.123.123.123.

2. Click **Settings** > **Device Solutions** > **Solutions (eSF)** > **Remote Operator Panel**.
3. Select the **Enabled** check box, and then customize the settings.
4. Click **Apply**.

To use the application, from the Embedded Web Server, click **Applications** > **Remote Operator Panel** > **Launch VNC Applet**.

Exporting and importing a configuration

You can export configuration settings into a text file, and then import the file to apply the settings to other printers.

1. Open a Web browser, and then type the printer IP address in the address field.

   Note: View the IP address on the printer home screen. The IP address appears as four sets of numbers separated by periods, such as 123.123.123.123.

2. Export or import a configuration file for one or multiple applications.

For one application

a. Navigate to:
   Settings > **Apps** > **Apps Management** > select an application > **Configure**

b. Export or import the configuration file.

   Notes:

   - If a **`JVM Out of Memory`** error occurs, then repeat the export process until the configuration file is saved.
   - If a timeout occurs and a blank screen appears, then refresh the Web browser, and then click **Apply**.

For multiple applications

a. Click **Settings** > **Import/Export**.

b. Export or import a configuration file.

   Note: When importing a configuration file, click **Submit** to complete the process.

Additional printer setup

Turning on the printer

1 Open the front door.



2 Press the printer power switch.



3 Close the front door.



Installing internal options

CAUTION—SHOCK HAZARD: If you are accessing the system board or installing optional hardware or memory devices sometime after setting up the printer, then turn the printer off, and unplug the power cord from the wall outlet before continuing. If you have any other devices attached to the printer, then turn them off as well, and unplug any cables going into the printer.

Available internal options

- Memory cards
  - Printer memory
  - Flash memory
  - Fonts
- Firmware cards
  - Bar Code
  - PrintCryption™
- Printer hard disk
- Lexmark™ Internal Solutions Ports (ISP)
  - RS-232-C Serial ISP
  - Parallel 1284-B ISP
  - MarkNet™ N8250 802.11 b/g/n Wireless ISP
  - MarkNet N8130 10/100 Fiber ISP
  - MarkNet N8120 10/100/1000 Ethernet ISP

Note: An external kit is needed to support the ISP.

Accessing the system board

CAUTION—SHOCK HAZARD: If you are accessing the system board or installing optional hardware or memory devices sometime after setting up the printer, then turn the printer off, and unplug the power cord from the wall outlet before continuing. If you have any other devices attached to the printer, then turn them off as well, and unplug any cables going into the printer.

Note: This task requires a flathead screwdriver.

1 Turn the screws counterclockwise to loosen them.



2 Pull the system board forward to remove it.



3 Use the following illustration to locate the appropriate connectors.

Warning—Potential Damage: System board electronic components are easily damaged by static electricity. Touch something metal on the printer before touching any system board electronic components or connectors.



1	ISP connector
2	Firmware and flash memory card connectors
3	Memory card connectors

4 Push the system board back into place.

Installing a memory card

CAUTION—SHOCK HAZARD: If you are accessing the system board or installing optional hardware or memory devices sometime after setting up the printer, then turn the printer off, and unplug the power cord from the wall outlet before continuing. If you have any other devices attached to the printer, then turn them off as well, and unplug any cables going into the printer.

Warning—Potential Damage: System board electronic components are easily damaged by static electricity. Touch something metal on the printer before touching any system board electronic components or connectors.

An optional memory card can be purchased separately and attached to the system board.

1 Access the system board.

For more information, see “Accessing the system board” on page 22.

Note: This task requires a flathead screwdriver.

2 Unpack the memory card.

Note: Avoid touching the connection points along the edge of the card.

3 On the system board, open the memory card connector latches.



4 Align the notch on the memory card to the ridge on the connector.



1	Notch
2	Ridge

5 Push the memory card into the connector until it *clicks* into place.



Installing a flash memory or firmware card

The system board has two connections for an optional flash memory or firmware card. Only one of each may be installed, but the connectors are interchangeable.

CAUTION—SHOCK HAZARD: If you are accessing the system board or installing optional hardware or memory devices sometime after setting up the printer, then turn the printer off, and unplug the power cord from the wall outlet before continuing. If you have any other devices attached to the printer, then turn them off as well, and unplug any cables going into the printer.

Warning—Potential Damage: System board electronic components are easily damaged by static electricity. Touch something metal on the printer before touching any system board electronic components or connectors.

1 Access the system board.

For more information, see "Accessing the system board" on page 22.

Notes:

- This task requires a flathead screwdriver.
- Do not unplug the fan cable upon opening the metal panel.

2 Unpack the card.

Note: Avoid touching the connection points along the edge of the card.

3 Holding the card by its sides, align the plastic pins on the card with the holes on the system board.



1	Plastic pins
2	Metal pins

4 Push the card firmly into place.



Notes:

- The entire length of the connector on the card must touch and be flush against the system board.
- Be careful not to damage the connectors.

Installing an Internal Solutions Port

The system board supports one optional Lexmark Internal Solutions Port (ISP).

Note: This task requires a flathead screwdriver.

CAUTION—SHOCK HAZARD: If you are accessing the system board or installing optional hardware or memory devices sometime after setting up the printer, then turn the printer off, and unplug the power cord from the wall outlet before continuing. If you have any other devices attached to the printer, then turn them off as well, and unplug any cables going into the printer.

Warning—Potential Damage: System board electronic components are easily damaged by static electricity. Touch something metal on the printer before touching any system board electronic components or connectors.

1. Access the system board.

   For more information, see "Accessing the system board" on page 22.

2. Remove the printer hard disk.

   For more information, see "Removing a printer hard disk" on page 34

3. Unpack the ISP kit.



1	ISP solution
2	Screws for the ISP solution
3	Screws for the plastic bracket
4	Plastic bracket

4. Use the provided screws to attach the plastic bracket to the ISP solution.



5 Use the provided screw to attach the ISP solution to the system board cage.



6 Connect the ISP solution interface cable into the receptacle of the system board.



7 Firmly connect the ISP solution to the system board cage using two screws.



Installing a printer hard disk

Note: This task requires a flathead screwdriver.

CAUTION—SHOCK HAZARD: If you are accessing the system board or installing optional hardware or memory devices sometime after setting up the printer, then turn the printer off, and unplug the power cord from the wall outlet before continuing. If you have any other devices attached to the printer, then turn them off as well, and unplug any cables going into the printer.

Warning—Potential Damage: System board electronic components are easily damaged by static electricity. Touch something metal on the printer before touching any system board electronic components or connectors.

1 Access the system board.

For more information, see “Accessing the system board” on page 22.

2 Unpack the printer hard disk.

3 Locate the appropriate connector on the system board.



Note: If an optional ISP is currently installed, then the printer hard disk must be installed onto the ISP.

To install a printer hard disk onto the ISP:

a Using a flathead screwdriver, loosen the screws.



b Remove the screws attached to the printer hard disk mounting bracket, and then remove the bracket.

c Align the standoffs of the printer hard disk to the holes in the ISP, and then press down on the printer hard disk until the standoffs are in place.



d Insert the plug of the printer hard disk interface cable into the receptacle of the ISP.

Note: The plugs and receptacles are color-coded.



To install a printer hard disk directly on the system board:

a Align the standoffs of the printer hard disk to the holes in the system board, and then press down on the printer hard disk until the standoffs are in place.



b Use the two provided screws to attach the printer hard disk mounting bracket.



c Insert the plug of the printer hard disk interface cable into the receptacle of the system board.

Note: The plugs and receptacles are color-coded.



Removing a printer hard disk

Note: This task requires a flathead screwdriver.

Warning—Potential Damage: System board electronic components are easily damaged by static electricity. Touch something metal on the printer before touching any system board electronic components or connectors.

1. Access the system board.

   For more information, see "Accessing the system board" on page 22.

2. Unplug the printer hard disk interface cable from the system board, leaving the cable attached to the printer hard disk. To unplug the cable, squeeze the paddle at the plug of the interface cable to disengage the latch before pulling the cable out.



3 Remove the screws while holding the printer hard disk in place, and then remove the printer hard disk.



4 Set aside the printer hard disk.

Installing hardware options

Order of installation

CAUTION—TIPPING HAZARD: Floor-mounted configurations require additional furniture for stability. You must use either a printer stand or printer base if you are using a high-capacity input tray, a duplex unit and an input option, or more than one input option. If you purchased a multifunction printer (MFP) that scans, copies, and faxes, you may need additional furniture. For more information, see **www.lexmark.com/multifunctionprinters**.

CAUTION—SHOCK HAZARD: If you are accessing the system board or installing optional hardware or memory devices sometime after setting up the printer, then turn the printer off, and unplug the power cord from the wall outlet before continuing. If you have any other devices attached to the printer, then turn them off as well, and unplug any cables going into the printer.

CAUTION—POTENTIAL INJURY: The printer weight is greater than 18 kg (40 lb) and requires two or more trained personnel to lift it safely.

Install the printer and any optional trays or finishers you have purchased in the following order:

Using a one-tray module

- Optional 520-sheet tray (Tray 2)
- Printer
- 2,000-sheet high-capacity feeder
- Finisher

Using a three-tray module

- Three-tray module
- Printer
- 2,000-sheet high-capacity feeder
- Finisher

Using a tandem-tray module

- Tandem-tray module
- Printer
- 2,000-sheet high-capacity feeder
- Finisher

For information on installing a one-tray module, three-tray module, tandem-tray module, high-capacity feeder, or any of the finishers, see the setup documentation that came with the option.

Installing optional trays

The printer supports the following optional trays:

- 1-tray module
- 3-tray module
- Tandem-tray module
- High-capacity feeder

CAUTION—POTENTIAL INJURY: The printer weight is greater than 18 kg (40 lb) and requires two or more trained personnel to lift it safely.

CAUTION—SHOCK HAZARD: If you are accessing the system board or installing optional hardware or memory devices sometime after setting up the printer, then turn the printer off, and unplug the power cord from the wall outlet before continuing. If you have any other devices attached to the printer, then turn them off as well, and unplug any cables going into the printer.

CAUTION—TIPPING HAZARD: Floor-mounted configurations require additional furniture for stability. You must use either a printer stand or printer base if you are using a high-capacity input tray, a duplex unit and an input option, or more than one input option. If you purchased a multifunction printer (MFP) that scans, copies, and faxes, you may need additional furniture. For more information, see **www.lexmark.com/multifunctionprinters**.

1. Unpack the optional tray, and then remove all packing material.
2. Place the tray near the printer.
3. Turn off the printer.

4 Align the printer with the tray, and then lower the printer into place.



1	1-tray module
2	2,000-sheet high-capacity feeder



1	3-tray module
2	2,000-sheet high-capacity feeder



1	Tandem-tray module
2	2,000-sheet high-capacity feeder

5 Turn the printer back on.

6 Set the printer software to recognize the optional tray. For more information, see "Adding available options in the print driver" on page 42.

Attaching cables

CAUTION—POTENTIAL INJURY: Do not use the fax feature during a lightning storm. Do not set up this product or make any electrical or cabling connections, such as the fax feature, power cord, or telephone, during a lightning storm.

Connect the printer to the computer using a USB cable or Ethernet cable.

Be sure to match the following:

- The USB symbol on the cable with the USB symbol on the printer
- The appropriate Ethernet cable to the Ethernet port



1	USB printer port
2	USB port
3	Ethernet port
Warning—Potential Damage: Do not touch the USB cable, any network adapter, or the printer in the area shown while actively printing. A loss of data or a malfunction can occur.	

Verifying printer setup

Once all hardware and software options are installed and the printer is turned on, verify that the printer is set up correctly by printing the following:

- **Menu settings page**—Use this page to verify that all printer options are installed correctly. A list of installed options appears toward the bottom of the page. If an option you installed is not listed, then it is not installed correctly. Remove the option and install it again.
- **Network setup page**—If your printer is a network model and is attached to a network, print a network setup page to verify the network connection. This page also provides important information that aids network printing configuration.

Printing a menu settings page

From the home screen, navigate to:

> **Reports** > **Menu Settings Page**

Printing a network setup page

If the printer is attached to a network, then print a network setup page to verify the network connection. This page also provides important information that aids network printing configuration.

1 From the home screen, navigate to:

> **Reports** > **Network Setup Page**

2 Check the first section of the network setup page, and confirm that the status is **Connected**.

If the status is **Not Connected**, then the LAN drop may not be active, or the network cable may be malfunctioning. Consult a system support person for a solution, and then print another network setup page.

Setting up the printer software

Installing the printer software

Notes:

- If you installed the printer software on the computer before but need to reinstall the software, then uninstall the current software first.
- Close all open software programs before installing the printer software.

1 Obtain a copy of the software installer package.

- From the *Software and Documentation* CD that came with your printer.
- From our Web site:
  Go to **http://support.lexmark.com**, and then navigate to:
  SUPPORT & DOWNLOAD > select your printer > select your operating system

2 Double-click the software installer package.

Wait for the installation dialog to appear.

If you are using a *Software and Documentation* CD and the installation dialog does not appear, then do the following:

In Windows 8

From the Search charm, type **run**, and then navigate to:

Apps list > **Run** > type **D:\setup.exe** > **OK**.

In Windows 7 or earlier

a Click or click **Start**, and then click **Run**.

b In the Start Search or Run dialog, type **D:\setup.exe**.

c Press **Enter**, or click **OK**.

In Macintosh

Click the CD icon on the desktop.

Note: `D` is the letter of your CD or DVD drive.

3 Click **Install**, and then follow the instructions on the computer screen.

Adding available options in the print driver

For Windows users

1 Open the printers folder.

In Windows 8

From the Search charm, type `run`, and then navigate to:

Run > type `control printers` > **OK**

In Windows 7 or earlier

a Click , or click **Start** and then click **Run**.

b Type `control printers`.

c Press **Enter**, or click **OK**.

2 Select the printer you want to update, and then do either of the following:

- For Windows 7 or later, select **Printer properties**.
- For earlier versions, select **Properties**.

3 Navigate to the Configuration tab, and then select **Update Now - Ask Printer**.

4 Apply the changes.

For Macintosh users

1 From System Preferences in the Apple menu, navigate to your printer, and then select **Options & Supplies**.

2 Navigate to the list of hardware options, and then add any installed options.

3 Apply the changes.

Networking

Notes:

- Purchase a MarkNet N8352 wireless network adapter before setting up the printer on a wireless network. For information on installing the wireless network adapter, see the instruction sheet that came with the adapter.
- A Service Set Identifier (SSID) is a name assigned to a wireless network. Wired Equivalent Privacy (WEP), Wi-Fi Protected Access (WPA), WPA2, and 802.1X - RADIUS are types of security used on a network.

Preparing to set up the printer on an Ethernet network

To configure your printer to connect to an Ethernet network, organize the following information before you begin:

Note: If your network automatically assigns IP addresses to computers and printers, continue on to installing the printer.

- A valid, unique IP address for the printer to use on the network
- The network gateway
- The network mask
- A nickname for the printer (optional)

  Note: A printer nickname can make it easier for you to identify your printer on the network. You can choose to use the default printer nickname, or assign a name that is easier for you to remember.

You will need an Ethernet cable to connect the printer to the network and an available port where the printer can physically connect to the network. Use a new network cable when possible to avoid potential problems caused by a damaged cable.

Preparing to set up the printer on a wireless network

Notes:

- Make sure your access point (wireless router) is turned on and is working properly.
- Do not connect the installation or network cables until prompted to do so by the setup software.

Make sure you have the following information before setting up the printer on a wireless network:

- **SSID**—The SSID is also referred to as the network name.
- **Wireless Mode (or Network Mode)**—The mode is either infrastructure or ad hoc.
- **Channel (for ad hoc networks)**—The channel defaults to automatic for infrastructure networks.

  Some ad hoc networks will also require the automatic setting. Check with your system support person if you are not sure which channel to select.
- **Security Method**—There are four basic options for Security Method:
  - WEP key

    If your network uses more than one WEP key, then enter up to four in the provided spaces. Select the key currently in use on the network by selecting the default WEP transmit key.
  - WPA or WPA2 preshared key or passphrase

    WPA includes encryption as an additional layer of security. The choices are AES or TKIP. Encryption must be set for the same type on the router and on the printer, or the printer will not be able to communicate on the network.
  - 802.1X–RADIUS

    If you are installing the printer on an 802.1X network, then you may need the following:
    - Authentication type
    - Inner authentication type
    - 802.1X user name and password
    - Certificates
  - No security

    If your wireless network does not use any type of security, then you will not have any security information.

    Note: Using an unsecured wireless network is not recommended.

Notes:

- If you do not know the SSID of the network that your computer is connected to, then launch the wireless utility of the computer network adapter, and then look for the network name. If you cannot find the SSID or the security information for your network, then see the documentation that came with the access point or contact your system support person.
- To find the WPA/WPA2 preshared key or passphrase for the wireless network, see the documentation that came with the access point, see the Embedded Web Server associated with the access point, or consult your system support person.

Installing the printer on a wireless network (Windows)

Before installing the printer on a wireless network, make sure:

- Your wireless network is set up and is working properly.
- The computer you are using is connected to the same wireless network where you want to set up the printer.

1 Connect the power cord to the printer, then to a properly grounded electrical outlet, and then turn on the printer.



Note: Make sure the printer and the computer are fully on and ready.

Warning—Potential Damage: Do not connect the USB cable until instructed to do so on the computer screen.

2 Obtain a copy of the software installer package.

- From the *Software and Documentation* CD that came with your printer.
- From our Web site:
  Go to **http://support.lexmark.com**, and then navigate to:
  SUPPORT & DOWNLOAD > select your printer > select your operating system

3 Double-click the software installer package.

Wait for the installation dialog to appear.

If you are using the *Software and Documentation* CD and the installation dialog does not appear, then do the following:

In Windows 8

From the Search charm, type **run**, and then navigate to:

Apps list > **Run** > type **D:\setup.exe** > **OK**

In Windows 7 or earlier

a Click or click **Start**, and then click **Run**.

b In the Start Search or Run dialog, type **D:\setup.exe**.

c Press **Enter** or click **OK**.

Note: **D** is the letter of your CD or DVD drive.

4 Click **Install**, and then follow the instructions on the computer screen.

5 Select **Wireless connection** when asked to choose a connection type.

6 From the Wireless Configuration dialog, select **Guided Setup (Recommended)**.

Note: Choose **Advanced Setup** only if you want to customize your installation.

7 Temporarily connect a USB cable between the computer on the wireless network and the printer.



Note: After the printer is configured, the software will instruct you to disconnect the temporary USB cable so you can print wirelessly.

8 Follow the instructions on the computer screen.

Note: For more information on allowing other computers on the network to use the wireless printer, see the *Networking Guide*.

Installing the printer on a wireless network (Macintosh)

Note: Make sure to disconnect the Ethernet cable when installing the printer on a wireless network.

Prepare to configure the printer

1 Connect the power cord to the printer, then to a properly grounded electrical outlet, and then turn on the printer.





2 Locate the printer MAC address.

   a From the printer control panel, navigate to:

   > **Reports** > > **Network Setup Page** >

   or

   > **Reports** > **Network Setup Page**

   b In the Standard Network Card section, look for **UAA (MAC)**.

   Note: You will need this information later.

Enter the printer information

1 Access the AirPort options:

In Mac OS X version 10.5 or later

From the Apple menu, navigate to either of the following:

- **System Preferences** > **Network** > **Wi-Fi**
- **System Preferences** > **Network** > **AirPort**

In Mac OS X version 10.4

From the Finder, navigate to:

Applications > **Internet Connect** > **AirPort**

2 From the Network Name pop-up menu, select **print server [yyyyyy]**, where the **y**'s are the last six digits of the MAC address located on the MAC address sheet.

3 Open a Web browser.

4 From the Bookmarks menu, select **Show** or **Show All Bookmarks**.

5 Under COLLECTIONS, select **Bonjour** or **Rendezvous**, and then double-click the printer name.

Note: The application referred to as *Rendezvous* in Mac OS X version 10.2 is now called *Bonjour* by Apple Inc.

6 From the Embedded Web Server, navigate to the location of the wireless settings information.

Configure the printer for wireless access

1. Type the network name (SSID) in the appropriate field.
2. Select **Infrastructure** as your Network Mode setting if you are using an access point (wireless router).
3. Select the type of security you want to use to protect the wireless network.
4. Enter the security information necessary for the printer to connect to the wireless network.
5. Click **Submit**.
6. Open the AirPort application on the computer:

   In Mac OS X version 10.5 or later

   From the Apple menu, navigate to either of the following:

   - **System Preferences** > **Network** > **Wi-Fi**
   - **System Preferences** > **Network** > **AirPort**

   In Mac OS X version 10.4

   From the Finder, navigate to:

   Applications > **Internet Connect** > **AirPort**
7. From the Network pop-up menu, select the name of the wireless network.

Configure your computer to use the printer wirelessly

To print on a network printer, each Macintosh user must install a custom printer driver file and create a print queue in the Printer Setup Utility or Print Center.

1. Install a printer driver file on the computer:
   a. Obtain a copy of the software installer package.
      - From the *Software and Documentation* CD that came with your printer.
      - From our Web site:
        Go to **http://support.lexmark.com**, and then navigate to:
        SUPPORT & DOWNLOAD > select your printer > select your operating system

   b. Double-click the installer package for the printer.
   c. Follow the instructions on the computer screen.
   d. Select a destination, and then click **Continue**.
   e. From the Easy Install screen, click **Install**.
   f. Type the user password, and then click **OK**.
      All necessary applications are installed in the computer.
   g. Click **Close** when the installation is complete.
2. Add the printer:
   a. For IP printing:

      In Mac OS X version 10.5 or later

      1. From the Apple menu, navigate to either of the following:
         - **System Preferences** > **Print & Scan**
         - **System Preferences** > **Print & Fax**

2 Click **+**.
3 If necessary, click **Add Printer or Scanner** or **Add Other Printer or Scanner**.
4 Click the **IP** tab.
5 Type the IP address of the printer in the address field, and then click **Add**.

In Mac OS X version 10.4

1 From the Finder, navigate to:
Applications > **Utilities**
2 Double-click **Printer Setup Utility** or **Print Center**.
3 From the Printer List, choose **Add**, and then click **IP Printer**.
4 Type the IP address of the printer in the address field, and then click **Add**.

b For AppleTalk printing:

Notes:

- Make sure AppleTalk is activated on your printer.
- This feature is supported only in Mac OS X version 10.5 or earlier.

In Mac OS X version 10.5

1 From the Apple menu, navigate to:
System Preferences > **Print & Fax**
2 Click **+**, and then navigate to:
AppleTalk > select the printer from the list > **Add**

In Mac OS X version 10.4

1 From the Finder, navigate to:
Applications > **Utilities**
2 Double-click **Printer Setup Utility** or **Print Center**.
3 From the Printer List, click **Add**.
4 Click **Default Browser** tab > **More Printers**.
5 From the first pop-up menu, select **AppleTalk**.
6 From the second pop-up menu, select **Local AppleTalk Zone**.
7 Select the printer from the list, and then click **Add**.

Changing port settings after installing a new network ISP

Notes:

- If the printer has a static IP address, then you do not need to make any changes.
- If the computers are configured to use the network name, instead of an IP address, then you do not need to make any changes.
- If you are adding a wireless ISP to a printer previously configured for an Ethernet connection, then make sure the printer is disconnected from the Ethernet network.

For Windows users

1 Open the printers folder.
2 From the shortcut menu of the printer with the new ISP, open the printer properties.

3 Configure the port from the list.

4 Update the IP address.

5 Apply the changes.

For Macintosh users

1 From System Preferences in the Apple menu, navigate to the list of printers, and then select **+** > **IP**.

2 Type the IP address in the address field.

3 Apply the changes.

Setting up serial printing (Windows only)

After installing the serial or communication (COM) port, configure the printer and the computer.

Note: Serial printing reduces print speed.

1 Set the parameters in the printer.

   a From the control panel, navigate to the menu for the port settings.

   b Locate the menu for the serial port settings, and then adjust the settings, if necessary.

   c Save the settings.

2 From your computer, open the printers folder, and then select your printer.

3 Open the printer properties, and then select the COM port from the list.

4 Set the COM port parameters in Device Manager.

   Use the Run dialog box to open the command prompt, and then type **`devmgmt.msc`**.

Minimizing your printer's environmental impact

Lexmark is committed to environmental sustainability and is continually improving its printers to reduce their impact on the environment. We design with the environment in mind, engineer our packaging to reduce materials, and provide collection and recycling programs. For more information, see:

- The Notices chapter
- The Environmental Sustainability section of the Lexmark Web site at **www.lexmark.com/environment**
- The Lexmark recycling program at **www.lexmark.com/recycle**

By selecting certain printer settings or tasks, you may be able to reduce your printer's impact even further. This chapter outlines the settings and tasks that may yield a greater environmental benefit.

Saving paper and toner

Studies show that as much as 80% of the carbon footprint of a printer is related to paper usage. You can significantly reduce your carbon footprint by using recycled paper and the following printing suggestions, such as printing on both sides of the paper and printing multiple pages on one side of a sheet of paper.

For information on how you can quickly save paper and energy using one printer setting, see "Using Eco-Mode" on page 51.

Using recycled paper

As an environmentally conscious company, Lexmark supports the use of recycled office paper produced specifically for use in laser/LED printers. For more information on recycled papers that work well with your printer, see "Using recycled paper and other office papers" on page 70.

Conserving supplies

Use both sides of the paper

If your printer model supports two-sided printing, then you can control whether print appears on one or two sides of the paper.

Notes:

- Two-sided printing is the default setting in the print driver.
- For a complete list of supported products and countries, go to **http://support.lexmark.com**.

Place multiple pages on one sheet of paper

You can print up to 16 consecutive pages of a multiple-page document onto one side of a single sheet of paper by setting multiple page printing (N-Up) for the print job.

Check your first draft for accuracy

Before printing or making multiple copies of a document:

- Use the preview feature to see how the document looks like before you print it.
- Print one copy of the document to check its content and format for accuracy.

Avoid paper jams

Correctly set the paper type and size to avoid paper jams. For more information, see "Avoiding jams" on page 175.

Saving energy

Using Eco-Mode

1. Type the printer IP address into the address field of your Web browser.

   If you do not know the IP address of the printer, you can:

   - View the IP address on the printer control panel in the TCP/IP section under the Networks/Ports menu.
   - Print a network setup page or the menu settings pages and locate the IP address in the TCP/IP section.

2. Click **Settings** > **General Settings** > **Eco-Mode** > select a setting > **Submit**.

Choose	To
Off	Use factory default settings for all settings associated with Eco-Mode. This setting supports the performance specifications of your printer.
Energy	Reduce energy use, especially when the printer is idle. • Printer engine motors do not start until it is ready to print. You may notice a short delay before the first page is printed. • The printer enters Sleep mode after one minute of inactivity. • When the printer enters Sleep mode, the printer control panel display and the standard exit bin lights are turned off. • If scanning is supported, the scanner lamps are activated only when a scan job is started.
Energy/Paper	Use all the settings associated with Energy mode and Paper mode.
Paper	• Enable the automatic duplex feature. • Turn off print log features.

Reducing printer noise

To select a Quiet Mode setting using the Embedded Web Server:

1. Type the printer IP address into the address field of your Web browser.

   If you do not know the IP address of the printer, you can:

   - View the IP address on the printer control panel in the TCP/IP section under the Networks/Ports menu.
   - Print a network setup page or the menu settings pages and locate the IP address in the TCP/IP section.

2. Click **Settings** > **General Settings** > **Quiet Mode** > select a setting > **Submit**.

Choose	To
Off **Note:** Selecting **Photo** from the driver may disable Quiet Mode and provide better print quality and full speed printing.	Use factory default settings. This setting supports the performance specifications of your printer.
On	Reduce printer noise. • Print jobs will process at a reduced speed. • Printer engine motors do not start until a document is ready to print. There will be a short delay before the first page is printed. • If your printer has faxing capability, fax sounds are reduced or disabled, including those made by the fax speaker and ringer. The fax is placed in standby mode. • The alarm control and cartridge alarm sounds are turned off. • The printer will ignore the Advance Start command.

Adjusting Sleep mode

1 From the home screen, navigate to:

> **Settings** > **General Settings** > **Timeouts** > **Sleep Mode**

2 In the Sleep Mode field, select the number of minutes the printer is idle before it enters Sleep mode.

3 Apply the changes.

Using Hibernate Mode

Hibernate is an ultra-low power operating mode. When operating in Hibernate mode, all other systems and devices are powered down safely.

Using the Embedded Web Server

1 Type the printer IP address into the address field of your Web browser.

If you do not know the IP address of the printer, you can:

- View the IP address on the printer control panel in the TCP/IP section under the Networks/Ports menu.
- Print a network setup page or the menu settings pages and locate the IP address in the TCP/IP section.

2 Click **Settings** > **General Settings** > **Sleep Button Settings**.

3 From the Press Sleep Button or Press and Hold Sleep Button drop-down, select **Hibernate**.

4 Click **Submit**.

Using the printer control panel

1 From the home screen, navigate to:

> **Settings** > **General Settings** > **Press Sleep Button** or **Press and Hold Sleep Button** > **Hibernate**

2 Touch .

Adjusting the brightness of the printer display

To save energy, or if you have trouble reading from the display, adjust the brightness of the display.

Using the Embedded Web Server

1 Open a Web browser, and then type the printer IP address in the address field.

Notes:

- The IP address is located on the upper portion of the home screen. It appears as four sets of numbers separated by periods, such as 123.123.123.123.
- If you are using a proxy server, then temporarily disable it to load the Web page correctly.

2 Select **Settings** > **General Settings**.

3 In the Screen Brightness field, enter the brightness percentage you want for the display.

4 Apply the changes.

Using the control panel

1 From the home screen, navigate to:

> **Settings** > **General Settings**

2 In the Screen Brightness field, enter the brightness percentage you want for the display.

3 Apply the changes.

Recycling

Recycling Lexmark products

To return Lexmark products for recycling:

1 Go to **www.lexmark.com/recycle**.

2 Find the product type you want to recycle, and then select your country or region from the list.

3 Follow the instructions on the computer screen.

Note: Printer supplies and hardware not listed in the Lexmark collection program may be recycled through your local recycling center. Contact your local recycling center to determine the items they accept.

Recycling Lexmark packaging

Lexmark continually strives to minimize packaging. Less packaging helps to ensure that Lexmark printers are transported in the most efficient and environmentally sensitive manner and that there is less packaging to dispose of. These efficiencies result in fewer greenhouse emissions, energy savings, and natural resource savings.

Lexmark cartons are 100% recyclable where corrugated recycling facilities exist. Facilities may not exist in your area.

The foam used in Lexmark packaging is recyclable where foam recycling facilities exist. Facilities may not exist in your area.

When you return a cartridge to Lexmark, you can reuse the box that the cartridge came in. Lexmark will recycle the box.

Returning Lexmark cartridges for reuse or recycling

Lexmark Cartridge Collection Program diverts millions of Lexmark cartridges from landfills annually by making it both easy and free for Lexmark customers to return used cartridges to Lexmark for reuse or recycling. One hundred percent of the empty cartridges returned to Lexmark are either reused or demanufactured for recycling. Boxes used to return the cartridges are also recycled.

To return Lexmark cartridges for reuse or recycling, follow the instructions that came with your printer or cartridge and use the prepaid shipping label. You can also do the following:

1. Go to **www.lexmark.com/recycle**.
2. From the Toner Cartridges section, select your country or region.
3. Follow the instructions on the computer screen.

Loading paper and specialty media

Setting the paper size and type

The Paper Size setting is automatically sensed according to the position of the paper guides in each tray except the multipurpose feeder. The Paper Size setting for the multipurpose feeder must be set manually from the Paper Size menu. The Paper Type setting must be set manually for all trays that do not contain plain paper.

From the home screen navigate to:

> **Paper Menu** > **Paper Size/Type** > select a tray > select the paper size or type >

The factory default Paper Type setting is Plain Paper.

Configuring Universal paper settings

The Universal Paper Size is a user-defined setting that lets you print on paper sizes that are not preset in the printer menus. Set paper size to Universal for the specified tray when the size you want is not available from the Paper Size menu. Then, specify all of the following Universal size settings for your paper:

- Units of Measure
- Portrait Width
- Portrait Height

The following are the supported Universal sizes:

- 76.2–296.93 x 76.2–1219.2 mm (3–11.69 x 3–48 inches)
- 297.18–320.29 x 76.2–609.6 mm (11.70–12.61 x 3–24 inches)
- 320.55–609.6 x 76.2–320.29 mm (12.62–24 x 3–12.61 inches)
- 609.85–1219.2 x 76.2–296.93 mm (24.01–48 x 3–11.69 inches)

1. From the home screen, navigate to:

   > **Paper Menu** > **Universal Setup** > **Units of Measure** > select a unit of measure

2. Touch **Portrait Width** or **Portrait Height**.

3. Select the width or height, and then touch .

Loading the standard or optional 520-sheet tray

The printer has one standard 520-sheet tray (Tray 1), and may have one or more optional 520-sheet trays. All 520-sheet trays support the same paper sizes and types.

CAUTION—POTENTIAL INJURY: To reduce the risk of equipment instability, load each paper drawer or tray separately. Keep all other drawers or trays closed until needed.

1 Pull the tray out.



Notice the size indicators at the bottom of the tray. Use these indicators to help position the length and width guides.



2 Squeeze and then slide the width guide to the correct position for the paper size loaded.



3 Squeeze and then slide the length guide to the correct position for the paper size loaded.

Note: The length guide has a locking device. To unlock, slide the button on top of the length guide down. To lock, slide the button up when a length has been selected.



4 Flex the sheets back and forth to loosen them. Do not fold or crease the paper. Straighten the edges on a level surface.



5 Load the paper stack with the recommended print side faceup.

Notes:

- Place print side facedown for duplex printing.
- Place pre-punched paper with the holes toward the front of the tray.
- Place letterheads with the header on the left side of the tray.
- Make sure the paper is below the maximum fill line located on the edge of the paper tray.

Warning—Potential Damage: Overloading the tray can cause paper jams and possible printer damage.



6 Insert the tray.



7 From the printer control panel, verify the Paper Size and Paper Type setting for the tray based on the paper you loaded.

Loading the optional 850- and 1,150-sheet trays

The 850- and 1,150-sheet trays support the same paper sizes and types, and require the same process for loading paper.

CAUTION—POTENTIAL INJURY: To reduce the risk of equipment instability, load each paper drawer or tray separately. Keep all other drawers or trays closed until needed.

1 Pull the tray out.



2 Squeeze and then slide the length guide to the correct position for the paper size you are loading.



3 Flex the sheets back and forth to loosen them. Do not fold or crease the paper. Straighten the edges on a level surface.



4 Load the paper stack with the recommended print side faceup.



Notes:

- Place print side facedown for duplex printing.
- Place pre-punched paper with the holes toward the front of the tray.
- Place letterheads faceup with the header on the left side of the tray.
- Place letterheads facedown with the header on the right side of the tray for duplex printing.
- Make sure the paper is below the maximum fill line located on the edge of the paper tray.

Warning—Potential Damage: Overloading the tray can cause paper jams and possible printer damage.

5 Insert the tray.

6 From the printer control panel, verify the Paper Size and Paper Type setting for the tray based on the paper you loaded.

Loading the 2000-sheet high-capacity feeder

The high-capacity feeder can hold up to 2,000 sheets of letter-, A4-, and legal-size paper (80 g/m^2 or 20 lb).

1 Pull the tray out.



2 Adjust the width guide as necessary.



3 Flex the sheets back and forth to loosen them. Do not fold or crease the paper. Straighten the edges on a level surface.



4 Load paper into the tray with the print side faceup.



Note: Make sure the paper is below the maximum fill line located on the edge of the paper tray. Overloading the tray can cause paper jams and possible printer damage.



Notes:

- Place pre-punched paper with the holes toward the front of the tray.
- Place letterheads faceup with the header on the left side of the tray.
- Place letterheads facedown with the header on the right side of the tray for duplex printing.

5 Insert the tray.

Loading the multipurpose feeder

The multipurpose feeder can hold several sizes and types of print media, such as transparencies, labels, card stock, and envelopes. It can be used for single-page or manual printing, or as an additional tray.

The multipurpose feeder can hold approximately:

- 100 sheets of 75-g/m^2 (20-lb) paper
- 10 envelopes
- 75 transparencies

The multipurpose feeder accepts paper or specialty media within the following dimensions:

- Width—89 mm (3.5 in.) to 229 mm (9.02 in.)
- Length—127 mm (5 in.) to 1270 mm (50 in.)

Note: Maximum width and length can be applied only to short-edge feeding.

Note: Do not add or remove paper or specialty media when the printer is printing from the multipurpose feeder or when the printer control panel indicator light is blinking. Doing so may cause a jam.

1 Pull down the multipurpose feeder door.



2 For paper or specialty media that is longer than letter-size paper, gently pull the extension until it is fully extended.



3 Flex the sheets of paper or specialty media back and forth to loosen them. Do not fold or crease them. Straighten the edges on a level surface.

Paper



Envelopes



Transparencies

Note: Avoid scratching or touching the print side.



4 Push the paper pick tab, and then load the paper or specialty media. Slide the stack gently into the multipurpose feeder until it comes to a stop, and then release the paper pick tab.



Warning—Potential Damage: Pulling the paper out, without pushing the paper pick tab first, may cause jams or the paper pick tab to break.

- Load paper and transparencies with the recommended print side facedown and the long edge entering the printer first.
- For duplex letterhead printing, place the letterhead faceup and the header entering the printer last.
- Load envelopes with the flap side up and to the right.



Warning—Potential Damage: Never use envelopes with stamps, clasps, snaps, windows, coated linings, or self-stick adhesives. These envelopes may severely damage the printer.

Notes:

- Do not exceed the maximum stack height by forcing paper or transparencies under the stack height limiter.
- Load only one size and type of paper at a time.

5 Adjust the width guide to lightly touch the edge of the stack. Make sure the paper or specialty media fits loosely in the multipurpose feeder, lies flat, and is not bent or wrinkled.



6 From the printer control panel, set the Paper Size and Paper Type for the multipurpose feeder (MP Feeder Size and MP Feeder Type) based on the paper or specialty media loaded.

Linking and unlinking trays

Linking and unlinking trays

1 Open a Web browser, and then type the printer IP address in the address field.

Notes:

- View the printer IP address on the printer home screen. The IP address appears as four sets of numbers separated by periods, such as 123.123.123.123.
- If you are using a proxy server, then temporarily disable it to load the Web page correctly.

2 Click **Settings** > **Paper Menu**.

3 Change the paper size and type settings for the trays you are linking.

- To link trays, make sure the paper size and type for the tray match that of the other tray.
- To unlink trays, make sure the paper size or type for the tray does *not* match that of the other tray.

4 Click **Submit**.

Note: You can also change the paper size and type settings using the printer control panel. For more information, see "Setting the paper size and type" on page 55.

Warning—Potential Damage: Paper loaded in the tray should match the paper type name assigned in the printer. The temperature of the fuser varies according to the specified paper type. Printing issues may occur if settings are not properly configured.

Linking exit bins

Link exit bins to create a single output source. The printer automatically uses the next available bin as the output source.

The standard exit bin holds up to 550 sheets of 20-lb paper. If you need additional output capacity, you can purchase other optional exit bins.

Note: Not all exit bins support every paper size and type.

1 From the home screen, navigate to:

> **Paper Menu** > **Bin Setup**

2 Touch the bin or bins you want to link, and then touch **Configure Bins** > **Link**.

Creating a custom name for a paper type

If the printer is on a network, you can use the Embedded Web Server to define a name other than Custom Type [x] for each of the custom paper types loaded into the printer.

1 Type the printer IP address into the address field of your Web browser.

Note: If you do not know the IP address of the printer, then you can:

- View the IP address on the printer control panel in the TCP/IP section under the Networks/Ports menu.
- Print a network setup page or the menu settings pages and locate the IP address in the TCP/IP section.

2 Click **Settings** > **Paper Menu** > **Custom Name** > type a name > **Submit**.

Note: This custom name will replace the Custom Type [x] name under the Custom Types and Paper Size and Type menus.

3 Click **Custom Types** > select a paper type > **Submit**.

Assigning a custom paper type name

1 From the home screen, navigate to:

> **Paper Menu** > **Paper Size/Type**

2 Select the tray number or MP Feeder Type.

3 Touch the left or right arrow until **`Custom Type [x]`** or another custom name appears.

4 Touch .

Configuring a custom name

If the printer is on a network, then you can use the Embedded Web Server to define a name other than Custom Type [x] for each of the custom paper types loaded into the printer.

1 Type the printer IP address in the address field of your Web browser.

Note: If you do not know the IP address of the printer, then you can:

- View the IP address on the printer control panel in the TCP/IP section under the Networks/Ports menu.
- Print a network setup page or the menu settings pages and locate the IP address in the TCP/IP section.

2 Click **Settings** > **Paper Menu** > **Custom Types** > select the custom name you want to configure > select a paper or specialty media type > **Submit**.

Paper and specialty media guide

Notes:

- Make sure that the paper size, type, and weight are set correctly on the computer or on the control panel.
- Flex, and straighten specialty media before loading them.
- The printer may print at a reduced speed to prevent damage to the fuser.
- For more information on card stock and labels, see the *Card Stock & Label Guide* on the Lexmark support Web site at **http://support.lexmark.com**.

Paper guidelines

Paper characteristics

The following paper characteristics affect print quality and reliability. Consider these characteristics when evaluating new paper stock.

Weight

The printer trays can automatically feed paper weights from 60 to 300 g/m^2 (16–80 lb bond) grain long. Paper lighter than 60 g/m^2 (16 lb) might not be stiff enough to feed properly, causing jams. For best performance, use 75 g/m^2 (20 lb bond) grain long paper. For paper smaller than 182 x 257 mm (7.2 x 10.1 in.), we recommend 90 g/m^2 (24 lb) or heavier paper.

Notes:

- The duplex unit supports only 60–169 g/m^2 (16–32 lb bond) paper weights.
- The multipurpose feeder supports 60–300 g/m^2 (16–80 lb bond) paper weights.

Curl

Curl is the tendency for paper to curl at its edges. Excessive curl can cause paper feeding problems. Curl can occur after the paper passes through the printer, where it is exposed to high temperatures. Storing paper unwrapped in hot, humid, cold, or dry conditions, even in the trays, can contribute to paper curling prior to printing and can cause feeding problems.

Smoothness

Paper smoothness directly affects print quality. If paper is too rough, then toner cannot fuse to it properly. If paper is too smooth, then it can cause paper feeding or print quality issues. Always use paper between 100 and 300 Sheffield points; however, smoothness between 150 and 200 Sheffield points produces the best print quality.

Moisture content

The amount of moisture in paper affects both print quality and the ability of the printer to feed the paper correctly. Leave paper in its original wrapper until it is time to use it. This limits the exposure of paper to moisture changes that can degrade its performance.

Store paper in its original wrapper in the same environment as the printer for 24 to 48 hours before printing. Extend the time to several days if the storage or transportation environment is very different from the printer environment. Thick paper may also require a longer conditioning period.

Grain direction

Grain refers to the alignment of the paper fibers in a sheet of paper. Grain is either *grain long*, running the length of the paper, or *grain short*, running the width of the paper.

For 60–135 g/m^2 (16–36 lb bond) paper, grain long paper is recommended. For papers heavier than 135 g/m^2, grain short is recommended.

Fiber content

Most high-quality xerographic paper is made from 100% chemically treated pulped wood. This content provides the paper with a high degree of stability resulting in fewer paper feeding problems and better print quality. Paper containing fibers such as cotton can negatively affect paper handling.

Unacceptable paper

The following paper types are not recommended for use with the printer:

- Chemically treated papers used to make copies without carbon paper, also known as carbonless papers, carbonless copy paper (CCP), or no carbon required (NCR) paper
- Preprinted papers with chemicals that may contaminate the printer
- Preprinted papers that can be affected by the temperature in the printer fuser
- Preprinted papers that require a registration (the precise print location on the page) greater than ±2.3 mm (±0.9 in.), such as optical character recognition (OCR) forms

  In some cases, registration can be adjusted with a software application to successfully print on these forms.
- Coated papers (erasable bond), synthetic papers, thermal papers
- Rough-edged, rough or heavily textured surface papers, or curled papers
- Recycled papers that fail EN12281:2002 (European)
- Paper weighing less than 60 g/m^2 (16 lb)
- Multiple-part forms or documents

Selecting paper

Using appropriate paper prevents jams and helps ensure trouble-free printing.

To help avoid jams and poor print quality:

- *Always* use new, undamaged paper.
- Before loading paper, know the recommended print side of the paper. This information is usually indicated on the paper package.
- *Do not* use paper that has been cut or trimmed by hand.
- *Do not* mix paper sizes, types, or weights in the same source; mixing results in jams.
- *Do not* use coated papers unless they are specifically designed for electrophotographic printing.

Selecting preprinted forms and letterhead

Use these guidelines when selecting preprinted forms and letterhead:

- Use grain long for 60 to 90 g/m^2 (16 to 24 lb) weight paper.
- Use only forms and letterhead printed using an offset lithographic or engraved printing process.
- Avoid papers with rough or heavily textured surfaces.

Use papers printed with heat-resistant inks designed for use in xerographic copiers. The ink must be able to withstand temperatures up to 190°C (374°F) without melting or releasing hazardous emissions. Use inks that are not affected by the resin in toner. Inks that are oxidation-set or oil-based generally meet these requirements; latex inks might not. When in doubt, contact the paper supplier.

Preprinted papers such as letterhead must be able to withstand temperatures up to 190°C (374°F) without melting or releasing hazardous emissions.

Using recycled paper and other office papers

As an environmentally conscientious company, Lexmark supports the use of recycled paper produced specifically for use in laser (electrophotographic) printers.

While no blanket statement can be made that all recycled paper will feed well, Lexmark consistently tests papers that represent recycled cut size copier papers available on the global market. This scientific testing is conducted with rigor and discipline. Many factors are taken into consideration both separately and as a whole, including the following:

- Amount of post-consumer waste (Lexmark tests up to 100% post-consumer waste content.)
- Temperature and humidity conditions (Testing chambers simulate climates from all over the world.)
- Moisture content (Business papers should have low moisture: 4–5%.)
- Bending resistance and proper stiffness means optimum feeding through the printer.
- Thickness (impacts how much can be loaded into a tray)
- Surface roughness (measured in Sheffield units, impacts print clarity and how well toner fuses to the paper)
- Surface friction (determines how easily sheets can be separated)
- Grain and formation (impacts curling, which also influences the mechanics of how the paper behaves as it moves through the printer)
- Brightness and texture (look and feel)

Recycled papers are better than ever; however, the amount of recycled content in a paper affects the degree of control over foreign matter. And while recycled papers are one good path to printing in an environmentally responsible manner, they are not perfect. The energy required to de-ink and deal with additives such as colorants and “glue” often generates more carbon emissions than does normal paper production. However, using recycled papers enables better resource management overall.

Lexmark concerns itself with the responsible use of paper in general based on life cycle assessments of its products. To gain a better understanding of the impact of printers on the environment, the company commissioned a number of life cycle assessments and found that paper was identified as the primary contributor (up to 80%) of carbon emissions caused throughout the entire life of a device (from design to end-of-life). This is due to the energy-intensive manufacturing processes required to make paper.

Thus, Lexmark seeks to educate customers and partners on minimizing the impact of paper. Using recycled paper is one way. Eliminating excessive and unnecessary paper consumption is another. Lexmark is well-equipped to help customers minimize printing and copying waste. In addition, the company encourages purchasing paper from suppliers who demonstrate their commitment to sustainable forestry practices.

Lexmark does not endorse specific suppliers, although a converter's product list for special applications is maintained. However, the following paper choice guidelines will help alleviate the environmental impact of printing:

1. Minimize paper consumption.
2. Be selective about the origin of wood fiber. Buy from suppliers who carry certifications such as the Forestry Stewardship Council (FSC) or The Program for the Endorsement of Forest Certification (PEFC). These certifications guarantee that the paper manufacturer uses wood pulp from forestry operators that employ environmentally and socially responsible forest management and restoration practices.
3. Choose the most appropriate paper for printing needs: normal 75 or 80 g/m^2 certified paper, lower weight paper, or recycled paper.

Unacceptable paper examples

Test results indicate that the following paper types are at risk for use with laser printers:

- Chemically treated papers used to make copies without carbon paper, also known as *carbonless papers*
- Preprinted papers with chemicals that may contaminate the paper
- Preprinted papers that can be affected by the temperature in the printer fuser
- Preprinted papers that require a registration (the precise location on the page) greater than ± 2.3 mm (± 0.9 in.), such as optical character recognition (OCR) forms. In some cases, registration can be adjusted with a software application to successfully print on these forms.)
- Coated papers (erasable bond), synthetic papers, thermal papers
- Rough-edged, rough or heavily textured surface papers or curled papers
- Recycled papers that fail EN12281:2002 (European testing)
- Paper weighing less than 60 g/m^2 (16 lb)
- Multiple part forms or documents

For more information about Lexmark, visit **www.lexmark.com**. General sustainability-related information can be found at the **Environmental Sustainability** link.

Storing paper

Use these paper storage guidelines to help avoid jams and uneven print quality:

- For best results, store paper where the temperature is 21°C (70°F) and the relative humidity is 40%. Most label manufacturers recommend printing in a temperature range of 18 to 24°C (65 to 75°F) with relative humidity between 40 and 60%.
- Store paper in cartons when possible, on a pallet or shelf, rather than on the floor.
- Store individual packages on a flat surface.
- Do not store anything on top of individual paper packages.

Supported paper sizes, types, and weights

The following tables provide information on standard and optional paper sources and the sizes, types, and weights of paper they support.

Note: To use a paper size that is unlisted, configure a Universal paper size.

Supported paper sizes

Paper size and dimension	520-sheet tray	2,000-sheet drawer	MP feeder	Manual paper	Manual envelope	Duplex
A4 210 x 297 mm (8.27 x 11.7 in.)	✓[1]	✓[1,6]	✓[2,6]	✓[2,6]	X	✓[2]
A5 148 x 210 mm (5.83 x 8.27 in.)	✓[1,5]	X	✓[2,5]	✓[2,5]	X	✓[2,5]
A6 105 x 148 mm (4.13 x 5.83 in.)	X	X	✓[2]	✓[2]	X	X
JIS B5 182 x 257 mm (7.17 x 10.1 in.)	✓[1,6]	✓[1,6]	✓[2,6]	✓[2,6]	X	✓[2,6]
Letter 216 x 279 mm (8.5 x 11 in.)	✓[1]	✓[1,6]	✓[2,6]	✓[2,6]	X	✓[2]
Legal 216 x 356 mm (8.5 x 14 in.)	✓[1]	X	✓[2]	✓[2]	X	✓[2]
Executive 184 x 267 mm (7.25 x 10.5 in.)	✓[1,6]	✓[1,6]	✓[2,6]	✓[2,6]	X	✓[2,6]
JIS B4 257 x 364 mm (10.12 x 14.33 in.)	✓[1]	X	✓[2]	✓[2]	X	✓[2]
A3 297 x 420 mm (11.69 x 16.54 in.)	✓[1]	X	✓[2]	✓[2]	X	✓[2]
SRA3 320 x 450 mm (12.6 x 17.7 in.)	✓[7]	X	✓[2]	✓[2]	X	✓[2]
11x17 279 x 432 mm (11 x 17 in.)	✓[1]	X	✓[2]	✓[2]	X	✓[2]

[1] Source supports size with *size sensing*.

[2] Source supports size without *size sensing*.

[3] Paper size is supported if set to metric.

[4] Paper size is supported if set to US.

[5] Paper size is supported if loaded in the short-edge orientation. The short edge of the paper enters the printer first.

[6] Paper size is supported if loaded in the long-edge orientation. The long edge of the paper enters the printer first.

[7] This is applicable only to the optional 520-sheet tray.

Paper size and dimension	520-sheet tray	2,000-sheet drawer	MP feeder	Manual paper	Manual envelope	Duplex
12x18 305 x 457 mm (12 x 18 in.)	√[7]	X	√[2]	√[2]	X	√[2]
Oficio (México) 216 x 340 mm (8.5 x 13.4 in.)	√[2]	X	√[2]	√[2]	X	√[2]
Folio 216 x 330 mm (8.5 x 13 in.)	√[1]	X	√[2]	√[2]	X	√[2]
Statement 140 x 216 mm (5.5 x 8.5 in.)	√[1,5]	X	√[2,5]	√[2,5]	X	√[2,5]
Universal • 76.2–296.93 x 76.2–1219.2 mm (3–11.69 x 3–48 in.) • 297.18–320.29 x 76.2–609.6 mm (11.70–12.61 x 3–24 in.) • 320.55–609.6 x 76.2–320.29 mm (12.62–24 x 3–12.61 in.) • 609.85–1219.2 x 76.2–296.93 mm (24.01–48 x 3–11.69 in.)	√[2]	X	√[2]	√[2]	X	√[2]
7 3/4 Envelope (Monarch) 98 x 191 mm (3.875 x 7.5 in.)	X	X	√[2]	X	√[2]	X
9 Envelope 98 x 226 mm (3.875 x 8.9 in.)	X	X	X	X	X	X
Com 10 Envelope 105 x 241 mm (4.12 x 9.5 in.)	X	X	√[2]	X	√[2]	X
DL Envelope 110 x 220 mm (4.33 x 8.66 in.)	X	X	√[2]	X	√[2]	X
C5 Envelope 162 x 229 mm (6.38 x 9.01 in.)	X	X	√[2]	X	√[2]	X
B5 Envelope 176 x 250 mm (6.93 x 9.84 in.)	X	X	X	X	X	X

[1] Source supports size with *size sensing*.

[2] Source supports size without *size sensing*.

[3] Paper size is supported if set to metric.

[4] Paper size is supported if set to US.

[5] Paper size is supported if loaded in the short-edge orientation. The short edge of the paper enters the printer first.

[6] Paper size is supported if loaded in the long-edge orientation. The long edge of the paper enters the printer first.

[7] This is applicable only to the optional 520-sheet tray.

Paper size and dimension	520-sheet tray	2,000-sheet drawer	MP feeder	Manual paper	Manual envelope	Duplex
Other Envelope 86 x 165 mm to 216 x 356 mm (3.375 x 6.50 in. to 8.5 x 14 in.)	**X**	**X**	✓[2]	**X**	✓[2]	**X**

[1] Source supports size with *size sensing*.

[2] Source supports size without *size sensing*.

[3] Paper size is supported if set to metric.

[4] Paper size is supported if set to US.

[5] Paper size is supported if loaded in the short-edge orientation. The short edge of the paper enters the printer first.

[6] Paper size is supported if loaded in the long-edge orientation. The long edge of the paper enters the printer first.

[7] This is applicable only to the optional 520-sheet tray.

Supported paper types and weights

Printer

The printer supports 60–300 g/m^2 (16–80 lb) paper weights. The duplex unit supports 60–169 g/m^2 (16–32 lb) paper weights.

Note: Labels, transparencies, envelopes, and card stock always print at reduced speed.

Paper type	520-sheet tray	2,000-sheet drawer	MP feeder	Manual paper	Manual envelope	Duplex
Paper • Plain • Bond • Glossy • Colored • Letterhead • Light • Heavy • Preprinted • Recycled	✓	✓	✓	✓	**X**	✓
Heavy Glossy	✓	✓	✓	✓	**X**	**X**
Custom Type [x]	✓	✓	✓	✓	✓	✓
Rough/Cotton	✓	✓	✓	✓	**X**	**X**
Rough Envelope	✓	✓	✓	✓	✓	✓
Card stock	✓	✓	✓	✓	**X**	**X**
Transparencies	✓	✓	✓	✓	**X**	**X**

Paper type	520-sheet tray	2,000-sheet drawer	MP feeder	Manual paper	Manual envelope	Duplex
Labels • Paper	✓	✓	✓	✓	X	X
Envelopes	X	X	✓	X	✓	X

Finisher

The paper capacity of each exit bin is listed in parentheses. Paper capacity estimations are calculated based on 75 g/m^2 (20 lb) paper.

The finisher standard bin supports 60–300 g/m^2 (16–80 lb) paper weights, bin 1 supports 60–220 g/m^2 (16–60 lb) paper weights, and bin 2 (booklet-maker) supports 60–90 g/m^2 (16–24 lb) paper weights plus one additional cover weighted up to 220 g/m^2 (60 lb).

Paper type	Standard 500-sheet bin	Second exit bin	Bin 1	Bin 2	Bin 3
Plain paper	✓	✓	✓	✓	✓
Card stock	✓	✓	✓	✓	X
Transparency	✓	✓	✓	✓	✓
Recycled	✓	✓	✓	✓	✓
Glossy	✓	✓	✓	✓	X
Heavy glossy	✓	✓	✓	✓	X
Labels	✓	✓	X	X	X
Bond	✓	✓	✓	✓	✓
Envelope	✓	✓	X	X	X
Rough envelope	✓	✓	X	X	X
Letterhead	✓	✓	✓	✓	✓
Preprinted	✓	✓	✓	✓	✓
Colored paper	✓	✓	✓	✓	✓
Light paper	✓	✓	✓	✓	✓
Heavy paper	✓	✓	✓	✓	X
Rough/Cotton	✓	✓	✓	✓	✓
Custom Type [x]	✓	✓	✓	✓	✓

Supported finishing features



1	Finisher standard bin
2	Finisher bin 1
3	Finisher bin 2 (booklet-maker)
4	Paper transport

Notes:

- The finisher shown is the booklet finisher. Bin 2 is available only when the booklet finisher is installed.
- All paper tray capacities are based on 75-g/m^2 (20-lb) paper.

Paper transport

- The paper capacity is 50 sheets.
- Finishing options are not supported in this bin.
- Envelopes are routed here.
- Universal paper is routed here when it is longer than 483 mm (19 inches) or shorter than 148 mm (6 inches).

Finisher standard bin

- The paper capacity is 500 sheets.
- Envelopes and executive-size paper are not supported in this bin.
- Finishing options are not supported in this bin.

Bin 1

- The paper capacity is 3,000 sheets when the standard finisher is installed.
- The paper capacity is 1,500 sheets when the booklet finisher is installed.

Size	Punch*	Offset	Single/Double staple	Double dual staple
A3	✓	✓	✓	✓
A4	✓	✓	✓	✓
A5	X	X	X	X
Executive	✓	✓	✓	X
Folio	X	✓	✓	X
JIS B4	✓	✓	✓	X
JIS B5	✓	✓	✓	X
Legal	X	✓	✓	X
Letter	✓	✓	✓	✓
Statement	X	X	X	✓
Tabloid	✓	✓	✓	X
Universal	✓	✓	✓	✓
Envelopes (any size)	X	X	X	X

* For the Universal paper size, the finishing edge must be at least 9 in. (229 mm) for a 3-hole punch and 10 in. (254 mm) for a 4-hole punch.

Punch—Select from two-, three-, or four-hole punch

Single staple—Use only one staple

Double staple—Use two staples

Double dual staple—Use two sets of two staples. This setting is supported only for widths between 8 in. (203 mm) and 12 in. (297 mm) with lengths between 7 in. (182 mm) and 17 in. (432 mm).

Bin 2 (booklet-maker)

Bin 2 is available only when the booklet finisher is installed. The paper capacity of bin 2 (booklet-maker) is 270 sheets or 18 sets of 15-sheet booklets.

Size	Bi fold	Booklet fold	Saddle staple
A3	✓	✓	✓
A4 (only SEF)	✓	✓	✓
A5	X	X	X
Executive	X	X	X
SRA3	✓	✓	✓

SEF—The paper is loaded in the short edge orientation. The short edge of the paper enters the printer first.

Bi fold—Each page is individually folded and stacked separately.

Booklet fold—A multiple-page job is folded along the center into a single booklet.

Saddle staple—A booklet-fold print job is stapled along the center fold.

Size	Bi fold	Booklet fold	Saddle staple
12 x 18	✓	✓	✓
Folio	✓	✓	✓
JIS B4	✓	✓	✓
JIS B5	X	X	X
Legal	✓	✓	✓
Letter (only SEF)	✓	✓	✓
Statement	X	X	X
Tabloid	✓	✓	✓
Universal	X	X	X
Envelopes (any size)	X	X	X

SEF—The paper is loaded in the short edge orientation. The short edge of the paper enters the printer first.
Bi fold—Each page is individually folded and stacked separately.
Booklet fold—A multiple-page job is folded along the center into a single booklet.
Saddle staple—A booklet-fold print job is stapled along the center fold.

Setting the finisher exit bin

1 From the home screen, navigate to:

> **Paper Menu** > **Bin setup** > **Output bin**

2 Select a bin, and then touch .

Notes:

- This function is available only when a finisher is installed.
- The standard finisher bin is the factory default setting.

Printing

The selection and handling of paper and specialty media can affect how reliably documents print. For more information, see “Avoiding jams” on page 175 and “Storing paper” on page 71.

Printing a document

Printing a document

1. From the printer control panel Paper menu, set the Paper Type and Paper Size to match the loaded paper.
2. Send the print job:

   For Windows users

   a. With a document open, click **File** > **Print**.
   b. Click **Properties**, **Preferences**, **Options**, or **Setup**.
   c. Adjust settings as necessary.
   d. Click **OK** > **Print**.

   For Macintosh users

   a. Customize the settings as needed in the Page Setup dialog:
      1. With a document open, choose **File** > **Page Setup**.
      2. Choose a paper size or create a custom size to match the loaded paper.
      3. Click **OK**.
   b. Customize the settings as needed in the Print dialog:
      1. With a document open, choose **File** > **Print**.
         If necessary, click the disclosure triangle to see more options.
      2. From the Print dialog and pop-up menus, adjust the settings as needed.

         Note: To print on a specific paper type, adjust the paper type setting to match the loaded paper, or select the appropriate tray or feeder.
      3. Click **Print**.

Printing in black and white

From the home screen, navigate to:

> **Settings** > **Print Settings** > **Quality Menu** > **Print Mode** > **Black Only** >

Adjusting toner darkness

1. Type the printer IP address into the address field of your Web browser.

If you do not know the IP address of the printer, you can:

- View the IP address on the printer control panel in the TCP/IP section under the Networks/Ports menu.
- Print a network setup page or the menu settings pages and locate the IP address in the TCP/IP section.

2 Click **Settings** > **Print Settings** > **Quality Menu** > **Toner Darkness**.

3 Adjust the toner darkness setting.

4 Click **Submit**.

Using Max Speed and Max Yield

The Max Speed and Max Yield settings let you choose between a faster print speed or a higher toner yield. Max Yield is the factory default setting.

- **Max Speed**—Prints in color unless Black Only is selected in the driver. Prints in black only if the black only driver setting is selected.
- **Max Yield**—Switches from black to color based on the color content found on each page. Frequent color mode switching can result in slower printing if the content of pages is mixed.

Using the Embedded Web Server

1 Type the printer IP address or host name in the address field of your Web browser.

If you do not know the IP address or host name of the printer, then you can:

- View the information on the printer control panel home screen, or in the TCP/IP section under the Networks/Ports menu.
- Print a network setup page or menu settings page, and then locate the information in the TCP/IP section.

2 Click **Configuration** > **Print Settings** > **Setup Menu**.

3 From the Printer Usage list, select **Max Speed** or **Max Yield**.

4 Click **Submit**.

Using the printer control panel

1 From the home screen, navigate to:

> **Settings** > **Print Settings** > **Setup Menu**

2 From the Printer Usage list, select **Max Speed** or **Max Yield**.

3 Touch .

Printing from a mobile device

For the list of supported mobile devices and to download a compatible mobile printing application, visit **http://lexmark.com/mobile**.

Note: Mobile printing applications may also be available from your mobile device manufacturer.

Printing from a flash drive

Printing from a flash drive

Notes:

- Before printing an encrypted PDF file, enter the file password from the printer control panel.
- You cannot print files for which you do not have printing permissions.

1 Insert a flash drive into the USB port.



Notes:

- If you insert the flash drive when the printer requires attention, such as when a jam has occurred, then the printer ignores the flash drive.
- If you insert the flash drive while the printer is processing other print jobs, then **Busy** appears. After these print jobs are processed, you may need to view the held jobs list to print documents from the flash drive.

Warning—Potential Damage: Do not touch the USB cable, any network adapter, any connector, the memory device, or the printer in the areas shown while actively printing, reading, or writing from the memory device. A loss of data can occur.

2 From the printer control panel, touch the document you want to print.

3 Touch the arrows to increase the number of copies to print, and then touch **Print**.

Notes:

- Do not remove the flash drive from the USB port until the document has finished printing.
- If you leave the flash drive in the printer after leaving the initial USB menu screen, then you can still print files from the flash drive as held jobs.

Supported flash drives and file types

Flash drive	File type
• Lexar JumpDrive 2.0 Pro (256MB, 512MB, or 1GB sizes) • SanDisk Cruzer Mini (256MB, 512MB, or 1GB sizes) **Notes:** • Hi-Speed USB flash drives must support the full-speed standard. Devices supporting only USB low-speed capabilities are not supported. • USB flash drives must support the File Allocation Table (FAT) system. Devices formatted with New Technology File System (NTFS) or any other file system are not supported.	Documents: • .pdf • .xps • .html Images: • .dcx • .gif • .JPEG or .jpg • .bmp • .pcx • .TIFF or .tif • .png

Printing on specialty media

Tips on using letterhead

- Use letterhead designed specifically for laser/LED printers.
- Print samples on the letterhead being considered for use before buying large quantities.
- Before loading letterhead, flex the sheets to prevent them from sticking together.
- Page orientation is important when printing on letterhead.

Source	Print side	Paper orientation
Standard and optional trays (simplex printing)	Preprinted letterhead design is placed faceup.	When feeding short edge, the top edge of the sheet with the logo is placed at the right side of the tray. When feeding long-edge, the letter head should go to the rear of the printer.
Standard and optional trays (duplex printing)	Preprinted letterhead design is placed facedown.	The top edge of the sheet with the logo is placed at the right side of the tray.
Multipurpose feeder (simplex printing)	Preprinted letterhead design is placed facedown.	The top edge of the sheet with the logo should enter the multipurpose feeder first.
Multipurpose feeder (duplex printing)	Preprinted letterhead design is placed faceup.	The top edge of the sheet with the logo should enter the multipurpose feeder last.
Note: Check with the manufacturer or vendor to determine whether the chosen preprinted letterhead is acceptable for laser/LED printers.		

Tips on using transparencies

- Print samples on the transparencies being considered for use before buying large quantities.
- Feed transparencies from the standard tray or from the multipurpose feeder.
- From the Paper menu, set the Paper Type to Transparency.
- Use transparencies designed specifically for laser/LED printers. Transparencies must be able to withstand temperatures of 230°C (446°F) without melting, discoloring, offsetting, or releasing hazardous emissions.
- To prevent print quality problems, avoid getting fingerprints on the transparencies.
- Before loading transparencies, flex the stack to prevent sheets from sticking together.
- We recommend Lexmark transparencies. For ordering information, see the Lexmark Web site at **www.lexmark.com**.

Tips on using envelopes

Print samples on the envelopes being considered for use before buying large quantities.

- Use envelopes designed specifically for laser/LED printers. Check with the manufacturer or vendor to ensure that the envelopes can withstand temperatures up to 220°C (446°F) without sealing, wrinkling, curling excessively, or releasing hazardous emissions.
- For best performance, use envelopes made from 90 g/m^2 (24 lb bond) paper or 25% cotton. All-cotton envelopes must not exceed 70 g/m^2 (20 lb bond) weight.
- Use only new envelopes from undamaged packages.
- To optimize performance and minimize jams, do not use envelopes that:
  - Have excessive curl or twist
  - Are stuck together or damaged in any way
  - Have windows, holes, perforations, cutouts, or embossing
  - Have metal clasps, string ties, or folding bars
  - Have an interlocking design
  - Have postage stamps attached
  - Have any exposed adhesive when the flap is in the sealed or closed position
  - Have bent corners
  - Have rough, cockle, or laid finishes
- Adjust the width guides to fit the width of the envelopes.

Note: A combination of high humidity (over 60%) and the high printing temperature may wrinkle or seal envelopes.

Tips on using labels

Notes:

- Single-sided paper labels designed for laser/LED printers are supported for occasional use.
- It is recommended to print no more than 20 pages of paper labels a month.
- Vinyl, pharmacy, and dual-sided labels are not supported.

For detailed information on label printing, characteristics, and design, see the *Card Stock & Label Guide* available on the Lexmark Web site at **http://support.lexmark.com**.

When printing on labels:

- Use labels designed specifically for laser/LED printers. Check with the manufacturer or vendor to verify that:
  - The labels can withstand temperatures up to 210°C (410°F) without sealing, excessive curling, wrinkling, or releasing hazardous emissions.

    Note: Labels can be printed at a higher fusing temperature up to 220°C (428°F) if Label Weight is set to Heavy. Select this setting using the Embedded Web Server, or from the printer control panel Paper menu.
  - Label adhesives, face sheet (printable stock), and topcoats can withstand up to 25 psi (172 kPa) pressure without delaminating, oozing around the edges, or releasing hazardous fumes.
- Do not use labels with slick backing material.
- Use full label sheets. Partial sheets may cause labels to peel off during printing, resulting in a jam. Partial sheets also contaminate the printer and the cartridge with adhesive, and could void the printer and cartridge warranties.
- Do not use labels with exposed adhesive.

- Do not print within 1 mm (0.04 in.) of the edge of the label, of the perforations, or between die-cuts of the label.
- Be sure adhesive backing does not reach to the sheet edge. Zone coating of the adhesive at least 1 mm (0.04 in.) away from edges is recommended. Adhesive material contaminates the printer and could void the warranty.
- If zone coating of the adhesive is not possible, then remove a 1.6 mm (0.06 in.) strip on the leading and driver edge, and use a non-oozing adhesive.
- Portrait orientation works best, especially when printing bar codes.

Tips on using card stock

Card stock is heavy, single-ply specialty media. Many of its variable characteristics, such as moisture content, thickness, and texture, can significantly impact print quality. Print samples on the card stock being considered for use before buying large quantities.

- From the Paper menu, set the Paper Type to Card Stock.
- Select the appropriate Paper Texture setting.
- Be aware that preprinting, perforation, and creasing may significantly affect the print quality and cause jams or other paper handling problems.
- Check with the manufacturer or vendor to ensure the card stock can withstand temperatures up to 220°C (446°F) without releasing hazardous emissions.
- Do not use preprinted card stock manufactured with chemicals that may contaminate the printer. Preprinting introduces semi-liquid and volatile components into the printer.
- Use grain short card stock when possible.

Printing confidential and other held jobs

Storing print jobs in the printer

You can set the printer to store print jobs in the printer memory until you start the print job from the printer control panel.

All print jobs that can be initiated by the user at the printer are called *held jobs*.

Note: Confidential, Verify, Reserve, and Repeat print jobs may be deleted if the printer requires extra memory to process additional held jobs.

Print job type	Description
Confidential	Confidential lets you hold print jobs in the computer until you enter the PIN from the control panel. **Note:** The PIN is set from the computer. It must be four digits, using the numbers 0–9.
Verify	Verify lets you print one copy of a print job while the printer holds the remaining copies. It allows you to examine if the first copy is satisfactory. The print job is automatically deleted from the printer memory once all copies are printed.
Reserve	Reserve allows the printer to store print jobs for printing at a later time. The print jobs are held until deleted from the Help Jobs menu.
Repeat	Repeat prints *and* stores print jobs in the printer memory for reprinting.

Printing confidential and other held jobs

Note: Confidential and Verify print jobs are automatically deleted from memory after printing. Repeat and Reserve jobs are held in the printer until you choose to delete them.

For Windows users

1. With a document open, click **File** > **Print**.
2. Click **Properties**, **Preferences**, **Options**, or **Setup**.
3. Click **Print and Hold**.
4. Select the print job type (Confidential, Repeat, Reserve, or Verify), and then assign a user name. For a confidential print job, also enter a four-digit PIN.
5. Click **OK** or **Print**.
6. From the printer home screen, release the print job.
   - For confidential print jobs, navigate to:
     Held jobs > your user name > **Confidential Jobs** > enter PIN > select print job > specify number of copies > **Print**
   - For other print jobs, navigate to:
     Held jobs > your user name > select print job > specify number of copies > **Print**

For Macintosh users

1. With a document open, choose **File** > **Print**.
   If necessary, click the disclosure triangle to see more options.
2. From the print options or Copies & Pages pop-up menu, choose **Job Routing**.
3. Select the print job type (Confidential, Repeat, Reserve, or Verify), and then assign a user name. For a confidential print job, also enter a four-digit PIN.
4. Click **OK** or **Print**.
5. From the printer home screen, release the print job.
   - For confidential print jobs, navigate to:
     Held jobs > your user name > **Confidential Jobs** > enter PIN > select print job > specify number of copies > **Print**
   - For other print jobs, navigate to:
     Held jobs > your user name > select print job > specify number of copies > **Print**

Printing information pages

Printing a font sample list

1. From the home screen, navigate to:

   > **Reports** > **Print Fonts**

2. Touch **PCL Fonts** or **PostScript Fonts**.

Printing a directory list

A directory list shows the resources stored in a flash memory or on the printer hard disk.

From the home screen, navigate to:

> **Reports** > **Print Directory**

Canceling a print job

Canceling a print job from the printer control panel

1. From the printer control panel, touch **Cancel Job** or press on the keypad.
2. Touch the print job you want to cancel, and then touch **Delete Selected Jobs**.

   Note: If you press on the keypad, then touch **Resume** to return to the home screen.

Canceling a print job from the computer

For Windows users

1. Open the printers folder.

   In Windows 8

   From the Search charm, type **`run`**, and then navigate to:

   Apps list > **Run** > type **`control printers`** > **OK**

   In Windows 7 or earlier

   a. Click or click **Start**, and then click **Run**.

   b. In the Start Search or Run dialog, type **`control printers`**.

   c. Press **Enter**, or click **OK**.
2. Double-click the printer icon.
3. Select the print job you want to cancel.
4. Click **Delete**.

For Macintosh users

1. From the Apple menu, navigate to either of the following:
   - **System Preferences** > **Print & Scan** > select your printer > **Open Print Queue**
   - **System Preferences** > **Print & Fax** > select your printer > **Open Print Queue**
2. From the printer window, select the print job you want to cancel, and then delete it.

Understanding the printer menus

Menus list

Supplies Menu

Cyan Cartridge
Magenta Cartridge
Yellow Cartridge
Black Cartridge
Cyan Photoconductor Unit
Magenta Photoconductor Unit
Yellow Photoconductor Unit
Black Photoconductor Unit
Waste Toner Bottle
Staple Cartridge
Hole Punch Box
160K Maintenance Kit
320K Maintenance Kit
480K Maintenance Kit

Paper Menu

Default Source
Paper Size/Type
Configure MP
Substitute Size
Paper Texture
Paper Loading
Custom Types
Custom Names
Custom Bin Names
Universal Setup
Bin Setup

Reports

Menu Settings Page
Device Statistics
Network Setup Page
Network [x] Setup Page
Profiles List
Print Fonts
Print Directory
Print Demo
Asset Report

Settings

General Settings
Flash Drive Menu
Print Settings

Security

Miscellaneous Security Settings
Confidential Print
Erase Temporary Data Files[1]
Security Audit Log
Set Date and Time

Network/Ports

Active NIC
Standard Network *or* Network [x][2]
Standard USB
Parallel [x]
Serial [x]
SMTP Setup

Help

Print All Guides
Color Quality
Print Quality
Printing Guide
Media Guide
Print Defects Guide
Menu Map
Information Guide
Connection Guide
Moving Guide
Supplies Guide

[1] This menu appears only when a printer hard disk is installed.

[2] Depending on the printer setup, this menu appears as Standard Network, Wireless Network, or Network [x].

Supplies menu

Menu item	Description
Cyan Cartridge Early Warning Low Invalid Replace Missing or Defective OK Unsupported	Shows the status of the cyan print cartridge
Magenta Cartridge Early Warning Low Invalid Replace Missing or Defective OK Unsupported	Shows the status of the magenta print cartridge
Yellow Cartridge Early Warning Low Invalid Replace Missing or Defective OK Unsupported	Shows the status of the yellow print cartridge
Black Cartridge Early Warning Low Invalid Replace Missing or Defective OK Unsupported	Shows the status of the black print cartridge
Cyan Photoconductor Unit Early Warning Low Replace Missing OK	Shows the status of the cyan photoconductor unit

Menu item	Description
Magenta Photoconductor Unit Early Warning Low Replace Missing OK	Shows the status of the magenta photoconductor unit
Yellow Photoconductor Unit Early Warning Low Replace Missing OK	Shows the status of the yellow photoconductor unit
Black Photoconductor Unit Early Warning Low Replace Missing OK	Shows the status of the black photoconductor unit
Waste Toner Bottle Near Full Replace Missing OK	Shows the status of the waste toner bottle
Staples Early Warning Low Replace Missing OK	Shows the status of the staple cartridge
Hole Punch Box Near Full Replace Missing OK	Shows the status of the hole punch box
160K Maintenance Kit Near End of Life End of Life OK	Shows the status of the maintenance kit
320K Maintenance Kit Near End of Life End of Life OK	Shows the status of the maintenance kit

Menu item	Description
480K Maintenance Kit Near End of Life End of Life OK	Shows the status of the maintenance kit

Paper menu

Default Source menu

Menu item	Description
Default Source Tray [x] MP Feeder Manual Paper Manual Envelope	Sets a default paper source for all print jobs **Notes:** • Tray 1 (standard tray) is the factory default setting. • From the Paper menu, Configure MP feeder must be set to Cassette for MP feeder to appear as a menu setting. • If the same size and type of paper are in two trays and the Paper Size and Paper Type settings match, then the trays are automatically linked. When one tray is empty, the print job continues using the linked tray.

Paper Size/Type menu

Menu item	Description
Tray [x] Size Letter Legal Executive JIS-B4 A3 11 x 17 Oficio (México) Folio Statement Universal A4 A5 A6 JIS B5	Specifies the paper size loaded in each tray **Note:** Letter is the U.S. factory default setting. A4 is the international factory default setting.
Note: Only installed trays are listed in this menu.	

Menu item	Description
Tray [x] Type Plain Paper Card Stock Transparency Recycled Glossy Heavy Glossy Labels Bond Letterhead Preprinted Colored Paper Light Paper Heavy Paper Rough/Cotton Paper Custom Type [x]	Specifies the paper type loaded in each tray **Note:** Plain Paper is the factory default setting for Tray 1. Custom Type [x] is the factory default setting for all other trays.
MP Feeder Size Letter Legal Executive JIS-B4 A3 11 x 17 12 x 18 Oficio (México) Folio Statement Universal 7 3/4 Envelope 10 Envelope DL Envelope C5 Envelope Other Envelope A4 A5 A6 JIS B5 SRA3	Specifies the paper size loaded in the multipurpose feeder **Note:** Letter is the U.S. factory default setting. A4 is the international factory default setting.
Note: Only installed trays are listed in this menu.	

Menu item	Description
MP Feeder Type Custom Type [x] Plain Paper Card Stock Transparency Recycled Glossy Heavy Glossy Labels Bond Envelope Rough Envelope Letterhead Preprinted Colored Paper Light Paper Heavy Paper Rough/Cotton Paper	Specifies the paper type loaded in the multipurpose feeder **Note:** Custom Type [x] is the factory default setting.
Manual Paper Size Letter Legal Executive JIS-B4 A3 11 x 17 12 x 18 Oficio (México) Folio Statement Universal A4 A5 A6 JIS B5 SRA3	Specifies the paper size being manually loaded **Note:** Letter is the U.S. factory default setting. A4 is the international factory default setting.
Note: Only installed trays are listed in this menu.	

Menu item	Description
Manual Paper Type Plain Paper Card Stock Transparency Recycled Glossy Heavy Glossy Labels Bond Letterhead Preprinted Colored Paper Light Paper Heavy Paper Rough/Cotton Paper Custom Type [x]	Specifies the paper type being manually loaded **Note:** Plain Paper is the factory default setting.
Manual Envelope Size 10 Envelope DL Envelope C5 Envelope Other Envelope 7 3/4 Envelope	Specifies the envelope size being manually loaded **Note:** 10 Envelope is the U.S. factory default setting. DL Envelope is the international factory default setting. Printing a custom size envelope is not supported.
Manual Envelope Type Envelope Rough Envelope Custom Type [x]	Specifies the envelope type being manually loaded **Note:** Envelope is the factory default setting.
Note: Only installed trays are listed in this menu.	

Configure MP menu

Menu item	Description
Configure MP Cassette Manual	Determines when the printer selects paper from the multipurpose feeder **Notes:** • Cassette is the factory default setting. This configures the multipurpose feeder as the automatic paper source. • Manual sets the multipurpose feeder only for manual feed print jobs.

Substitute Size menu

Menu item	Description
Substitute Size All Listed Off Statement/A5 Letter/A4 11 x 17/A3	Substitutes a specified paper size if the requested paper size is not available **Notes:** • All Listed is the factory default setting. All available substitutions are allowed. • Off indicates that no size substitutions are allowed. • Setting a size substitution lets the print job continue without a Change Paper message appearing.

Paper Texture menu

Menu item	Description
Plain Texture Normal Rough Smooth	Specifies the relative texture of the paper loaded
Card Stock Texture Normal Rough Smooth	Specifies the relative texture of the card stock loaded **Note:** Settings appear only if card stock is supported.
Transparency Texture Normal Rough Smooth	Specifies the relative texture of the transparencies loaded
Recycled Texture Normal Rough Smooth	Specifies the relative texture of the recycled paper loaded
Glossy Texture Normal Rough Smooth	Specifies the relative texture of the glossy paper loaded
Heavy Glossy Texture Normal Rough Smooth	Specifies the relative texture of the glossy paper loaded
Note: Normal is the factory default setting for all paper types except bond, rough envelope and rough/cotton paper.	

Menu item	Description
Labels Texture Normal Rough Smooth	Specifies the relative texture of the labels loaded
Bond Texture Rough Smooth Normal	Specifies the relative texture of the bond paper loaded
Envelope Texture Normal Rough Smooth	Specifies the relative texture of the envelopes loaded
Rough Envelope Texture Rough	Specifies the relative texture of the envelopes loaded
Letterhead Texture Normal Rough Smooth	Specifies the relative texture of the letterhead loaded
Preprinted Texture Normal Rough Smooth	Specifies the relative texture of the preprinted paper loaded
Colored Texture Normal Rough Smooth	Specifies the relative texture of the colored paper loaded
Light Texture Normal Rough Smooth	Specifies the relative texture of the paper loaded
Heavy Texture Normal Rough Smooth	Specifies the relative texture of the paper loaded
Rough/Cotton Texture Rough	Specifies the relative texture of the cotton paper loaded
Custom [x] Texture Normal Rough Smooth	Specifies the relative texture of the custom paper loaded **Note:** Settings appear only if the custom type is supported.
Note: Normal is the factory default setting for all paper types except bond, rough envelope and rough/cotton paper.	

Paper Loading menu

Use	To
Card Stock Loading Duplex Off	Determine and set two-sided printing for all print jobs with Card Stock as the paper type.
Recycled Loading Duplex Off	Determine and set two-sided printing for all print jobs with Recycled as the paper type.
Glossy Loading Duplex Off	Determine and set two-sided printing for all print jobs with Glossy as the paper type.
Heavy Glossy Loading Duplex Off	Determine and set two-sided printing for all print jobs with Heavy Glossy as the paper type.
Bond Loading Duplex Off	Determine and set two-sided printing for all print jobs with Bond as the paper type.
Letterhead Loading Duplex Off	Determine and set two-sided printing for all print jobs with Letterhead as the paper type.
Preprinted Loading Duplex Off	Determine and set two-sided printing for all print jobs with Preprinted as the paper type.
Colored Loading Duplex Off	Determine and set two-sided printing for all print jobs with Colored as the paper type.
Light Loading Duplex Off	Determine and set two-sided printing for all print jobs with Light as the paper type.
Heavy Loading Duplex Off	Determine and set two-sided printing for all print jobs with Heavy as the paper type.
Rough/Cotton Loading Duplex Off	Determine and set two-sided printing for all print jobs with Rough or Cotton as the paper type.

Notes:

- Off is the factory default setting for all Paper Loading menu selections.
- Duplex sets the printer default to two-sided printing for every print job unless one-sided printing is selected from Print Properties or the print dialog, depending on your operating system.

Use	To
Custom [x] Loading Duplex Off	Determine and set two-sided printing for all print jobs with Custom [x] as the paper type. **Note:** Custom [x] Loading is available only when the custom type is supported.

Notes:

- Off is the factory default setting for all Paper Loading menu selections.
- Duplex sets the printer default to two-sided printing for every print job unless one-sided printing is selected from Print Properties or the print dialog, depending on your operating system.

Custom Types menu

Use	To
Custom Type [x] Paper Card Stock Transparency Glossy Rough/Cotton Labels Bond Envelope	Associate a paper or specialty media type with a Custom Type [x] name. **Notes:** • Paper is the factory default setting for Custom Type [x]. • The specialty media type must be supported in the selected tray or feeder in order to print from that source.
Recycled Paper Card Stock Transparency Glossy Rough/Cotton Labels Envelope	Specify a paper type when the Recycled setting is selected in other menus. **Notes:** • Paper is the factory default setting. • The Recycled paper type must be supported in the selected tray or feeder in order to print from that source.

Custom Names menu

Menu item	Definition
Custom Name [x] [none]	Specify a custom name for a paper type. This name replaces the **Custom Type [x]** name in the printer menus.

Custom Bin Names menu

Menu Item	Description
Standard Bin	Specifies a custom name for the Standard Bin
Bin [x]	Specifies a custom name for Bin [x]

Universal Setup menu

Use	To
Units of Measure Inches Millimeters	Specify the unit of measure. **Note:** Inches is the U.S. factory default setting. Millimeters is the international factory default setting.
Portrait Width 3–48 inches 76–1219 mm	Set the portrait width. **Notes:** • 11.00 inches is the U.S. factory default setting. 297.4 mm is the international factory default setting. • If the width exceeds the maximum, then the printer uses the maximum width allowed. • The width can be increased in 0.01-inch or in 1-mm increments.
Portrait Height 3–48 inches 76–1219 mm	Set the portrait height **Notes:** • 17 inches is the U.S. factory default setting. 431.8 mm is the international factory default setting. • If the height exceeds the maximum, then the printer uses the maximum height allowed. • The height can be increased in 0.01-inch or in 1-mm increments.

Bin Setup menu

Menu item	Description
Output Bin Standard Bin Bin [x]	Specifies the default output bin **Note:** Standard Bin is the factory default setting.
Configure Bins Mailbox Link Type Assignment	Specifies configuration options for output bins **Note:** Mailbox is the factory default setting.

Menu item	Description
Assign Type/Bin Plain Paper Bin Card Stock Bin Transparency Bin Recycled Bin Glossy Bin Heavy Glossy Bin Labels Bin Bond Bin Envelope Bin Rough Envelope Bin Letterhead Bin Preprinted Bin Colored Bin Light Paper Bin Heavy Paper Bin Rough/Cotton Bin Custom [x] Bin	Selects an output bin for each supported paper type Available selections for each type are: Disabled Standard Bin Bin [x] **Note:** Disabled is the factory default setting.

Reports menu

Reports menu

Use	To
Menu Settings Page	Print a report on the current printer settings.
Device Statistics	Print a report containing printer statistics.
Network Setup Page	Print a report on the network printer settings. **Note:** This menu item appears only in network printers or in printers connected to print servers.
Profiles List	Print a list of profiles stored in the printer. **Note:** This menu item appears only when LDSS is enabled.
Print Fonts PCL Fonts PostScript Fonts	Print a report of all the fonts available for the printer language currently set in the printer. **Note:** A separate list is available for PCL and PostScript emulations.
Print Directory	Print a list of all the resources stored in an optional flash memory card. **Notes:** • Job Buffer Size must be set to 100%. • This menu item appears only when an optional flash memory card is installed and is working properly.
Asset Report	Print a report on printer asset information.

Use	To
Print Demo Demo Page	Print demo files that are available in the firmware, the flash option, and the disk option.

Network/Ports menu

Active NIC menu

Menu item	Description
Active NIC Auto [list of available network cards]	**Notes:** • Auto is the factory default setting. • This menu item appears only if an optional network card is installed.

Standard Network or Network [x] menus

Note: Only active ports appear in this menu; all inactive ports are omitted.

Menu item	Description
PCL SmartSwitch On Off	Sets the printer to automatically switch to PCL emulation when a print job requires it, regardless of the default printer language **Notes:** • On is the factory default setting. • When Off is used, the printer does not examine incoming data. The printer uses PostScript emulation if PS SmartSwitch is set to On. It uses the default printer language specified in the Setup menu if PS SmartSwitch is set to Off.
PS SmartSwitch On Off	Sets the printer to automatically switch to PS emulation when a print job requires it, regardless of the default printer language **Notes:** • On is the factory default setting. • When Off is used, the printer does not examine incoming data. The printer uses PCL emulation if PCL SmartSwitch is set to On. It uses the default printer language specified in the Setup menu if PCL SmartSwitch is set to Off.
NPA Mode Auto Off	Sets the printer to perform the special processing required for bidirectional communication following the conventions defined by the NPA protocol **Notes:** • Auto is the factory default setting. • Changing this setting from the printer control panel and then exiting the menus causes the printer to restart. The menu selection is then updated.

Menu item	Description
Network Buffer Auto 3KB to [maximum size allowed]	Sets the size of the network input buffer **Notes:** • Auto is the factory default setting. • The value can be changed in 1-KB increments. • The maximum size allowed depends on the amount of memory in the printer, the size of the other link buffers, and whether Resource Save is set to On or Off. • To increase the maximum size range for the Network Buffer, disable or reduce the size of the parallel, serial, and USB buffers. • Changing this setting from the printer control panel and then exiting the menus causes the printer to restart. The menu selection is then updated.
Job Buffering Off On Auto	Temporarily stores print jobs on the printer hard disk before printing. This menu only appears if a formatted disk is installed. **Notes:** • Off is the factory default setting. • On buffers print jobs on the printer hard disk. • Auto buffers print jobs only if the printer is busy processing data from another input port. • Changing this setting from the printer control panel and then exiting the menus causes the printer to restart. The menu selection is then updated.
Mac Binary PS Auto On Off	Sets the printer to process Macintosh binary PostScript print jobs **Notes:** • Auto is the factory default setting. • Off filters print jobs using the standard protocol. • On processes raw binary PostScript print jobs.
Standard Network Setup Reports Network Card TCP/IP IPv6 Wireless AppleTalk	Displays and sets the printer network settings. **Note:** The Wireless menu appears only when the printer is connected to a wireless network.
Network [x] Setup Reports Network Card TCP/IP IPv6 Wireless AppleTalk	

Network Reports menu

This menu is available from the Network/Ports menu:

Network/Ports > **Standard Network** or **Network [x]** > **Standard Network Setup** or **Network [x] Setup** > **Reports** or **Network Reports**

Menu item	Description
Print Setup Page	Prints a report containing information about the network printer settings, such as the TCP/IP address

Network Card menu

This menu is available from the Network/Ports menu:

Network/Ports > **Standard Network** or **Network [x]** > **Standard Network Setup** or **Network [x] Setup** > **Network Card**

Menu item	Description
View Card Status Connected Disconnected	Lets you view the connection status of the Network Card
View Card Speed	Lets you view the speed of a currently active network card
View Network Address UAA LAA	Lets you view the network addresses
End-of-Job Timeout 0–225	Sets the amount of time in seconds before a network print job is canceled **Notes:** • 90 seconds is the factory default setting. • 0 disables the timeout. • If a value of 1–9 is selected, then the setting is saved as 10.
Banner Page Off On	Allows the printer to print a banner page **Note:** Off is the factory default setting.

TCP/IP menu

Note: This menu is available only in network printers or in printers connected to print servers.

Menu item	Description
Set Hostname	Lets you set the current TCP/IP host name **Note:** This can be changed only from the Embedded Web Server.
IP Address	Lets you view or change the current TCP/IP address **Note:** Manually setting the IP address sets the Enable DHCP and Enable Auto IP settings to Off. It also sets Enable BOOTP and Enable RARP to Off on systems that support BOOTP and RARP.
Netmask	Lets you view or change the current TCP/IP netmask

Menu item	Description
Gateway	Lets you view or change the current TCP/IP gateway
Enable DHCP On Off	Specifies the DHCP address and parameter assignment setting **Note:** On is the factory default setting.
Enable RARP On Off	Specifies the RARP address assignment setting **Note:** Off is the factory default setting.
Enable BOOTP On Off	Specifies the BOOTP address assignment setting **Note:** On is the factory default setting.
Enable AutoIP Yes No	Specifies the Zero Configuration Networking setting **Note:** Yes is the factory default setting.
Enable FTP/TFTP Yes No	Enables the built-in FTP server, which allows you to send files to the printer using File Transfer Protocol. **Note:** Yes is the factory default setting.
Enable HTTP Server Yes No	Enables the built-in Web server (Embedded Web Server). When enabled, the printer can be monitored and managed remotely using a Web browser. **Note:** Yes is the factory default setting.
WINS Server Address	Lets you view or change the current WINS server address
DNS Server Address	Lets you view or change the current DNS server address
Backup DNS Server Address	View or change the backup DNS server addresses.
Backup DNS Server Address 2	
Backup DNS Server Address 3	

IPv6 menu

Note: This menu is available only in network models or in printers attached to print servers.

This menu is available from the Network/Ports menu:

Network/Ports > **Standard Network** or **Network [x]** > **Standard Network Setup** or **Network [x] Setup** > **IPv6**

Menu item	Description
Enable IPv6 On Off	Enables IPv6 in the printer **Note:** On is the factory default setting.
Auto Configuration On Off	Specifies whether the network adapter accepts the automatic IPv6 address configuration entries provided by a router **Note:** On is the factory default setting.
Set Hostname	Lets you set the printer host name

Menu item	Description
View Address	Shows the printer IPv6 address **Note:** The IPv6 address can be changed only from the Embedded Web Server.
View Router Address	Shows the router address **Note:** The router address can be changed only from the Embedded Web Server.
Enable DHCPv6 On Off	Enables DHCPv6 in the printer **Note:** On is the factory default setting.

Wireless menu

Use the following menu items to view or configure the wireless internal print server settings.

Note: This menu is available only in printer models connected to a wireless network.

The Wireless menu is available from the Network/Ports menu:

Network/Ports > **Standard Network** or **Network [x]** > **Standard Network Setup** or **Network [x] Setup** > **Wireless**

Menu item	Description
Wi-Fi Protected Setup Start Push Button	Lets you connect the printer to a wireless network by pressing buttons on both the printer and the access point (wireless router) within a given period of time
Wi-Fi Protected Setup Start PIN Method	Lets you connect the printer to a wireless network by using a PIN on the printer and entering it into the wireless settings of the access point
Enable/Disable WPS Autodetection Enable Disable	Automatically detects the connection method that an access point with WPS uses—WPS Push Button Configuration (PBC) or WPS Personal Identification Number (PIN) **Note:** Disable is the factory default setting.
Network Mode Infrastructure Ad hoc	Specifies the network mode **Notes:** • Ad hoc is the factory default setting. This configures wireless connection directly between the printer and a computer. • Infrastructure lets the printer access a network using an access point.
Compatibility 802.11b/g 802.11b/g/n	Specifies the wireless standard for the wireless network **Note:** The 802.11b/g/n is the factory default setting.
Choose Network [list of available networks]	Lets you select an available network for the printer to use
View Signal Quality	Lets you view the quality of the wireless connection
View Security Mode	Lets you view the encryption method that a wireless network uses

Note: *Wi-Fi Protected Setup* (WPS) is a simple and secure configuration that lets you establish a wireless network and enable network security without requiring prior knowledge of Wi-Fi technology. It is no longer necessary to configure the network name (SSID) and WEP key or WPA passphrase for network devices.

AppleTalk menu

To access the menu, navigate to either of the following:

- **Network/Ports** > **Standard Network** > **Standard Network Setup** > **AppleTalk**
- **Network/Ports** > **Network [x]** > **Network [x] Setup** > **AppleTalk**

Use	To
Activate Yes No	Enable or disable AppleTalk support. **Note:** No is the factory default setting.
View Name	Show the assigned AppleTalk name. **Note:** The AppleTalk name can be changed only from the Embedded Web Server.
View Address	Show the assigned AppleTalk address. **Note:** The AppleTalk address can be changed only from the Embedded Web Server.
Set Zone [list of zones available on the network]	Provide a list of AppleTalk zones available on the network. **Note:** The default zone for the network is the factory default setting.

Standard USB menu

Menu item	Description
PCL SmartSwitch On Off	Sets the printer to automatically switch to PCL emulation when a print job received through a USB port requires it, regardless of the default printer language **Notes:** • On is the factory default setting. • When set to Off, the printer does not examine incoming data. The printer uses PostScript emulation if the PS SmartSwitch is set to On. It uses the default printer language specified in the Setup menu if the PS SmartSwitch is set to Off.
PS SmartSwitch On Off	Sets the printer to automatically switch to PS emulation when a print job received through a USB port requires it, regardless of the default printer language **Notes:** • On is the factory default setting. • When set to Off, the printer does not examine incoming data. The printer uses PCL emulation if the PCL SmartSwitch is set to On. It uses the default printer language specified in the Setup menu if the PCL SmartSwitch is set to Off.

Menu item	Description
NPA Mode Auto On Off	Sets the printer to perform the special processing required for bidirectional communication following the conventions defined by the NPA protocol **Notes:** • Auto is the factory default setting. Auto sets the printer to examine data, determine the format, and then process it appropriately. • Changing this setting from the printer control panel and then exiting the menus causes the printer to restart. The menu selection is then updated.
USB Buffer Auto 3KB to [maximum size allowed] Disabled	Sets the size of the USB input buffer **Notes:** • Auto is the factory default setting. • Disabled turns off job buffering. Any jobs already buffered on the printer hard disk are printed before normal processing resumes. • The USB buffer size value can be changed in 1-KB increments. • The maximum size allowed depends on the amount of memory in the printer, the size of the other link buffers, and whether Resource Save is set to On or Off. • To increase the maximum size range for the USB Buffer, disable or reduce the size of the parallel, serial, and network buffers. • Changing this setting from the printer control panel and then exiting the menus causes the printer to restart. The menu selection is then updated.
Job Buffering Off On Auto	Temporarily stores print jobs on the printer hard disk before printing **Notes:** • Off is the factory default setting. • On buffers jobs on the printer hard disk. • Auto buffers print jobs only if the printer is busy processing data from another input port. • Changing this setting from the printer control panel and then exiting the menus causes the printer to restart. The menu selection is then updated.
Mac Binary PS Auto On Off	Sets the printer to process Macintosh binary PostScript print jobs **Notes:** • Auto is the factory default setting. • On processes raw binary PostScript print jobs. • Off filters print jobs using the standard protocol.
ENA Address yyy.yyy.yyy.yyy	Sets the network address information for an external print server **Note:** This menu item is available only if the printer is attached to an external print server through the USB port.
ENA Netmask yyy.yyy.yyy.yyy	Sets the netmask information for an external print server **Note:** This menu item is available only if the printer is attached to an external print server through the USB port.

Menu item	Description
ENA Gateway yyy.yyy.yyy.yyy	Sets the gateway information for an external print server **Note:** This menu item is available only if the printer is attached to an external print server through the USB port.

Parallel [x] menu

Menu item	Description
PCL SmartSwitch On Off	Sets the printer to automatically switch to PCL emulation when a print job received through a serial port requires it, regardless of the default printer language **Notes:** • On is the factory default setting. • When set to Off, the printer does not examine incoming data. The printer uses PostScript emulation if PS SmartSwitch is set to On. It uses the default printer language specified in the Setup menu if PS SmartSwitch is set to Off.
PS SmartSwitch On Off	Sets the printer to automatically switch to PS emulation when a print job received through a serial port requires it, regardless of the default printer language **Notes:** • On is the factory default setting. • When set to Off, the printer does not examine incoming data. The printer uses PCL emulation if PCL SmartSwitch is set to On. It uses the default printer language specified in the Setup menu if PCL SmartSwitch is set to Off.
NPA Mode Auto On Off	Sets the printer to perform the special processing required for bidirectional communication following the conventions defined by the NPA protocol **Notes:** • Auto is the factory default setting. • Changing this setting from the printer control panel and then exiting the menus causes the printer to restart. The menu selection is then updated.
Parallel Buffer Auto 3KB to [maximum size allowed] Disabled	Sets the size of the parallel input buffer **Notes:** • Auto is the factory default setting. • Disabled turns off job buffering. Any print jobs already buffered on the printer hard disk are printed before normal processing resumes. • The parallel buffer size setting can be changed in 1-KB increments. • The maximum size allowed depends on the amount of memory in the printer, the size of the other link buffers, and whether Resource Save is set to On or Off. • To increase the maximum size range for the Parallel Buffer, disable or reduce the size of the USB, serial, and network buffers. • Changing this setting from the printer control panel and then exiting the menus causes the printer to restart. The menu selection is then updated.

Menu item	Description
Job Buffering Off On Auto	Temporarily stores print jobs on the printer hard disk before printing **Notes:** • Off is the factory default setting. • On buffers print jobs on the printer hard disk. • Auto buffers print jobs only if the printer is busy processing data from another input port. • Changing this setting from the printer control panel and then exiting the menus causes the printer to restart. The menu selection is then updated.
Advanced Status On Off	Enables bidirectional communication through the parallel port **Notes:** • On is the factory default setting. • Off disables parallel port negotiation.
Protocol Fastbytes Standard	Specifies the parallel port protocol **Notes:** • Fastbytes is the factory default setting. It provides compatibility with most existing parallel ports and is the recommended setting. • Standard tries to resolve parallel port communication problems.
Honor Init Off On	Determines if the printer honors printer hardware initialization requests from the computer **Notes:** • Off is the factory default setting. • The computer requests initialization by activating the Init signal from the parallel port. Many personal computers activate the Init signal each time the computer is turned on.
Parallel Mode 2 On Off	Determines if the parallel port data is sampled on the leading or trailing edge of a strobe **Note:** On is the factory default setting.
Mac Binary PS Auto On Off	Sets the printer to process Macintosh binary PostScript print jobs **Notes:** • Auto is the factory default setting. • Off filters print jobs using the standard protocol. • On processes raw binary PostScript print jobs.
ENA Address yyy.yyy.yyy.yyy	Sets the network address information for an external print server **Note:** This menu item is available only if the printer is attached to an external print server through the USB port.
ENA Netmask yyy.yyy.yyy.yyy	Sets the netmask information for an external print server **Note:** This menu item is available only if the printer is attached to an external print server through the USB port.

Menu item	Description
ENA gateway yyy.yyy.yyy.yyy	Sets the gateway information for an external print server **Note:** This menu item is available only if the printer is attached to an external print server through the USB port.

Serial [x] menu

Menu item	Description
PCL SmartSwitch On Off	Sets the printer to automatically switch to PCL emulation when a print job received through a serial port requires it, regardless of the default printer language **Notes:** • On is the factory default setting. • When set to Off, the printer does not examine incoming data. The printer uses PostScript emulation if PS SmartSwitch is set to On. It uses the default printer language specified in the Setup menu if PS SmartSwitch is set to Off.
PS SmartSwitch On Off	Sets the printer to automatically switch to PS emulation when a print job received through a serial port requires it, regardless of the default printer language **Notes:** • On is the factory default setting. • When set to Off, the printer does not examine incoming data. The printer uses PCL emulation if PCL SmartSwitch is set to On. It uses the default printer language specified in the Setup menu if PCL SmartSwitch is set to Off.
NPA Mode Auto On Off	Sets the printer to perform the special processing required for bidirectional communication following the conventions defined by the NPA protocol **Notes:** • Auto is the factory default setting. Auto sets the printer to examine data, determine the format, and then processes it appropriately. • When set to On, the printer performs NPA processing. If the data is not in NPA format, it is rejected as bad data. • When set to Off, the printer does not perform NPA processing. • Changing this setting from the printer control panel and then exiting the menus causes the printer to restart. The menu selection is then updated.

Menu item	Description
Serial Buffer Auto 3KB to [maximum size allowed] Disabled	Sets the size of the serial input buffer **Notes:** • Auto is the factory default setting. • Disabled turns off job buffering. Any jobs already buffered on the disk are printed before normal processing is resumed. • The serial buffer size setting can be changed in 1-KB increments. • The maximum size allowed depends on the amount of memory in the printer, the size of the other link buffers, and whether Resource Save is set to On or Off. • To increase the maximum size range for the Serial Buffer, disable or reduce the size of the parallel, serial, and network buffers. • Changing this setting from the printer control panel and then exiting the menus causes the printer to restart. The menu selection is then updated.
Job Buffering Off On Auto	Temporarily stores print jobs on the printer hard disk before printing **Notes:** • Off is the factory default setting. The printer does not buffer print jobs on the printer hard disk. • On buffers print jobs on the printer hard disk. • Auto buffers print jobs only if the printer is busy processing data from another input port. • Changing this setting from the printer control panel and then exiting the menus causes the printer to restart. The menu selection is then updated.
Protocol DTR DTR/DSR XON/XOFF XON/XOFF/DTR XONXOFF/DTRDSR	Selects the hardware and software handshaking settings for the serial port **Notes:** • DTR is the factory default setting. • DTR/DSR is a hardware handshaking setting. • XON/XOFF is a software handshaking setting. • XON/XOFF/DTR and XON/XOFF/DTR/DSR are combined hardware and software handshaking settings.
Robust XON Off On	Determines whether the printer communicates availability to the computer **Notes:** • Off is the factory default setting. • This menu item applies only to the serial port if Serial Protocol is set to XON/XOFF.

Menu item	Description
Baud 9600 19200 38400 57600 115200 138200 172800 230400 345600 1200 2400 4800	Specifies the rate at which data can be received through the serial port **Notes:** • 9600 is the factory default setting. • 138200, 172800, 230400, and 345600 baud rates are only displayed in the Standard Serial menu. These settings do not appear in the Serial Option 1, Serial Option 2, or Serial Option 3 menus.
Data Bits 8 7	Specifies the number of data bits sent in each transmission frame **Note:** 8 is the factory default setting.
Parity None Ignore Even Odd	Sets the parity for serial input and output data frames **Note:** None is the factory default setting.
Honor DSR Off On	Determines whether the printer uses the DSR Signal **Notes:** • Off is the factory default setting. • DSR is a handshaking signal used by most serial cables. The serial port uses DSR to distinguish data sent by the computer from data created by electrical noise in the serial cable. The electrical noise can cause stray characters to print. Set this to On to prevent stray characters from printing.

SMTP Setup menu

Menu item	Description
Primary SMTP Gateway	Specifies SMTP server gateway and port information **Note:** 25 is the default SMTP gateway port.
Primary SMTP Gateway Port	
Secondary SMTP Gateway	
Secondary SMTP Gateway Port	
SMTP Timeout 5–30	Specifies the amount of time in seconds before the server stops trying to send an e-mail **Note:** 30 seconds is the factory default setting.
Reply Address	Specifies a reply address of up to 128 characters in the e-mail sent by the printer

Menu item	Description
Use SSL Disabled Negotiate Required	Sets the printer to use SSL for increased security when connecting to the SMTP server **Notes:** • Disabled is the factory default setting. • When the Negotiate setting is used, the SMTP server determines if SSL will be used.
SMTP Server Authentication No authentication required Login/Plain CRAM-MD5 Digest-MD5 NTLM Kerberos 5	Specifies the type of user authentication required for scan to e-mail privileges **Note:** "No authentication required" is the factory default setting.
Device-Initiated E-mail None Use Device SMTP Credentials	Specifies what credentials will be used when communicating to the SMTP server. Some SMTP servers require credentials to send an e-mail. **Notes:** • None is the factory default setting for Device and User-Initiated E-mail. • Device Userid and Device Password are used to log in to the SMTP server when Use Device SMTP Credentials is selected.
User-Initiated E-mail None Use Device SMTP Credentials Use Session User ID & Password Use Session E-mail address & Password Prompt User	
Device Userid	
Device Password	
Kerberos 5 Realm	
NTLM Domain	

Security menu

Miscellaneous Security Settings menu

Use	To
Login Restrictions Login failures Failure time frame Lockout time Panel Login Timeout Remote Login Timeout	Limit the number and time frames of failed login attempts from the printer control panel before *all* users are locked out. **Notes:** • “Login failures” specifies the number of failed login attempts before users are locked out. Settings range from 1–10 attempts. 3 attempts is the factory default setting. • “Failure time frame” specifies the time frame during which failed login attempts can be made before users are locked out. Settings range from 1–60 minutes. 5 minutes is the factory default setting. • “Lockout time” specifies how long users are locked out after exceeding the login failures limit. Settings range from 1–60 minutes. 5 minutes is the factory default setting. 1 indicates the printer does not impose a lockout time. • “Panel Login Timeout” specifies how long the printer remains idle on the home screen before automatically logging off the user. Settings range from 1–900 seconds. 30 seconds is the factory default setting. • “Remote Login Timeout” specifies how long a remote interface remains idle before automatically logging off the user. Settings range from 1–120 minutes. 10 minutes is the factory default setting.
Security Reset Jumper Access controls=”No Security” No Effect Reset factory security defaults	Adjust the security settings. **Notes:** • “Access controls=’No Security’” retains all the security information that the user has defined. “No Security" is the factory default setting. • “No Effect” means the reset has no effect on the printer security configuration. • “Reset factory security defaults” deletes all security information that the user has defined, and restores the factory default settings in the Miscellaneous Security menu.
LDAP Certificate Verification Demand Try Allow Never	Allow the user to request a server certificate. **Notes:** • “Demand” means a server certificate is requested. If a bad certificate is provided or if no certificate is provided, then the session is terminated immediately. “Demand” is the factory default setting. • “Try” means a server certificate is requested. If no certificate is provided, then the session proceeds normally. If a bad certificate is provided, then the session is terminated immediately. • “Allow” means a server certificate is requested. If no certificate is provided, then the session proceeds normally. If a bad certificate is provided, then it will be ignored and the session proceeds normally. • “Never” means no server certificate is requested.

Use	To
Minimum PIN Length 1–16	Limit the digit length of the personal identification number (PIN). **Note:** 4 is the is the factory default setting.

Confidential Print menu

Menu item	Description
Max Invalid PIN Off 2–10	Limits the number of times an invalid PIN can be entered **Notes:** • This menu appears only if a formatted, non-defective printer hard disk is installed. • Once the limit is reached, the print job for that user name and that PIN are deleted.
Confidential Job Expiration Off 1 hour 4 hours 24 hours 1 week	Limits the amount of time a confidential print job stays in the printer before it is deleted **Notes:** • If the Job Expiration setting is changed while confidential print jobs reside on the printer RAM or printer hard disk, then the expiration time for those print jobs does not change to the new default value. • If the printer is turned off, then all confidential jobs held in printer RAM are deleted.
Repeat Job Expiration Off 1 hour 4 hours 24 hours 1 week	Sets a time limit on how long the printer stores print jobs
Verify Job Expiration Off 1 hour 4 hours 24 hours 1 week	Sets a time limit on how long the printer stores print jobs needing verification
Reserve Job Expiration Off 1 hour 4 hours 24 hours 1 week	Sets a time limit on how long the printer stores print jobs for printing at a later time
Note: Off is the factory default setting.	

Erase Temporary Data Files menu

Erase Temporary Data Files deletes *only* print job data on the printer hard disk that *are not* currently in use by the file system. All permanent data on the hard disk are preserved, such as downloaded fonts, macros, and held jobs.

Note: This menu appears only when a formatted, working hard disk is installed.

Use	To
Wiping Mode Off Auto Manual	Specify the mode for erasing temporary data files. **Note:** Auto is the factory default setting.
Automatic Method Single pass Multi-pass	Specify a method for automatic disk wiping. **Notes:** • Single pass is the factory default setting. • Highly confidential information should be erased using *only* the Multiple pass method.
Manual Method Single pass Multi-pass	Specify a method for manual disk wiping. **Note:** Single pass is the factory default setting.
Scheduled Method Single pass Multi-pass	Specify a method for a scheduled disk wiping. **Note:** Single pass is the factory default setting.

Security Audit Log menu

Menu item	Description
Export Log	Enables an authorized user to export the audit log **Notes:** • To export the audit log from the printer control panel, a flash drive must be attached to the printer. • From the Embedded Web Server, the audit log can be downloaded to a computer.
Delete Log Yes No	Specifies whether audit logs are deleted **Note:** "Yes" is the factory default setting.
Configure Log Enable Audit No Yes Enable Remote Syslog No Yes Remote Syslog Facility 0–23 Severity of events to log 0–7	Specifies whether and how audit logs are created **Notes:** • Enable Audit determines if events are recorded in the secure audit log and remote syslog. No is the factory default setting. • Enable Remote Syslog determines if logs are sent to a remote server. No is the factory default setting. • Remote Syslog Facility determines the value used to send logs to the remote syslog server. 4 is the factory default setting. • With the security audit log activated, the severity value of each event is recorded. 4 is the factory default setting.

Set Date and Time menu

Menu item	Description
Current Date and Time	Shows the current date and time settings for the printer
Manually Set Date and Time [input date/time]	**Notes:** • Date and Time is set in YYYY-MM-DD HH:MM format. • Manually setting the date and time sets Enable NTP to Off.
Time Zone [list of time zones]	**Note:** GMT is the factory default setting.
Automatically observe DST On Off	**Note:** On is the factory default setting. This uses the applicable Daylight Saving Time associated with the Time Zone setting.
Enable NTP On Off	Enables Network Time Protocol, which synchronizes the clocks of devices on a network **Notes:** • On is the factory default setting. • The setting is turned off if you manually set the date and time.

Settings menu

General Settings menu

Use	To
Display Language English Francais Deutsch Italiano Espanol Dansk Norsk Nederlands Svenska Portugues Suomi Russian Polski Greek Magyar Turkce Cesky Simplified Chinese Traditional Chinese Korean Japanese	Set the language of the text appearing on the display. **Note:** Not all languages are available for all models. You may need to install a special hardware for some languages.
Eco-Mode Off Energy Energy/Paper Paper	Minimize the use of energy, paper, or specialty media. **Notes:** • Off is the factory default setting. This resets the printer to its factory default settings. • When setting Eco Mode to Energy or Paper, performance may be affected, but print quality is not.
Quiet Mode Off On	Minimize the printer noise. **Note:** Off is the factory default setting.
Run Initial setup Yes No	Run the setup wizard.

Use	To
Keyboard Keyboard Type English Francais Francais Canadien Deutsch Italiano Espanol Greek Dansk Norsk Nederlands Svenska Suomi Portugues Russian Polski Swiss German Swiss French Korean Magyar Turkish Czech Simplified Chinese Traditional Chinese Japanese Custom Key [x]	Specify a language and custom key information for the display keyboard.
Paper Sizes U.S. Metric	Specify the unit of measurement for paper sizes. **Notes:** • U.S. is the factory default setting. • The initial setting is determined by your country or region selection in the initial setup wizard.

Use	To
Displayed Information Left side Right side Custom Text [x]	Specify what is displayed on the upper corners of the home screen. For Left side and Right side, select from the following options: None IP Address Hostname Contact Name Location Date/Time mDNS/DDNS Service Name Zero Configuration Name Custom Text [x] Model Name **Notes:** • IP Address is the factory default setting for Left side. • Date/Time is the factory default setting for Right side.
Displayed Information (continued) [x] Toner [x] Photoconductor Waste Toner Bottle Fuser Transfer Module	Customize the displayed information for the parts and supplies. Select from the following options: When to display Do not display Display Message to display Default Alternate Default [text entry] Alternate [text entry] **Notes:** • Do not display is the factory default setting for When to display. • Default is the factory default setting for Message to display.

Use	To
Displayed Information (continued) Paper Jam Load Paper Service Errors	Customize the displayed information for certain menus. Select from the following options: When to Display Do not display Alternate Message to display Default Alternate Default [text entry] Alternate [text entry] **Notes:** • Do not display is the factory default setting for Display. • Default is the factory default setting for Message to display.
Home screen customization Change Language Search Held Jobs Held Jobs USB Drive Profiles Bookmarks Jobs by User	Change the icons that appear on the home screen. For each icon, select from the following options: Display Do not display **Notes:** • Display is the factory default setting for Held Jobs, USB Drive, Profiles, Bookmarks, and Jobs by User. • Do not display is the factory default setting for Change Language and Search Held Jobs.
Date Format MM-DD-YYYY DD-MM-YYYY YYYY-MM-DD	Format the date. **Note:** MM-DD-YYYY is the U.S. factory default setting. DD-MM-YYYY is the international factory default setting.
Time Format 12 hour A.M./P.M. 24 hour clock	Format the time. **Note:** 12 hour A.M./P.M. is the factory default setting.
Screen Brightness 20–100	Specify the brightness of the display. **Note:** 100 is the factory default setting.
Output Lighting Normal/Standby Mode Dim Bright Off	Set the output lighting for the standard bin. **Note:** Bright is the factory default setting.
Custom Background Image	Import a background image.

Use	To
Audio Feedback Button Feedback On Off Volume 1–10	Specify the audio volume for the buttons. **Notes:** • On is the factory default setting for Button Feedback. • 3 is the factory default setting for Volume.
Tactile Touchscreen Feedback On Off	Enable touch-screen sensation feedback. **Note:** On is the factory default setting.
Web Page Refresh Rate 30–300	Specify the number of seconds between Embedded Web Server refreshes. **Note:** 120 is the factory default setting.
Contact Name	Specify a contact name. **Note:** The contact name is stored on the Embedded Web Server.
Location	Specify the location. **Note:** The location is stored on the Embedded Web Server.
Alarms Alarm Control Cartridge Alarm Stapler Alarm Hole Punch Alarm	Set an alarm when the printer requires user intervention. For each alarm type, select from the following options: Off Single Continuous **Notes:** • Single is the factory default setting for Alarm Control. This sounds three quick beeps. • Off is the factory default setting for Cartridge Alarm, Stapler Alarm, and Hole Punch Alarm. • Continuous repeats three beeps every 10 seconds.
Timeouts Standby Mode 1–240	Set the amount of time before the printer enters a lower power state. **Note:** 15 minutes is the factory default setting.
Timeouts Sleep Mode Disabled 1–240	Set the amount of time in minutes the printer waits after a job is printed before it goes into a reduced power state. **Notes:** • 5 is the factory default setting. • Disabled appears only when Energy Conserve is set to Off. • Lower settings conserve more energy, but may require longer warm-up times. • Select a high setting if the printer is in constant use. Under most circumstances, this keeps the printer ready to print with minimum warm-up time.

Use	To
Timeouts Hibernate Timeout Disabled 20 minutes 1–3 hours 6 hours 1–3 days 1–2 weeks 1 month	Set the amount of time the printer waits before it enters Hibernate mode. **Note:** 3 days is the factory default setting.
Hibernate Timeout on Connection Hibernate Do Not Hibernate	Set the printer to Hibernate mode even if there is an active Ethernet connection. **Note:** Do Not Hibernate is the factory default setting.
Timeouts Screen Timeout 15–300	Set the amount of time in seconds before returning the control panel to a Ready state. **Note:** 30 is the factory default setting.
Timeouts Print Timeout Disabled 1–255	Set the amount of time in seconds the printer waits to receive an end-of-job message before canceling the rest of the job. **Notes:** • 90 is the factory default setting. • When the timer expires, any partially printed page still in the printer is printed, and then the printer checks to see if any new print jobs are waiting. • Print Timeout is available only when using PCL emulation. This has no effect on PostScript emulation print jobs.
Timeouts Wait Timeout Disabled 15–65535	Set the amount of time in seconds the printer waits for more data before canceling a print job. **Notes:** • 40 is the factory default setting. • Wait Timeout is available only when the printer is using PostScript emulation. This setting has no effect on PCL emulation print jobs.
Timeouts Job Hold Timeout 5–255	Set the amount of time in seconds the printer waits for user intervention before it holds jobs that require unavailable resources and continues to print other jobs in the print queue. **Notes:** • 30 is the factory default setting. • This menu item appears only when a hard disk is installed.
Print Recovery Auto Continue Disabled 5–255	Let the printer automatically continue printing from certain offline situations when these are not resolved within the specified time period. **Note:** Disabled is the factory default setting.

Use	To
Print Recovery Jam Recovery On Off Auto	Specify whether the printer reprints jammed pages. **Notes:** • Auto is the factory default setting. The printer reprints jammed pages unless the memory required to hold the pages is needed for other printer tasks. • On sets the printer to always reprint jammed pages. • Off sets the printer to never reprint jammed pages.
Print Recovery Page Protect Off On	Successfully print a page that may not have printed otherwise. **Notes:** • Off is the factory default setting. This prints a partial page when there is not enough memory to print the whole page. • On sets the printer to print the entire page.
Press Sleep Button Do Nothing Sleep Hibernate	Determine how the printer, while in idle state, reacts to a short press of the Sleep button. **Note:** Sleep is the factory default setting.
Press and Hold Sleep Button Hibernate	Determine how the printer, while in idle state, reacts to a long press of the Sleep button.
Factory Defaults Do Not Restore Restore Now	Use the printer factory default settings except the Network/Ports menu settings. **Notes:** • Do Not Restore is the factory default setting. • All downloads stored in the RAM are deleted. Downloads stored in the flash memory or on a hard disk are not affected.

Print Settings

Finishing menu

Menu item	Description
Sides (Duplex) 1 sided 2 sided	Specifies whether duplex (2-sided) printing is set as the default setting for all print jobs **Notes:** • 1 sided is the factory default setting. • You can set 2-sided printing from the software program. For Windows users, click **File** > **Print**, and then click **Properties**, **Preferences**, **Options**, or **Setup**. For Macintosh users, choose **File** > **Print**, and then adjust the settings from the print dialog and pop-up menus.

Menu item	Description
Duplex Binding Long Edge Short Edge	Defines the way duplexed pages are bound and how the printing on the back of the page is oriented in relation to the printing on the front of the page **Notes:** • Long Edge is the factory default setting. Long edge assumes binding along the long edge of the page (left edge for portrait and top edge for landscape). • Short edge assumes binding along the short edge of the page (top edge for portrait and left edge for landscape).
Copies 1–999	Specifies the default number of copies for each print job **Note:** 1 is the factory default setting.
Blank Pages Do Not Print Print	Specifies whether blank pages are inserted in a print job **Note:** Do Not Print is the factory default setting.
Collate Off (1,1,1,2,2,2) On (1,2,1,2,1,2)	Stacks the pages of a print job in sequence when printing multiple copies **Notes:** • Off is the factory default setting. • On stacks the print job in sequence.
Separator Sheets Off Between Copies Between Jobs Between Pages	Specifies whether blank separator sheets are inserted **Notes:** • Off is the factory default setting. • Between Copies inserts a blank sheet between each copy of a print job if Collate is set to On. If Collate is set to Off, then a blank page is inserted between each set of printed pages, such as after all page 1's and after all page 2's. • Between Jobs inserts a blank sheet between print jobs. • Between Pages inserts a blank sheet between each page of a print job. This setting is useful when printing transparencies or when inserting blank pages in a document.
Separator Source Tray [x] Manual Feeder	Specifies the paper source for separator sheets **Notes:** • Tray 1 (standard tray) is the factory default setting. • From the Paper menu, Configure MP must be set to Cassette for Manual Feeder to appear as a menu setting.
Paper Saver Off 2-Up 3-Up 4-Up 6-Up 9-Up 12-Up 16-Up	Specifies that multiple-page images be printed on one side of a paper **Notes:** • Off is the factory default setting. • The number selected is the number of page images that will print per side.

Menu item	Description
Paper Saver Ordering Horizontal Reverse Horizontal Reverse Vertical Vertical	Specifies the positioning of multiple-page images when using Paper Saver **Notes:** • Horizontal is the factory default setting. • Positioning depends on the number of page images and whether they are in portrait or landscape orientation.
Paper Saver Orientation Auto Landscape Portrait	Specifies the orientation of a multiple-page document **Note:** Auto is the factory default setting. The printer chooses between portrait and landscape.
Paper Saver Border None Solid	Prints a border on each page image when using Paper Saver **Note:** None is the factory default setting.
Staple Job Off Auto Back Dual Dual Double Front	Specifies whether the prints are stapled **Notes:** • Off is the factory default setting. • This menu only appears when the printer is equipped with a stapler.
Hole Punch Off On	Specifies whether the prints have punched holes **Note:** This menu only appears when the printer is equipped with a puncher.
Hole Punch Mode 2 holes 3 holes 4 holes	Determines the type of punch finishing performed on a printed output **Notes:** • “2 holes” is the factory default setting regardless of hardware. • “3 holes” and “4 holes” only appear when their respective hole punch hardware is installed.
Offset Pages None Between Copies Between Jobs	Offsets pages at certain instances **Notes:** • None is the factory default setting. • Between Copies offsets each copy of a print job if Collate is set to On. If Collate is set to Off, each set of printed pages are offset, such as all page 1's and all page 2's. • Between Jobs sets the same offset position for the entire print job regardless of the number of copies printed. • This menu only appears when a stapler finisher is installed.

Quality menu

Use	To
Print Mode Color Black Only	Specify whether to print images in color. **Note:** Color is the factory default setting.
Color Correction Auto Off Manual	Adjust the color output on the printed page. **Note:** Auto is the factory default setting.
Print Resolution 1200 dpi 2400 Image Q	Specify the output resolution in dots per inch (dpi) or in image quality. **Note:** 2400 Image Q is the factory default setting.
Toner Darkness 1–5	Lighten or darken the output. **Note:** 3 is the factory default setting.
Enhance Fine Lines On Off	Enable a print mode preferable for files such as architectural drawings, maps, electrical circuit diagrams, and flow charts. **Note:** Off is the factory default setting.
Color Saver On Off	Reduce the amount of toner used for graphics and images. **Notes:** • Off is the factory default setting. • On overrides the Toner Darkness setting.
RGB Brightness -6 to 6	Adjust the brightness of the output. **Note:** 0 is the factory default setting.
RGB Contrast 0–5	Adjust the contrast of the output. **Note:** 0 is the factory default setting.
RGB Saturation 0–5	Adjust saturation in color outputs. **Note:** 0 is the factory default setting.
Color Balance Cyan -5 to 5 Magenta -5 to 5 Yellow -5 to 5 Black -5 to 5 Reset Defaults	Enable an equal balance of colors in the output. **Note:** 0 is the factory default setting.

Use	To
Color Samples sRGB Display sRGB Vivid Display—True Black Vivid Off—RGB US CMYK Euro CMYK Vivid CMYK Off—CMYK	Print sample pages for each of the RGB and CMYK color conversion tables used in the printer.
Manual Color RGB Image RGB Text RGB Graphics	Customize the RGB color conversions. Select from the following options: Vivid sRGB Display Display—True Black sRGB Vivid Off **Notes:** • sRGB Display is the factory default setting for RGB Image. • sRGB Vivid is the factory default setting for RGB Text and RGB Graphics.
Manual Color (continued) CMYK Image CMYK Text CMYK Graphics	Customize the CMYK color conversions. Select from the following options: US CMYK Euro CMYK Vivid CMYK Off **Note:** US CMYK is the U.S. factory default setting. Euro CMYK is the international factory default setting.
Spot Color Replacement	Assign specific CMYK values to named spot colors. **Note:** This menu is available only on the Embedded Web Server.
RGB Replacement	Match the colors of the output with that of the original document. **Note:** This menu is available only on the Embedded Web Server.

Job Accounting menu

Note: This menu item appears only if a formatted, non-defective printer hard disk is installed. The printer hard disk cannot be read/write- or write-protected.

Menu item	Description
Job Accounting Log Off On	Determines if the printer creates a log of the print jobs it receives **Note:** Off is the factory default setting.

Menu item	Description
Job Accounting Utilities	Lets you print and delete log files or export them to a flash drive
Accounting Log Frequency Monthly Weekly	Determines how often a log file is created **Note:** Monthly is the factory default setting.
Log Action at End of Frequency None E-mail Current Log E-mail & Delete Current Log Post Current Log Post & Delete Current Log	Determines how the printer responds when the frequency threshold expires **Note:** None is the factory default setting.
Disk Near Full Level 1–99 Off	Specifies the maximum size of the log file before the printer executes the Disk Near Full Action **Note:** 5MB is the factory default setting.
Disk Near Full Action None E-mail Current Log E-mail & Delete Current Log E-mail & Delete Oldest Log Post Current Log Post & Delete Current Log Post & Delete Oldest Log Delete Current Log Delete Oldest Log Delete All Logs Delete All But Current	Determines how the printer responds when the printer hard disk is nearly full **Notes:** • None is the factory default setting. • The value defined in Disk Near Full Level determines when this action is triggered.
Disk Full Action None E-mail & Delete Current Log E-mail & Delete Oldest Log Post & Delete Current Log Post & Delete Oldest Log Delete Current Log Delete Oldest Log Delete All Logs Delete All But Current	Determines how the printer responds when disk usage reaches the maximum limit (100MB) **Note:** None is the factory default setting.
URL to Post Logs	Determines where the printer posts job accounting logs
E-mail Address to Send Logs	Specifies the e-mail address to which the device sends job accounting logs
Log File Prefix	**Note:** The current host name defined in the TCP/IP menu is used as the default log file prefix.

Setup menu

Menu item	Description
Printer Language PS Emulation PCL Emulation	Sets the default printer language **Notes:** • PS Emulation is the factory default printer language. PS emulation uses a PS interpreter for processing print jobs. • PCL Emulation uses a PCL interpreter for processing print jobs. • Setting a printer language as the default does not prevent a software program from sending print jobs that use another printer language.
Job Waiting Off On	Specifies if print jobs are removed from the print queue when they require unavailable printer options or custom settings. These print jobs are stored in a separate print queue, so other jobs print normally. When the missing information and/or options are obtained, the stored jobs print. **Notes:** • Off is the factory default setting. • This menu item appears only if a non-read-only printer hard disk is installed. This requirement ensures that stored jobs are not deleted if the printer loses power.
Print Area Normal Whole Page	Sets the logical and physical printable area **Notes:** • Normal is the factory default setting. When attempting to print data in the non-printable area defined by the Normal setting, the printer clips the image at the boundary. • Whole Page allows images to be moved into the non-printable area defined by the Normal setting, but the printer clips the image at the Normal setting boundary. This setting affects only pages printed using a PCL 5e interpreter. This setting has no effect on pages printed using the PCL XL or PostScript interpreter.
Printer Usage Max Yield Max Speed	Sets the printer for a faster print speed or a higher toner yield. **Note:** Max Yield is the factory default setting.
Black Only Mode Off On	Sets the printer to print text and graphics using only the black toner cartridge **Note:** Off is the factory default setting.

Menu item	Description
Download Target RAM Flash Disk	Sets the storage location for downloads **Notes:** • RAM is the factory default setting. Downloads stored in RAM are temporary. • Storing downloads in flash memory or on a printer hard disk places them in permanent storage. Downloads remain in flash memory or on the printer hard disk even when the printer is turned off. • This menu item appears only if a flash and/or disk option is installed.
Resource Save Off On	Specifies how the printer handles temporary downloads, such as fonts and macros stored in the RAM, when the printer receives a print job that requires more memory than is available **Notes:** • Off is the factory default setting. Off sets the printer to retain downloads only until memory is needed. Downloads are deleted in order to process print jobs. • On sets the printer to retain downloads during language changes and printer resets. If the printer runs out of memory, **`38 Memory Full`** appears, but downloads are not deleted.
Print All Order Alphabetical Oldest First Newest First	Specifies the order in which held and confidential jobs are printed when Print All is selected **Notes:** • Alphabetical is the factory default setting. • Print jobs always appear in alphabetical order on the printer control panel.

PostScript menu

Menu item	Description
Print PS Error Off On	Prints a page containing the PostScript error **Note:** Off is the factory default setting.
Lock PS Startup Mode Off On	Enables users to disable the SysStart file **Note:** Off is the factory default setting.

Menu item	Description
Font Priority Resident Flash/Disk	Establishes the font search order **Notes:** • Resident is the factory default setting. • This menu item is available only if a formatted flash memory option card or printer hard disk is installed and operating properly. • Make sure the flash memory option or printer hard disk is not read/write-, write-, or password-protected. • Job Buffer Size must not be set to 100%.
Image Smoothing Off On	Enhances the contrast and sharpness of low-resolution images and smooths their color transitions **Notes:** • Off is the factory default setting. • Image Smoothing has no effect on images that are 300 dpi or higher in resolution.

PCL Emul menu

Menu item	Description
Font Source Resident Disk Download Flash All	Specifies the set of fonts used by the Font Name menu item **Notes:** • Resident is the factory default setting. It shows the factory default set of fonts downloaded in RAM. • Flash and Disk settings show all fonts resident in that option. Make sure the flash option is properly formatted and is not read/write-, or password-protected. • Download shows all the fonts downloaded in RAM. • All shows all fonts available to any option.
Font Name RO Courier	Identifies a specific font and where it is stored **Note:** RO Courier is the factory default setting. The RO Courier format shows the font name, font ID, and storage location in the printer. The font source abbreviation is R for Resident, F for Flash, K for Disk, and D for Download.
Symbol Set 10U PC-8 12U PC-850	Specifies the symbol set for each font name **Notes:** • 10U PC-8 is the US factory default setting. 12U PC-850 is the international factory default setting. • A symbol set is a set of alphabetical and numeric characters, punctuation, and special symbols. Symbol sets support the different languages or specific programs such as math symbols for scientific text. Only the supported symbol sets are shown.

Menu item	Description
PCL Emulation Settings Point Size 1.00–1008.00	Changes the point size for scalable typographic fonts **Notes:** • 12 is the factory default setting. • Point Size refers to the height of the characters in the font. One point equals approximately 1/72 of an inch. • Point sizes can be increased or decreased in 0.25-point increments.
PCL Emulation Settings Pitch 0.08–100	Specifies the font pitch for scalable monospaced fonts **Notes:** • 10 is the factory default setting. • Pitch refers to the number of fixed-space characters per inch (cpi). • Pitch can be increased or decreased in 0.01-cpi increments. • For non-scalable monospaced fonts, the pitch appears on the display but cannot be changed.
PCL Emulation Settings Orientation Portrait Landscape	Specifies the orientation of text and graphics on a page **Notes:** • Portrait is the factory default setting. • Portrait prints text and graphics parallel to the short edge of the page. • Landscape prints text and graphics parallel to the long edge of the page.
PCL Emulation Settings Lines per Page 1–255	Specifies the number of lines that print on each page **Notes:** • 60 is the US factory default setting. 64 is the international default setting. • The printer sets the amount of space between each line based on the Lines per Page, Paper Size, and Orientation settings. Select the desired Paper Size and Orientation before setting Lines per Page.
PCL Emulation Settings A4 Width 198 mm 203 mm	Sets the printer to print on A4-size paper **Notes:** • 198 mm is the factory default setting. • The 203-mm setting sets the width of the page to allow the printing of eighty 10-pitch characters.
PCL Emulation Settings Auto CR after LF Off On	Specifies whether the printer automatically performs a carriage return (CR) after a line feed (LF) control command **Note:** Off is the factory default setting.
PCL Emulation Settings Auto LF after CR Off On	Specifies whether the printer automatically performs a line feed (LF) after a carriage return (CR) control command **Note:** Off is the factory default setting.

Menu item	Description
Tray Renumber Assign MP Feeder Off None 0–199 Assign Tray [x] Off None 0–199 Assign Manual Paper Off None 0–199 Assign Manual Env Off None 0–199	Configures the printer to work with printer software or programs that use different source assignments for trays, drawers, and feeders **Notes:** • Off is the factory default setting. • None ignores the Select Paper Feed command. This selection is displayed only when it is selected by the PCL 5e interpreter. • 0–199 allows a custom setting to be assigned.
Tray Renumber View Factory Defaults MPF Default = 8 T1 Default = 1 T2 Default = 4 T3 Default = 5 T4 Default = 20 T5 Default = 21 Env Default = 6 MPaper Default = 2 MEnv Default = 3	Displays the factory default setting assigned to each tray, drawer, or feeder
Tray Renumber Restore Defaults Yes No	Returns all tray, drawer, and feeder assignments to the factory default settings

XPS menu

Menu item	Description
Print Error Pages Off On	Prints a page containing information on errors, including XML markup errors **Note:** Off is the factory default setting.

PDF menu

Menu item	Description
Scale to Fit No Yes	Scales page content to fit the selected paper size **Note:** No is the factory default setting.
Annotations Do Not Print Print	Prints annotations in a PDF **Note:** Do Not Print is the factory default setting.

HTML menu

Menu Item		Description
Font Name Albertus MT Antique Olive Apple Chancery Arial MT Avant Garde Bodoni Bookman Chicago Clarendon Cooper Black Copperplate Coronet Courier Eurostile Garamond Geneva Gill Sans Goudy Helvetica Hoefler Text Intl CG Times Intl Courier Intl Univers	Joanna MT Letter Gothic Lubalin Graph Marigold MonaLisa Recut Monaco New CenturySbk New York Optima Oxford Palatino StempelGaramond Taffy Times TimesNewRoman Univers Zapf Chancery NewSansMTCS NewSansMTCT New SansMTJA NewSansMTKO	Sets the default font for HTML documents **Note:** The Times font is used in HTML documents that do not specify a font.

Menu item	Description
Font Size 1–255 pt	Sets the default font size for HTML documents **Notes:** • 12 pt is the factory default setting. • Font size can be increased in 1-point increments.

Menu item	Description
Scale 1–400%	Scales the default font for HTML documents **Notes:** • 100% is the factory default setting. • Scaling can be increased in 1% increments.
Orientation Portrait Landscape	Sets the page orientation for HTML documents **Note:** Portrait is the factory default setting.
Margin Size 8–255 mm	Sets the page margin for HTML documents **Notes:** • 19 mm is the factory default setting. • Margin size can be increased in 1-mm increments.
Backgrounds Print Do Not Print	Specifies whether to print backgrounds on HTML documents **Note:** Print is the factory default setting.

Image menu

Menu item	Description
Auto Fit On Off	Selects the optimal paper size, scaling, and orientation **Note:** On is the factory default setting. It overrides scaling and orientation settings for some images.
Invert Off On	Inverts bi-tonal monochrome images **Notes:** • Off is the factory default setting. • This setting does not apply to GIF or JPEG images.
Scaling Best Fit Anchor Center Fit Height/Width Fit Height Fit Width Anchor Top Left	Scales the image to fit the selected paper size **Notes:** • Best Fit is the factory default setting. • When Auto Fit is set to On, Scaling is automatically set to Best Fit.
Orientation Portrait Landscape Rev Portrait Rev Landscape	Sets the image orientation **Note:** Portrait is the factory default setting.

Flash Drive menu

Use	To
Copies 1–999	Specify a default number of copies for each print job. **Note:** 1 is the factory default setting.
Paper Source Tray [x] Manual Paper Manual Envelope	Set a default paper source for all print jobs. **Note:** Tray 1 is the factory default setting.
Color Color Black Only	Specify whether to print the document in color. **Note:** Color is the factory default setting.
Collate Off (1,1,12,2,2) On (1,2,1,2,1,2)	Stack the pages of a print job in sequence when printing multiple copies. **Note:** On (1,2,1,2,1,2) is the factory default setting.
Sides (Duplex) 1 sided 2 sided	Enable two-sided printing for incoming print jobs. **Note:** 1 sided is the factory default setting.
Duplex Binding Long Edge Short Edge	Define binding for two-sided pages in relation to paper orientation. **Notes:** • Long Edge is the factory default setting. This assumes binding along the long edge of the page (left edge for portrait and top edge for landscape). • Short Edge assumes binding along the short edge of the page (top edge for portrait and left edge for landscape).
Paper Saver Orientation Auto Landscape Portrait	Specify the orientation of a multiple-page document. **Note:** Auto is the factory default setting.
Paper Saver Off 2-Up 3-Up 4-Up 6-Up 9-Up 12-Up 16-Up	Print multiple-page images on one side of the paper. **Note:** Off is the factory default setting.
Paper Saver Border None Solid	Print a border on each page image. **Note:** None is the factory default setting.

Use	To
Paper Saver Ordering Horizontal Reverse Horizontal Reverse Vertical Vertical	Specify the positioning of multiple-page images. **Notes:** • Horizontal is the factory default setting. • Positioning depends on the number of page images and whether they are in portrait or landscape orientation.
Separator Sheets Off Between Copies Between Jobs Between Pages	Specify whether to insert blank separator sheets. **Note:** Off is the factory default setting.
Separator Sheet Source Tray [x]	Specify the paper source for separator sheets. **Note:** Tray 1 is the factory default setting.
Blank Pages Do Not Print Print	Specify whether to insert blank pages in a print job. **Note:** Do Not Print is the factory default setting.

Help menu

Menu item	Description
Print All Guides	Prints all the guides
Color Quality	Provides information about solving color quality issues
Print Quality	Provides information about solving print quality issues
Printing Guide	Provides information about loading paper and other specialty media
Media Guide	Provides a list of the paper sizes supported in trays and feeders
Print Defects Guide	Provides a template for determining the cause of repeating print quality defects, and lists settings that can be used to adjust print quality
Menu Map	Provides a list of the control panel menus and settings
Information Guide	Provides help in locating additional information
Connection Guide	Provides information about connecting the printer locally (USB) or to a network
Moving Guide	Provides instructions for safely moving the printer
Supplies Guide	Provides information about ordering supplies

Securing the hard disk and other installed memory

Statement of Volatility

Your printer contains various types of memory that are capable of storing device and network settings, information from embedded solutions, and user data. The types of memory—along with the types of data stored by each—are described below.

- **Volatile memory**—Your device utilizes standard *Random Access Memory* (RAM) to temporarily buffer user data during simple print and copy jobs.
- **Non-volatile memory**—Your device may utilize two forms of non-volatile memory: EEPROM and NAND (flash memory). Both types are used to store the operating system, device settings, network information, scanner and bookmark settings, and embedded solutions.
- **Hard disk memory**—Some devices have a hard disk drive installed. The printer hard disk is designed for device-specific functionality and cannot be used for long term storage for data that is not print-related. The hard disk does not provide the capability for users to extract information, create folders, create disk or network file shares, or FTP information directly from a client device. The hard disk can retain buffered user data from complex scan, print, copy, and fax jobs, as well as form data, and font data.

There are several circumstances under which you might wish to erase the contents of the memory devices installed in your printer. A partial list includes:

- The printer is being decommissioned
- The printer hard drive is being replaced
- The printer is being moved to a different department or location
- The printer is being serviced by someone from outside your organization
- The printer is being removed from your premises for service
- The printer is being sold to another organization

Disposing of a hard drive

Note: Not all printers have a hard disk installed.

In high-security environments, it may be necessary to take additional steps to ensure that confidential data stored on the printer hard disk cannot be accessed once the printer—or its hard disk—is removed from your premises. While most data can be erased electronically, you may want to consider one or more of the following actions before disposing of a printer or hard disk:

- **Degaussing**—Flushes the hard drive with a magnetic field that erases stored data
- **Crushing**—Physically compresses the hard disk to break component parts and render them unreadable
- **Milling**—Physically shreds the hard disk into small metal bits

Note: While most data can be erased electronically, the only way to guarantee that all data is completely erased is to physically destroy each memory device on which data could have been stored.

Erasing volatile memory

The volatile memory (RAM) installed on your printer requires a power source to retain information. To erase the buffered data, simply power down the device.

Erasing non-volatile memory

- **Individual settings, device and network settings, security settings, and embedded solutions**—Erase information and settings by selecting Wipe All Settings in the Configuration menu.
- **Fax data**—Erase fax settings and data by selecting Wipe All Settings in the Configuration menu.

1 Turn off the printer.

2 Hold down 2ABC and 6MNO while turning the printer on. Release the buttons only when the screen with the progress bar appears.

The printer performs a power-on sequence, and then the Configuration menu appears. When the printer is fully powered up, the touch screen displays a list of functions, instead of the standard home screen icons.

3 Touch **Wipe All Settings**.

The printer will reboot several times during this process.

Note: Wipe All Settings securely removes device settings, solutions, jobs, faxes, and passwords on the printer.

4 Touch **Back** > **Exit Config Menu**.

The printer will power-on reset, and then return to normal operating mode.

Erasing printer hard disk memory

Notes:

- Some printer models may not have a printer hard disk installed.
- Configuring Erase Temporary Data Files in the printer menus lets you remove residual confidential material left by print jobs by securely overwriting files that have been marked for deletion.

Using the printer control panel

1 Turn off the printer.

2 Hold down **2** and **6** while turning the printer on. Release the buttons only when the screen with the progress bar appears.

The printer performs a power-on sequence, and then the Configuration menu appears. When the printer is fully turned on, the touch screen displays a list of functions.

3 Touch **Wipe Disk**, and then touch one of the following:

- **Wipe disk (fast)**—This lets you overwrite the disk with all zeroes in a single pass.
- **Wipe disk (secure)**—This lets you overwrite the disk with random bit patterns several times, followed by a verification pass. A secure overwrite is compliant with the DoD 5220.22-M standard for securely erasing data from a hard disk. Highly confidential information should be wiped using this method.

4 Touch **Yes** to proceed with disk wiping.

Notes:

- A status bar will indicate the progress of the disk wiping task.
- Disk wiping can take from several minutes to more than an hour, during which the printer will be unavailable for other user tasks.

5 Touch **Back** > **Exit Config Menu**.

The printer will perform a power-on reset, and then return to normal operating mode.

Configuring printer hard disk encryption

Note: Your printer may not have a hard disk installed.

Enabling hard disk encryption helps prevent the loss of sensitive data in the event your printer or its hard disk is stolen.

Using the Embedded Web Server

1. From the Embedded Web Server, click **Settings** > **Security** > **Disk Encryption**.

   Note: Disk Encryption appears in the Security Menu only when a formatted, non-defective printer hard disk is installed.

2. From the Disk encryption menu, select **Enable**.

   Notes:

   - Enabling disk encryption will erase the content of the printer hard disk.
   - Disk encryption can take from several minutes to more than an hour, during which the printer will be unavailable for other user tasks.

3. Click **Submit**.

Using the printer control panel

1. Turn off the printer.
2. Hold down 2ABC and 6MNO while turning the printer on. Release the buttons only when the screen with the progress bar appears.

   The printer performs a power-on sequence, and then the Configuration menu appears. Once the printer is fully powered up, the touch screen displays a list of functions, instead of standard home screen icons such as Copy or Fax.

3. Touch **Disk Encryption** > **Enable**.

   Note: Enabling disk encryption will erase the contents of the printer hard disk.

4. Touch **Yes** to proceed with disk wiping.

   A status bar will indicate the progress of the disk wiping task. After the disk has been encrypted, the printer will return to the Enable/Disable screen.

   Notes:

   - Do not turn off the printer during the encryption process. Doing so may result in loss of data.
   - Disk encryption can take from several minutes to more than an hour, during which the printer will be unavailable for other user tasks.

5. Touch **Back**, and then **Exit Config Menu**.

The printer will power-on reset, and then return to normal operating mode.

Maintaining the printer

Periodically, certain tasks are required to maintain optimum performance of your printer.

Cleaning the exterior of the printer

1 Make sure that the printer is turned off and unplugged from the wall outlet.

CAUTION—SHOCK HAZARD: To avoid the risk of electric shock when cleaning the exterior of the printer, unplug the power cord from the wall outlet and disconnect all cables to the printer before proceeding.

2 Remove paper from the standard exit bin.

3 Dampen a clean, lint-free cloth with water.

Warning—Potential Damage: Do not use household cleaners or detergents, as they may damage the finish of the printer.

4 Wipe only the outside of the printer, making sure to include the standard exit bin.

Warning—Potential Damage: Using a damp cloth to clean the interior may cause damage to your printer.

5 Make sure the paper support and standard exit bin are dry before beginning a new print job.

Cleaning the printhead lenses

Clean the printhead lenses when you encounter print quality problems.

1 Open the front door.



2 Slide the release lever to the left to unlock the cover.



3 Open the cover.

Warning—Potential Damage: To avoid overexposing the photoconductor unit, do not leave the cover open for more than 10 minutes.



4 Locate the printhead wipers.



5 Gently pull the printhead wipers out until it stops, and then slowly slide them back into place.



6 Close the cover.



7 Slide the release lever to the right to lock the cover.



8 Close the front door.



Emptying the hole punch box

1 Open door G.



2 Pull out the hole punch box.



3 Empty the container.



4 Insert the emptied hole punch box back into the finisher until it stops.



5 Close door G.

Storing supplies

Choose a cool, clean storage area for the printer supplies. Store supplies right side up in their original packing until you are ready to use them.

Do not expose supplies to:

- Direct sunlight
- Temperatures above 35°C (95°F)
- High humidity above 80%
- Salty air
- Corrosive gases
- Heavy dust

Checking the status of parts and supplies

A message appears on the display when a replacement supply item is needed or when maintenance is required.

Checking the status of parts and supplies on the printer control panel

From the home screen, touch **Status/Supplies** > **View Supplies**.

Checking the status of parts and supplies from a network computer

Note: The computer must be connected to the same network as the printer.

1 Open a Web browser, and then type the printer IP address in the address field.

Note: View the printer IP address on the printer control panel home screen. The IP address appears as four sets of numbers separated by periods, such as 123.123.123.123.

2 Click **Device Status**.

Ordering parts and supplies

To order parts and supplies in the U.S., contact Lexmark at 1-800-539-6275 for information about Lexmark authorized supplies dealers in your area. In other countries or regions, go to the Lexmark support Web site at **www.lexmark.com** or contact the place where you purchased the printer.

Notes:

- The gauges displayed are an estimate of the life left for the supply or part indicated next to each gauge.
- All page life estimates for supplies assume printing on a single side of letter- or A4-size plain paper.

Ordering toner cartridges

When **88.xx [color] cartridge low** or **88.xx [color] cartridge nearly low** appears, order a new cartridge.

When **88 Replace [color] cartridge** appears, replace the specified cartridge.

Estimated cartridge yield is based on the ISO/IEC 19798 standard (with about 5% coverage per color). Extremely low print coverage (less than 1.25% for a color) for extended periods of time may negatively affect actual yield for that color and may cause cartridge parts to fail prior to exhaustion of toner.

Part name	Part number
Black high-yield toner cartridge	C950X2KG
Yellow high-yield toner cartridge	C950X2YG
Magenta high-yield toner cartridge	C950X2MG
Cyan high-yield toner cartridge	C950X2CG

Ordering a photoconductor unit

When **84.xx [Color] photoconductor low** or **84.xx [Color] photoconductor nearly low** appears, order a replacement photoconductor unit.

When **84.xx Replace [color] photoconductor** appears, replace the specified photoconductor.

Part name	Part number
Photoconductor unit • Black • Cyan • Magenta • Yellow	C950X71G

Part name	Part number
CMY (Cyan, Magenta, Yellow) Photoconductor Kit **Note:** CMY photoconductor units may reach end of life all at the same time.	C950X73G

Ordering a waste toner bottle

When **82.xx Waste toner bottle nearly full** appears, order a replacement waste toner bottle.

When **82.xx Replace waste toner bottle** appears, replace the waste toner bottle.

Note: Waste toner bottle reuse is not recommended.

Part name	Part number
Waste toner bottle	C950X76G

Ordering staple cartridges

When **Staples Low** or **Staples Empty** appears, order the specified staple cartridge.

For more information, see the illustrations inside the stapler door.

Part name	Part number
Staple Cartridges--3 pack (Staples G5)	25A0013
Advanced Booklet Staples (Staples G11 and Staples G12)	21Z0357

Ordering a maintenance kit

When **[x] Maintenance Kit** appears on the printer display, order the indicated maintenance kit to replace the worn parts. All maintenance kit parts except that in the 480K maintenance kit are designed to be user-replaceable. The kits come with instructions.

Maintenance kit	Service part number
160K Maintenance Kit	40X7540
320K (100 V) Maintenance Kit	40X7568
320K (110 V) Maintenance Kit	40X7550
320K (220 V) Maintenance Kit	40X7569
480K Maintenance Kit	40X7560

Replacing parts and supplies

Replacing a maintenance kit

1 Replace the maintenance kit.

2 Reset the maintenance count to zero to clear the **`80 scheduled maintenance [x]`** message.

Note: For more information on replacing the maintenance kit and resetting the maintenance count, see the instruction sheets that came with the maintenance kit.

Replacing a photoconductor unit

1 Open the front door.



2 Rotate the release lever counterclockwise to open the cover.



3 Lower the cover.



Warning—Potential Damage: To avoid overexposing the photoconductor unit, do not leave the door open for more than 10 minutes.

4 Grasp the handle of the photoconductor unit and pull it out of the machine.



5 Unpack the replacement photoconductor unit.

6 Align and insert the end of photoconductor unit.



7 Remove the tape from the top of the photoconductor unit.



8 Push the tab forward to insert the photoconductor unit.



9 Push the photoconductor unit until it *clicks* into place



10 Gently pull the printhead wipers out until it stops, and then slowly slide them back into place.



11 Close the cover.



12 Rotate the release lever clockwise to lock the cover.



13 Close the front door.



Replacing a toner cartridge

1 Open the front door.



2 Put your hand under the dent of the toner cartridge, and then slightly lift up the cartridge.



3 Pull out the toner cartridge.



4 Unpack the replacement toner cartridge, and then shake it front-to-back and side-to-side to evenly distribute the toner.



5 Remove the red packing strip from the new cartridge.

6 Insert the new cartridge into the printer.



7 Close the front door.



Replacing the waste toner bottle

1 Turn the printer off.

2 Open the front door.



3 Remove the used waste toner bottle.



4 Unpack the new waste toner bottle.



5 Insert the new waste toner bottle into the printer until it *clicks* into place.



6 Rotate the release lever counterclockwise to open the cover.



7 Lower the cover.



8 Slide out the printhead wipers.



9 Slide the printhead wipers back into place.



10 Close the cover.



11 Rotate the release lever clockwise to lock the cover.



12 Close the front door.



13 Turn the printer back on.

Replacing a staple cartridge

Note: A message on the printer display indicates which staple cartridge needs to be replaced.

Replacing staple cartridge in the standard stapler unit

1 Open door G.



2 Grasp the handle of the staple cartridge holder, and then pull out the holder to the right.



3 Pull the staple cartridge out of the finisher.

Note: Use just a slight force when removing the staple cartridge.



4 Squeeze both sides of the empty staple case with your fingers, and then remove the staple case from the cartridge.



5 Insert the front side of the new staple case into the staple cartridge, and then push the rear side into the cartridge.



6 Push the staple cartridge into the finisher until it *clicks* into place.



7 Close door G.

Replacing staple cartridge in the booklet stapler unit

Note: This task is applicable only when a booklet finisher is installed.

1 Open door G.



2 Press the handles of the staple cartridge to the right, and then take the staple cartridge unit out of the finisher.



3 Hold the tabs on both sides of the staple cartridge.



4 Rotate the booklet staple cartridge at an angle.



5 Lift the booklet staple cartridge out of the unit.



6 Squeeze both sides of the empty staple case with your fingers, and then remove the staple case from the cartridge.



7 Insert the front side of the new staple case into the staple cartridge, and then push the rear side into the cartridge.



8 Return the cartridge to its original position, and then gently push the cartridge in until it *clicks* into place.



9 Return the unit to its original position.



10 Close door G.

Moving the printer

Before moving the printer

CAUTION—POTENTIAL INJURY: The printer weight is greater than 18 kg (40 lb) and requires two or more trained personnel to lift it safely.

CAUTION—POTENTIAL INJURY: Before moving the printer, follow these guidelines to avoid personal injury or printer damage:

- Turn the printer off using the power switch, and then unplug the power cord from the wall outlet.
- Disconnect all cords and cables from the printer before moving it.
- Lift the printer off of the optional drawer and set it aside instead of trying to lift the drawer and printer at the same time.

  Note: Use the handholds located on both sides of the printer to lift it off the optional drawer.

Warning—Potential Damage: Damage to the printer caused by improper moving is not covered by the printer warranty.

Moving the printer to another location

The printer and options can be safely moved to another location by following these precautions:

- Any cart used to move the printer must have a surface able to support the full footprint of the printer. Any cart used to move the options must have a surface able to support the dimensions of the options.
- Keep the printer in an upright position.
- Avoid severe jarring movements.

Shipping the printer

When shipping the printer, use the original packaging or call the place of purchase for a relocation kit.

Administrative support

Finding advanced networking and administrator information

This chapter covers basic administrative support tasks using the Embedded Web Server. For more advanced system support tasks, see the *Networking Guide* on the *Software and Documentation* CD or the *Embedded Web Server — Security: Administrator's Guide* on the Lexmark support Web site at **http://support.lexmark.com**.

Checking the virtual display

1. Open an Embedded Web Server associated with your printer.

   Type the printer IP address into the address field of your Web browser.

   If you do not know the IP address of the printer, you can:

   - View the IP address on the printer control panel in the TCP/IP section under the Networks/Ports menu.
   - Print a network setup page or the menu settings pages and locate the IP address in the TCP/IP section.

2. Check the virtual display that appears in the top left corner of the screen.

   The virtual display works as an actual display would work on a printer control panel, showing printer messages.

Checking the status of the printer

1. Type the printer IP address into the address field of your Web browser.

   If you do not know the IP address of the printer, you can:

   - View the IP address on the printer control panel in the TCP/IP section under the Networks/Ports menu.
   - Print a network setup page or the menu settings pages and locate the IP address in the TCP/IP section.

2. Click **Device Status**.

The device status shows the following:

- Paper tray settings
- Level of toner in the print cartridge
- Percentage of life remaining in the maintenance kit
- Capacity measurements of certain printer parts

Setting up e-mail alerts

Configure the printer to send you e-mail alerts when the supplies are getting low or when the paper needs to be changed or added, or when there is a paper jam.

1. Type the printer IP address into the address field of your Web browser.

   If you do not know the IP address of the printer, you can:

   - View the IP address on the printer control panel in the TCP/IP section under the Networks/Ports menu.
   - Print a network setup page or the menu settings pages and locate the IP address in the TCP/IP section.

2 Click **Settings**.

3 Under Other Settings, click **E-mail Alert Setup**.

4 Select the items for notification, and type the e-mail addresses.

5 Click **Submit**.

Note: For information on setting up the e-mail server, contact your system support person.

Viewing reports

You can view some reports from the Embedded Web Server. These reports are useful for assessing the status of the printer, the network, and supplies.

To view reports from a network printer:

1 Type the printer IP address into the address field of your Web browser.

If you do not know the IP address of the printer you can:

- View the IP address on the printer control panel in the TCP/IP section under the Networks/Ports menu.
- Print a network setup page or the menu settings pages and locate the IP address in the TCP/IP section.

2 Click **Reports**, and then click the type of report you want to view.

Restoring factory default settings

If you want to retain a list of the current menu settings for reference, then print a menu settings page before restoring the factory default settings.

Warning—Potential Damage: Restoring factory defaults returns most printer settings to the original factory default settings. Exceptions include the display language, custom sizes and messages, and network/port menu settings. All downloads stored in RAM are deleted. Downloads stored in flash memory or on a printer hard disk are not affected.

From the home screen, navigate to:

> **Settings** > **General Settings** > **Factory Defaults** > **Restore Now** >

Clearing jams

Carefully select paper and specialty media and load it properly to avoid most jams. If jams occur, follow the steps outlined in this chapter.

Note: Jam Recovery is set to Auto by default. The printer reprints jammed pages unless the memory required to hold the pages is needed for other printer tasks.

Avoiding jams

Paper tray recommendations

- Make sure the paper lies flat in the tray.
- Do not remove a tray while the printer is printing.
- Do not load a tray while the printer is printing. Load it prior to printing, or wait for a prompt to load it.
- Do not load too much paper. Make sure the stack height does not exceed the indicated maximum height.
- Make sure the guides in the tray or the multipurpose feeder are properly positioned and are not pressing too tightly against the paper or envelopes.
- Push the tray in firmly after loading paper.

Paper recommendations

- Use only recommended paper or specialty media.
- Do not load wrinkled, creased, damp, bent, or curled paper.
- Flex and straighten paper before loading it.



- Do not use paper that has been cut or trimmed by hand.
- Do not mix paper sizes, weights, or types in the same stack.
- Make sure all sizes and types are set correctly in the printer control panel menus.
- Store paper per manufacturer recommendations.

Understanding jam numbers and locations

When a jam occurs, a message indicating the jam location appears on the printer display. Open doors and covers, and remove trays to access jam locations. To resolve any paper jam message, you must clear all jammed paper from the paper path.



Area	Area name	Jam numbers	What to do
1	Cover F	**281** **4yy.xx**	Open cover F, and then remove the jammed paper.
2	Door G	**455** **4yy.xx**	Open door G, and then remove the jammed paper. For staple jams, remove the staple cartridge, and then clear the staple jam.
3	Door H	**4yy.xx**	Open door H, and then remove the jammed paper.
4	Standard exit bin	**201–202** **203**	Remove all paper from the standard exit bin, and then remove the jammed paper.
5	Standard finisher bin	**4yy.xx**	Remove all paper from the standard finisher bin, and then remove the jammed paper.
6	Finisher bin 1	**4yy.xx**	Remove all paper from the finisher bin 1, and then remove the jammed paper.
7	Finisher bin 2	**4yy.xx**	Remove all paper from the finisher bin 2, and then remove the jammed paper.
8	Door C Tray [x]	**24x**	Open door C, and then remove the jammed paper. Open each tray, and then remove any jams.
9	Tray 5 (high-capacity feeder)	**24x**	Open the tray, and then remove the jammed paper. Open the top cover, and then remove the jammed paper. Gently move the tray to the left until it stops, and then remove the jammed paper.

Area	Area name	Jam numbers	What to do
10	Multipurpose feeder	**250**	Remove all paper from the multipurpose feeder, and then remove the jammed paper.
11	Door B	**230**	Open door B, and then remove the jammed paper.
12	Door A	**201–202** **231** **281**	Open door A, and then remove the jammed paper.
13	Door D	**203**	Open door A, and then door D, and then remove the jammed paper.

201–202 paper jams

If the jammed paper is visible in the standard exit bin, then firmly grasp the paper on each side, and then gently pull it out.

Note: Make sure all paper fragments are removed.



Paper jam in the fuser

1 Open door A by lifting the release latch and lowering the door.

CAUTION—HOT SURFACE: The inside of the printer might be hot. To reduce the risk of injury from a hot component, allow the surface to cool before touching.

2 Lift the green lever.



3 Firmly grasp the jammed paper on each side, and then gently pull it out.

Warning—Potential Damage: Do not touch the center of the fuser unit. Doing so will damage the fuser.

Note: Make sure all paper fragments are removed.

4 Push the green lever back into place.

5 Close door A.

6 If necessary, touch **Continue** from the printer control panel.

Paper jam under the fuser

1 Open door A.

CAUTION—HOT SURFACE: The inside of the printer might be hot. To reduce the risk of injury from a hot component, allow the surface to cool before touching.

2 If the jammed paper is visible under the fuser, then firmly grasp the paper on each side, and then gently pull it out.

Note: Make sure all paper fragments are removed.

3 Close door A.

4 If necessary, touch **Continue** from the printer control panel.

203 paper jam

If the jammed paper is visible in the standard exit bin, then firmly grasp the paper on each side, and then gently pull it out.

Note: Make sure all paper fragments are removed.



1 Open door A, and then door D by lifting the release latch of each door and lowering the doors.

CAUTION—HOT SURFACE: The inside of the printer might be hot. To reduce the risk of injury from a hot component, allow the surface to cool before touching.

2 Firmly grasp the jammed paper on each side, and then gently pull it out.



Note: Make sure all paper fragments are removed.

3 Close door D, and then close door A.

4 If necessary, touch **Continue** from the printer control panel.

230 paper jam

1 Lower the multipurpose feeder, and then open door B.



2 Firmly grasp the jammed paper on each side, and then gently pull it out.

Note: Make sure all paper fragments are removed.



3 Close door B.

4 If necessary, touch **Continue** from the printer control panel.

231 paper jam

1 Open door A by lifting the release latch, and then lowering the door.

CAUTION—HOT SURFACE: The inside of the printer might be hot. To reduce the risk of injury from a hot component, allow the surface to cool before touching it.



2 Lift the green lever.



3 Firmly grasp the jammed paper on each side, and then gently pull it out.

Note: Make sure all paper fragments are removed.

4 Push the green lever back into place.

5 Close door A.



6 If necessary, touch **Continue** from the printer control panel.

24x paper jam

Note: Make sure all paper fragments are removed when pulling out any jammed paper.

Paper jam in Tray 1

1 Open Tray 1.



2 Firmly grasp the jammed paper on each side, and then gently pull it out.



3 Close Tray 1.

4 If necessary, touch **Continue, jam cleared** from the printer control panel.

Paper jam in one of the optional trays (Trays 2–4)

1 Check door C, and then firmly grasp the jammed paper and then pull it out.



2 Open the specified tray.

3 Firmly grasp the jammed paper on each side, and then gently pull it out.



4 Close the tray.

5 If necessary, touch **Continue, jam cleared** from the printer control panel.

Paper jam in Tray 5 (high-capacity feeder)

Paper jam inside the tray

1 Pull out the tray until it stops.



Warning—Potential Damage: Do not pull out the tray with too much force. Doing so may hit and injure your knees.

2 Firmly grasp the jammed paper on each side, and then gently pull it out.



3 Push the tray gently until it stops.

4 If necessary, touch **Continue, jam cleared** from the printer control panel.

Paper jam in the tray exit

1 Gently move the tray to the left until it stops.



2 Firmly grasp the jammed paper on each side, and then gently pull it out.



3 Gently put the tray back into position.

4 If necessary, touch **Continue, jam cleared** from the printer control panel.

Paper jam in the top cover

1 Gently move the tray to the left until it stops.



2 Open the top cover.



3 Firmly grasp the jammed paper on each side, and then gently pull it out.



4 Close the top cover.



5 Gently put the tray back into position.

6 If necessary, touch **Continue, jam cleared** from the printer control panel.

250 paper jam

1 Remove any jammed pages from the multipurpose feeder.



2 Load paper into the multipurpose feeder.

3 If necessary, touch **Continue, jam cleared** from the printer control panel.

281 paper jam

Paper jam in door A

1 Open door A.

CAUTION—HOT SURFACE: The inside of the printer might be hot. To reduce the risk of injury from a hot component, allow the surface to cool before touching.

2 Determine where the jam is located, and then remove it:

a If the paper is visible under the fuser, firmly grasp it on each side, and then gently pull it out.

Note: Make sure all paper fragments are removed.



b If the paper is not visible, then you will need to remove the fuser unit.

Warning—Potential Damage: Do not touch the center of the fuser unit. Doing so will damage the fuser.

1 Remove the thumbscrew from each side of the fuser unit by rotating them counterclockwise.

2 Lift the handles on each side of the fuser, and then pull to remove the fuser unit.



3 Lift the green lever, firmly grasp the paper on each side, and then gently pull it out.

Notes:

- Make sure all paper fragments are removed.
- If the paper is in the fuser, then lower the fuser nip release lever and switch it to envelope mode.
- After removing the jammed paper, return the lever to the proper position.



4 Align the fuser unit using the handles on each side, and then place it back into the printer.



3 Close door A.

4 If necessary, touch **Continue** from the printer control panel.

Paper jam in cover F (paper transport)

1 Open cover F.



2 Firmly grasp the jammed paper on each side, and then gently pull it out.

Note: Make sure all paper fragments are removed.



Note: If the paper jam on the right is difficult to remove, then rotate the knob counterclockwise.

3 Close cover F.

4 If necessary, touch **Continue** from the printer control panel.

4yy.xx paper jams

If the jammed paper is visible in any of the finisher exit bins, then firmly grasp the paper on each side, and then gently pull it out.



1	Standard finisher bin
2	Finisher bin 1
3	Finisher bin 2 **Note:** Finisher bin 2 is available only when a booklet finisher is installed.

Note: Make sure all paper fragments are removed.

Paper jam in door H

1 Open door H.

Note: Door H is located between the finisher exit bins.



2 Firmly grasp the jammed paper on each side, and then gently pull it out.

Note: Make sure all paper fragments are removed.



3 Close door H.

4 If necessary, touch **Continue** from the printer control panel.

Paper jam in door G

1 Open door G.





Area	Cover, knob, or handle name
1	Cover G1
2	Cover G2

Area	Cover, knob, or handle name
3	Knob G3
4	Cover G4
5	Cover G7
6	Knob G8
7	Handle G9

2 Lift cover G1 lever.

3 Firmly grasp any jammed paper, and then gently pull it out.

Note: Make sure to remove all paper fragments after gently pulling out any jammed paper inside door G.

4 Move cover G2 to the right, and then remove any jammed paper.

Note: If the paper is jammed in the rollers, then rotate knob G3 counterclockwise.

5 Move cover G4 down, and then remove any jammed paper.

6 Move cover G7 to the left, and then remove any jammed paper.

7 Pull handle G9 until the tray is completely open.



8 Lift the inside cover. If the paper is jammed in the rollers, then rotate knob G8 counterclockwise, and then remove the jammed paper.



9 Close door G.

10 If necessary, touch **Continue** from the printer control panel.

Paper jam in cover F (paper transport)

1 Open cover F.



2 Firmly grasp the jammed paper on each side, and then gently pull it out.

Note: Make sure all paper fragments are removed.





Note: If the paper jam on the right is difficult to remove, then rotate the knob counterclockwise.

3 Close cover F.

4 If necessary, touch **Continue** from the printer control panel.

455 staple jam

1 Open door G.



2 Press the latch to open the stapler door.

Note: The stapler door is located behind the finisher.



3 Lower the latch of the staple cartridge holder, and then pull the staple cartridge holder out of the printer.



4 Use the metal tab to lift the staple guard, and then remove any jammed or loose staples.



5 Close the staple guard.



6 Press down on the staple guard until it *clicks* into place.

7 Push the staple cartridge holder firmly back into the stapler unit until the staple cartridge holder *clicks* into place.



8 Close the stapler door.

9 Close door G.

10 If necessary, touch **Continue, jam cleared** from the printer control panel.

Troubleshooting

Solving basic printer problems

If there are basic printer problems, or the printer is unresponsive, make sure:

- The power cord is plugged into the printer and a properly grounded electrical outlet.
- The electrical outlet is not turned off by any switch or breaker.
- The printer is not plugged into any surge protectors, uninterrupted power supplies, or extension cords.
- Other electronic equipment plugged into the outlet is working.
- The printer is turned on. Check the printer power switch.
- The printer cable is securely attached to the printer and the host computer, print server, option, or other network device.
- All options are properly installed.
- The printer driver settings are correct.

Once you have checked each of these possibilities, turn the printer off, wait for about 10 seconds, and then turn the printer back on. This often fixes the problem.

Understanding the printer messages

An error has occured with the Flash Drive. Please remove and re-insert the drive.

Try one or more of the following:

- Remove and reinsert the flash drive.
- If the error message remains, the flash memory may be defective and require replacing.

Bin 2 is unable to lower, remove paper and check for an obstruction

Try one or more of the following:

- Remove paper and clear any obstruction from the bin.
- Touch **Continue** to clear the message and continue printing.

Change [paper source] to [custom type name]

Try one or more of the following:

- Touch **Use current [paper source]** to ignore the message and print from the selected tray.
- Load the correct paper size and type in the tray, verify the paper size and type settings are specified in the printer control panel Paper menu, and then touch **Paper changed, continue**.
- Touch **Cancel job** to cancel the print job.

Change [paper source] to [custom type name] load [orientation]

Try one or more of the following

- Touch **Use current [paper source]** to ignore the message and print from the selected tray.
- Load the correct paper size and type in the tray, verify the paper size and type settings are specified in the printer control panel Paper menu, and then touch **Paper changed, continue**.
- Touch **Cancel job** to cancel the print job.

Change [paper source] to [custom string]

Try one or more of the following:

- Touch **Use current [paper source]** to ignore the message and print from the selected tray.
- Load the correct paper size and type in the tray, verify the paper size and type settings are specified in the printer control panel Paper menu, and then touch **Paper changed, continue**.
- Touch **Cancel job** to cancel the print job.

Change [paper source] to [custom string] load [orientation]

Try one or more of the following:

- Touch **Use current [paper source]** to ignore the message and print from the selected tray.
- Load the correct paper size and type in the tray, verify the paper size and type settings are specified in the printer control panel Paper menu, and then touch **Paper changed, continue**.
- Touch **Cancel job** to cancel the print job.

Change [paper source] to [paper size] [paper type]

Try one or more of the following:

- Touch **Use current [paper source]** to ignore the message and print from the selected tray.
- Load the correct paper size and type in the tray, verify the paper size and type settings are specified in the printer control panel Paper menu, and then touch **Paper changed, continue**.
- Touch **Cancel job** to cancel the print job.

Change [paper source] to [paper size] [paper type] load [orientation]

Try one or more of the following:

- Touch **Use current [paper source]** to ignore the message and print from the selected tray.
- Load the correct paper size and type in the tray, verify the paper size and type settings are specified in the printer control panel Paper menu, and then touch **Paper changed, continue**.
- Touch **Cancel job** to cancel the print job.

Check [src] orientation or guides

Try one or more of the following:

- Move the paper guides in the tray to the correct positions for the paper size loaded.
- Make sure the paper size setting matches the paper loaded in the tray:
  1. From the printer control panel Paper menu, check the Paper Size setting.
  2. Before sending the print job, specify the correct size setting:
     - For Windows users, specify the paper size from Print Properties.
     - For Macintosh users, specify the paper size from the Page Setup dialog.

Close cover [x]

Close the specified cover to clear the message.

Close door [x]

Close the specified door.

Disk corrupted

The printer attempted a hard disk recovery on a corrupted hard disk, and the hard disk cannot be repaired. The hard disk must be reformatted.

Touch **Format disk** to reformat the printer hard disk and clear the message.

Note: Formatting deletes all the files stored on the printer hard disk.

Empty the hole punch box

1. Empty the hole punch box.

   For instructions on emptying the hole punch box, from the printer control panel touch **More Information**.
2. Reinsert the hole punch box into the finisher, and then touch **Continue** to clear the message.

Error reading USB drive. Remove USB.

An unsupported USB device has been inserted. Remove the USB device, and then install a supported one.

Error reading USB hub. Remove hub.

An unsupported USB hub has been inserted. Remove the USB hub, and then install a supported one.

Insert staple cartridge

Try one or more of the following:

- Insert a staple cartridge.
- Touch **Continue** to clear the message and print without using the staple finisher.

Insert the hole punch box

Insert the hole punch box into the finisher, and then touch **Continue** to clear the message.

Insert Tray [x]

Insert the specified tray into the printer.

Install bin [x]

Try one or more of the following:

- Install the specified bin:
  1. Turn the printer off.
  2. Unplug the power cord from the wall outlet.
  3. Install the specified bin.
  4. Connect the power cord to a properly grounded electrical outlet.
  5. Turn the printer back on.
- Cancel the print job.

Load [src] with [custom type name]

Try one or more of the following:

- Load the specified paper in the tray or feeder.
- Touch **Paper loaded, continue** to clear the message and continue printing.

  If the printer finds a tray that has the correct paper type and size, it feeds from that tray. If the printer cannot find a tray with the correct paper type and size, it prints from the default paper source.
- Cancel the print job.

Load [src] with [custom string]

Try one or more of the following:

- Load the specified paper in the tray or feeder.
- Touch **Paper loaded, continue** to clear the message and continue printing.

  If the printer finds a tray that has the correct paper type and size, it feeds from that tray. If the printer cannot find a tray with the correct paper type and size, it prints from the default paper source.
- Cancel the print job.

Load [src] with [size]

Try one or more of the following:

- Load the specified paper in the tray or feeder.
- Touch **Paper loaded, continue** to clear the message and continue printing.

  If the printer finds a tray that has the correct paper type and size, it feeds from that tray. If the printer cannot find a tray with the correct paper type and size, it feeds from the default paper source.
- Cancel the print job.

Load [src] with [type] [size]

Try one or more of the following:

- Load the specified paper in the tray or feeder.
- Touch **Paper loaded, continue** to clear the message and continue printing.

  If the printer finds a tray that has the correct paper type and size, it feeds from that tray. If the printer cannot find a tray with the correct paper type and size, it feeds from the default paper source.
- Cancel the print job.

Load Manual Feeder with [custom type name]

Try one or more of the following:

- Load the specified paper in the manual feeder.
- Touch **Prompt each page, paper loaded** or **Do not prompt, paper loaded** to clear the message and continue printing.
- Touch **Automatically select paper** to use the paper loaded in the tray.
- Cancel the print job.

Load Manual Feeder with [custom string]

Try one or more of the following:

- Load the specified paper in the manual feeder.
- Touch **Prompt each page, paper loaded** or **Do not prompt, paper loaded** to clear the message and continue printing.
- Touch **Automatically select paper** to use the paper loaded in the tray.
- Cancel the print job.

Load Manual Feeder with [paper size]

Try one or more of the following:

- Load the specified paper in the manual feeder.
- Touch **Prompt each page, paper loaded** or **Do not prompt, paper loaded** to clear the message and continue printing.
- Touch **Automatically select paper** to use the paper loaded in the tray.
- Cancel the print job.

Load Manual Feeder with [paper type] [paper size]

Try one or more of the following:

- Load the specified paper in the manual feeder.
- Touch **Prompt each page, paper loaded** or **Do not prompt, paper loaded** to clear the message and continue printing.
- Touch **Automatically select paper** to use the paper loaded in the tray.
- Cancel the print job.

Manual feeder expects [paper size]. Check [paper source] guides

Try one or more of the following:

- Load the specified paper size in the manual feeder.
- Physically adjust [paper source] guides to a recognized paper size.
- Touch **Continue** to clear the message and continue printing.

  If the printer finds a tray that has the correct paper type and size, then it feeds from that tray. If the printer cannot find a tray with the correct paper type and size, then it prints from the default source.

Load staples

Try one or more of the following:

- Replace the specified staple cartridge in the finisher.
- Touch **Continue** to clear the message and continue printing.

  Note: The print job will be stapled if the staple cartridge is replaced or inserted.
- Touch **Cancel job** to cancel the print job.

Remove paper from standard output bin

Remove the stack of paper from the standard exit bin.

Remove paper from bin [x]

Remove the paper from the specified bin. The printer automatically senses paper removal and resumes printing.

If removing the paper does not clear the message, then touch **Continue**.

Remove paper from all bins

Remove the paper from all of the bins. The printer automatically senses paper removal and resumes printing.

If removing the paper does not clear the message, then touch **Continue**.

Remove paper from [linked set bin name]

Remove paper from the specified bin. The printer automatically detects paper removal and resumes printing.

If removing the paper does not clear the message, then touch **Continue**.

Print quota exceeded. Print job canceled.

The print job has been cancelled because the print quota has been exceeded. Contact your system support person.

Print quota exceeded. Print job incomplete.

The print job did not complete because the print quota has been exceeded. Contact your system support person.

Restore held jobs?

Try one or more of the following:

- Touch **Restore** to restore all held jobs stored on the printer hard disk.
- Touch **Do not restore** if you do not want any print jobs to be restored.

Remove packaging material, [area name]

Remove any remaining packaging material from the specified location.

Some held jobs were not restored

Touch **Continue** to delete the specified job.

Note: Held jobs that are not restored stay on the hard disk and are inaccessible.

Unsupported camera mode, unplug camera and change mode

The camera mode does not support PictBridge.

Unplug the camera, change the mode and plug the camera back into the printer.

Unsupported disk

An unsupported disk has been inserted. Remove the unsupported disk, and then install a supported one.

31.xx Missing or defective [color] cartridge

Try one or more of the following:

1. Remove and reinstall the specified print cartridge.

   For instructions on removing a print cartridge, touch **More Information**.

2. Touch **Continue** to clear the message.

   Note: If the message is not cleared, then replace the defective print cartridge.

32.xx [color] cartridge part number unsupported by device

Remove the unsupported toner cartridge, and then install a supported one.

34 Incorrect paper size, check [paper source]

Try one or more of the following:

- Load the appropriate paper or specialty media in the proper tray.
- Confirm that the wheel on Tray 1 is set to the paper size loaded in the tray. Make sure the paper size matches the document you are trying to print.
- Touch **Continue** to clear the message and print using a different tray.
- Check the tray length and width guides and make sure the paper is loaded properly in the tray.
- Make sure the correct paper size and type are specified on the Print Properties or Print dialog settings.
- Check that the paper size is correctly set. For example, if the MP Feeder Size is set to Universal, make sure the paper is large enough for the data being printed.
- Cancel the print job.

34 Incorrect paper type, check [paper source]

Try one or more of the following:

- Load the appropriate paper or specialty media in the proper tray.
- Confirm that the wheel on Tray 1 is set to the paper type loaded in the tray. Make sure the paper type matches the document you are trying to print.
- Touch **Continue** to clear the message and print using a different tray.
- Check the tray length and width guides and make sure the paper is loaded properly in the tray.
- Make sure the correct paper size and type are specified on the Print Properties or Print dialog settings.
- Check that the paper type is correctly set. For example, if the MP Feeder Type is set to Universal, then make sure the paper is large enough for the data being printed.
- Cancel the print job.

35 Insufficient memory to support Resource Save feature

Try one or more of the following:

- Touch **Continue** to disable Resource Save and continue printing.
- To enable Resource Save after receiving this message, make sure the link buffers are set to Auto, and then exit the menus to activate the link buffer changes. When **Ready** appears, enable Resource Save.
- Install additional memory.

37 Insufficient memory, some held jobs will not be restored

The printer was unable to restore some or all of the confidential or held jobs on the printer hard disk.

Touch **Continue** to clear the message.

37 Insufficient memory, some Held Jobs were deleted

The printer deleted some held jobs in order to process current jobs.

Touch **Continue** to clear the message.

37 Insufficient memory to collate job

Try one or more of the following:

- Touch **Continue** to print the portion of the job already stored and begin collating the rest of the print job.
- Cancel the current print job.

37 Insufficient memory for Flash Memory Defragment operation

Try one or more of the following:

- Touch **Continue** to stop the defragment operation and continue printing.
- Delete fonts, macros, and other data in printer memory.
- Install additional printer memory.

38 Memory full

Try one or more of the following:

- Touch **Cancel job** to clear the message.
- Install additional printer memory.

39 Complex page, some data may not have printed

Try one or more of the following:

- Touch **Continue** to clear the message and continue printing.
- Cancel the current print job.
- Install additional printer memory.

40 [color] invalid refill, change cartridge

Replace the specified cartridge to continue printing.

51 Defective flash detected

Try one or more of the following:

- Touch **Continue** to clear the message and continue printing.
- Cancel the current print job.

52 Not enough free space in flash memory for resources

Try one or more of the following:

- Touch **Continue** to clear the message and continue printing.

  Downloaded fonts and macros not previously stored in flash memory are deleted.
- Delete fonts, macros, and other data stored in flash memory.
- Upgrade to a larger capacity flash memory card.

53 Unformatted flash detected

Try one or more of the following:

- Touch **Continue** to stop the defragment operation and continue printing.
- Format the flash memory. If the error message remains, the flash memory may be defective and require replacing.

54 Serial option [x] error

Try one or more of the following:

- Check that the serial cable is properly connected and is the correct one for the serial port.
- Check that the serial interface parameters (protocol, baud, parity, and data bits) are set correctly on the printer and host computer.
- Touch **Continue** to continue printing.
- Turn the printer power off and then back on to reset the printer.

54 Standard network software error

Try one or more of the following:

- Touch **Continue** to continue printing.
- Turn the printer off and then back on to reset the printer.
- Upgrade (flash) the network firmware in the printer or print server.

54 Network [x] software error

Try one or more of the following:

- Touch **Continue** to continue printing.
- Turn the printer off, wait for about 10 seconds, and then turn the printer back on.
- Upgrade (flash) the network firmware in the printer.

55 Unsupported option in slot [x]

1. Turn the printer off.
2. Unplug the power cord from the wall outlet.
3. Remove the unsupported option card from the printer system board, and then replace it with a supported card.
4. Connect the power cord to a properly grounded electrical outlet.
5. Turn the printer back on.

56 Parallel port [x] disabled

Try one or more of the following:

- Touch **Continue** to clear the message.

  The printer discards any data received through the parallel port.
- Make sure the Parallel Buffer menu item is not set to Disabled.

56 Serial port [x] disabled

Try one or more of the following:

- Touch **Continue** to clear the message.

  The printer discards any data received through the serial port.
- Make sure the Serial Buffer menu is not set to Disabled.

56 Standard USB port disabled

Try one or more of the following:

- Touch **Continue** to clear the message.

  The printer discards any data received through the USB port.
- Make sure the USB Buffer menu item is not set to Disabled.

56 Standard parallel port disabled

Try one or more of the following:

- Touch **Continue** to clear the message.

  The printer discards any data received through the parallel port.
- Make sure the Parallel Buffer menu item is not set to Disabled.

56 USB port [x] disabled

Try one or more of the following:

- Touch **Continue** to clear the message.

  The printer discards any data received through the USB port.
- Make sure the USB Buffer menu is not set to Disabled.

57 Configuration change, some held jobs were not restored

Something has changed in the printer to invalidate the held jobs. Possible changes include:

- The printer firmware has been updated.
- Paper input options needed for the print job were removed.
- The print job was created using data from a device in the USB port and the device is no longer in the USB port.
- The printer hard disk contains print jobs that were stored while installed in a different printer model.

Touch **Continue** to clear the message.

58 Too many disks installed

1. Turn the printer off.
2. Unplug the power cord from the wall outlet.
3. Remove the excess disks.
4. Connect the power cord to a properly grounded electrical outlet.
5. Turn the printer back on.

58 Too many flash options installed

1. Turn the printer off.
2. Unplug the power cord from the wall outlet.
3. Remove the excess flash memory.
4. Connect the power cord to a properly grounded outlet.
5. Turn the printer back on.

58 Too many trays attached

1. Turn the printer off.
2. Unplug the power cord from the wall outlet.
3. Remove the additional trays.
4. Connect the power cord to a properly grounded outlet.
5. Turn the printer back on.

59 Incompatible tray [x]

Try one or more of the following:

- Remove the specified tray.
- Touch **Continue** to clear the message and continue printing without using the specified tray.

61 Remove defective disk

Try one or more of the following:

- Remove the defective printer hard disk.
- Install a different printer hard disk before performing any operations that require a printer hard disk.

62 Disk full

Try one or more of the following:

- Touch **Continue** to clear the message and continue processing.
- Delete fonts, macros, and other data stored on the printer hard disk.
- Install a printer hard disk with larger capacity.

80 Scheduled maintenance [x]

Contact customer support, and report the message. The printer is scheduled for maintenance.

80 Replace paper pick rollers in [paper source], use parts and instructions in tray 1 compartment

Try one or more of the following:

- Touch **Continue and replace later** to ignore the message and continue printing.

  Note: Worn or defective paper pick rollers may cause paper jams.
- Replace the worn or defective paper pick rollers, and then touch **Rollers replaced** to clear the message and continue printing.

82.xx Replace waste toner bottle

1. Replace the waste toner bottle.

   For instructions on replacing the waste toner bottle, from the printer control panel touch **More Information**.
2. Touch **Continue** to clear the message and continue printing.

82.xx Waste toner bottle nearly full

Order a replacement waste toner bottle immediately.

1. Replace the waste toner bottle.

   For instructions on installing the waste toner bottle, from the printer control panel touch **More Information**.
2. Touch **Continue** to clear the message and continue printing.

82.xx Waste toner bottle missing

Reinsert the waste toner bottle into the printer.

84 unsupported [color] photoconductor

Remove the specified photoconductor, and then install a supported one.

84.xx [color] photoconductor low

1 Order a replacement photoconductor immediately.

2 When print quality is reduced, install the new photoconductor, following the instruction sheet that came with the replacement part.

3 Touch **Continue** to clear the message and continue printing.

84.xx [color] photoconductor missing

Install the specified color photoconductor, following the instruction sheet that came with the replacement part.

84.xx Replace [color] photoconductor

1 Replace the photoconductor, following the instruction sheet that came with the replacement part.

2 From the printer control panel, touch **Continue** to clear the message and continue printing.

88.xx [color] cartridge low

1 Remove the specified cartridge.

Warning—Potential Damage: Be careful not to touch the photoconductor drum. Doing so may affect the print quality of future print jobs.

2 Firmly shake the cartridge side-to-side and front-to-back several times to redistribute the toner.

3 Reinsert the cartridge, and then touch **Continue** to clear the message and continue printing.

Notes:

- Repeat this procedure multiple times until the print remains faded. When the print remains faded, replace the cartridge.
- Have a new cartridge available when the current one no longer prints satisfactorily.

88.xx [Color] cartridge very low

The specified print cartridge is very low.

1 For instructions on replacing a print cartridge, from the printer control panel touch **More Information**.

2 Touch **Continue** to clear the message and continue printing.

88 Replace [color] cartridge

The specified print or toner cartridge is empty.

1 Replace the specified cartridge.

For instructions on replacing cartridge, from the printer control panel, touch **More Information**.

2 Touch **Continue** to clear the message and continue printing.

1565 Emulation error, load emulation option

The printer automatically clears the message in 30 seconds, and then disables the download emulator on the firmware card.

Solving printing problems

Multiple-language PDF files do not print

The PDF files may contain unavailable fonts.

1. Open the document you want to print in Adobe Acrobat.
2. Click the printer icon > **Advanced** > **Print as image** > **OK** > **OK**.

Printer control panel display is blank or displays only diamonds

The printer self test failed. Turn the printer off, wait about 10 seconds, and then turn the printer back on.

If **`Performing Self Test`** and **`Ready`** do not appear, turn the printer off and contact Customer Support.

Error message about reading USB drive appears

Make sure the flash drive is supported.

Print jobs do not print

Try one or more of the following:

Make sure there is no problem with your printer

From the printer control panel, check the status. If necessary, follow the recovery instructions.

Make sure the printer is ready to print

Make sure **`Ready`** appears on the display before sending a print job.

Check if a supply is missing or needs replacement

Remove and then reinstall or replace the supply.

Check if the standard exit bin is full

Remove the paper stack from the standard exit bin.

Check if the paper tray is empty

Load paper in the tray.

Make sure the correct printer software is installed

- Verify that you are using the correct printer software.
- If the printer is connected to your computer through a USB port, then make sure you are running a supported operating system and using a compatible printer software.

Make sure the internal print server is working properly

- Make sure the internal print server is properly installed and that the printer is connected to the network.
- Print a network setup page and check that the status shows **Connected**. If the status is **Not Connected**, then check the network cables, and then try printing the network setup page again. Contact your system support person to make sure the network is functioning correctly.

The printer software is available on the Lexmark Web site at **http://support.lexmark.com**.

Make sure you are using a recommended USB, serial, or Ethernet cable

For more information, visit the Lexmark Web site at **http://support.lexmark.com**.

Make sure printer cables are securely connected

Check the cable connections to the printer and print server to make sure they are secure.

For more information, see the setup documentation that came with the printer.

Confidential and other held jobs do not print

These are possible solutions. Try one or more of the following:

Partial job, no job, or blank page prints

The print job may contain a formatting error or invalid data.

- Delete the print job, and then print it again.
- For PDF documents, recreate the PDF and then print it again.

If you are printing from the Internet, then the printer may be reading multiple job titles as duplicates and deleting all jobs except the first one.

- For Windows users, open Print Properties. From the Print and Hold dialog, select the "Keep duplicate documents" check box under the User name text box before entering a PIN number.
- For Macintosh users, save each print job, naming each job differently, and then send the individual jobs to the printer.

Make sure the printer has sufficient memory

Free up additional printer memory by scrolling through the list of held jobs and deleting some of them.

Print job takes longer than expected

Try one or more of the following:

Reduce the complexity of the print job

Eliminate the number and size of fonts, the number and complexity of images, and the number of pages in the print job.

Turn off the Page Protect setting

From the home screen, navigate to:

> **Settings** > **General Settings** > **Print Recovery** > **Page Protect** > **Off** >

Change the environmental settings

When using Eco-Mode or Quiet Mode settings, you may notice a reduction in performance.

Job prints from the wrong tray or on the wrong paper

Check the paper type and paper size settings

Make sure the paper type setting matches the paper loaded in the tray:

1. From the printer control panel Paper menu, check the paper type and paper size settings.
2. Before sending the job to print, specify the correct type setting:
   - For Windows users, specify the paper type from Print Properties.
   - For Macintosh users, specify the paper type from the Print dialog.

Incorrect characters print

- Make sure the printer is not in Hex Trace mode. If **`Ready Hex`** appears on the display, you must exit Hex Trace mode before you can print your job. Turn the printer off and back on to exit Hex Trace mode.
- Make sure the SmartSwitch settings are set to On in the Network and USB menus.

Tray linking does not work

These are possible solutions. Try one or more of the following:

Load the same size and type of paper

- Load the same size and type of paper in each tray to be linked.
- Move the paper guides to the correct positions for the paper size loaded in each tray.

Use the same Paper Size and Paper Type settings

- Print a menu settings page and compare the settings for each tray.
- If necessary, adjust the settings from the Paper Size/Type menu.

Note: The standard 550-sheet tray and the multipurpose feeder do not automatically sense the paper size. You must set the size from the Paper Size/Type menu.

Large jobs do not collate

These are possible solutions. Try one or more of the following:

Make sure Collate is set to On

From the Finishing menu or Print Properties, set Collate to On.

Note: Setting Collate to Off in the software overrides the setting in the Finishing menu.

Reduce the complexity of the print job

Reduce the complexity of the print job by eliminating the number and size of fonts, the number and complexity of images, and the number of pages in the job.

Make sure the printer has enough memory

Add printer memory or an optional hard disk.

Unexpected page breaks occur

Increase the Print Timeout value

1. From the home screen, navigate to:

   > **Settings** > **General Settings** > **Timeouts**

2. Touch the left or right arrow next to **`Print Timeout`** until the desired value appears.
3. Touch **Submit**.

Solving home screen application problems

An application error has occurred

Check the system log for relevant details

1. Type the printer IP address or host name in the address field of your Web browser.

If you do not know the IP address or host name of the printer, then you can:

- View the information on the printer control panel home screen, or in the TCP/IP section under the Networks/Ports menu.
- Print a network setup page or menu settings page and locate the information in the TCP/IP section.

2 Click **Settings** or **Configuration**.

3 Click **Device Solutions** > **Solutions (eSF)** > **System** tab > **Log**.

4 From the Filter menu, select an application status.

5 From the Application menu, select an application, and then click **Submit**.

Make sure the file name you want to scan to is not already in use

Verify that the file to which you want to scan is not open by another application or user.

To help prevent errors, make sure either “Append time stamp” or “Overwrite existing file” is selected in the destination configuration settings.

Adjust the scan settings

In the destination configuration settings, lower the scan settings. For example, lower the scan resolution, disable Color, or change the Content type to Text.

Contact customer support

If you still cannot isolate the problem, then contact customer support.

Forms and Favorites troubleshooting

Forms are not available or are not working

Make sure the bookmark pointing to the form is in the Bookmarks root folder

If the bookmark pointing to the form was created in a subfolder of the Bookmarks folder, then it will not be available under the Forms solution. Delete the bookmark and recreate it under the Bookmarks root folder.

Make sure the bookmark is pointing to the correct location

The printer does not validate bookmarks. If the URL or network location that was specified when the bookmark was created is incorrect, then the printer will not be able to access the document.

Make sure the bookmark is created with Forms and Favorites

If the bookmark is created using another application, then it cannot be accessed in Forms and Favorites.

A network destination stopped working or is invalid

Make sure the printer authentication is configured

If the application is configured to use MFP authentication credentials, then the printer authentication settings must be configured from the Embedded Web Server.

For more information on configuring the printer authentication settings, see the *Embedded Web Server Administrator's Guide* available on **www.lexmark.com**.

Make sure destination is shared and has a valid network address

Check that the folder or source file is set to be shared across the network.

If the destination has been moved, then the network address may have changed. The destination network address can be accessed from the Embedded Web Server.

Make sure the printer is connected to the network

Make sure that all appropriate network cables are securely connected and that the network settings of the printer are correctly configured. For information on networking the printer, see the *Networking Guide* on the *Software and Documentation* CD that came with the printer.

If the source file and printer reside in different domains, then make sure the domain information is specified

If the source file exists within a different domain than the printer, then you can edit the destination from the application configuration page and enter the appropriate domain information in the Network Address and Network Domain fields. If you do not know the network address of the computer where your source file resides, then consult your system support person.

You can also add the domain name to the Domain Search Order list under the printer network setup.

Check the system log for relevant details

1. Type the printer IP address or host name in the address field of your Web browser.

   If you do not know the IP address or host name of the printer, then you can:

   - View the information on the printer control panel home screen, or in the TCP/IP section under the Networks/Ports menu.
   - Print a network setup page or menu settings page and locate the information in the TCP/IP section.

2. Click **Settings** or **Configuration**.
3. Click **Device Solutions** > **Solutions (eSF)**, or click **Embedded Solutions**.
4. Click **System** tab > **Log**.
5. From the Filter menu, select an application status.
6. From the Application menu, select an application, and then click **Submit**.

Solving option problems

Option does not operate correctly or quits after it is installed

Try one or more of the following:

Reset the printer

Turn the printer off, wait for about 10 seconds, and then turn the printer on.

Check to see if the option is connected to the printer

1. Turn the printer off using the power switch.
2. Unplug the power cord from the wall outlet, and then from the printer.
3. Check the connection between the option and the printer.

Make sure the option is installed correctly

Print a menu settings page and check to see if the option is listed in the Installed Options list. If the option is not listed, then reinstall it. For more information, see the hardware setup documentation that came with the option, or go to **www.lexmark.com** to view the option instruction sheet.

Make sure the option is selected

From the computer you are printing from, select the option.

For more information, see “Adding available options in the print driver” on page 42.

Paper tray problems

Try one or more of the following:

Make sure the paper is loaded correctly

1. Open the paper tray.
2. Check for paper jams or misfeeds.
3. Make sure the paper guides are aligned against the edges of the paper.
4. Make sure the paper tray closes properly.

Reset the printer

Turn the printer off, wait about 10 seconds, and then turn the printer on.

Make sure the paper tray is installed correctly

If the paper tray is listed on the menu settings page, but paper jams when it enters or exits the tray, then it may not be properly installed. Reinstall the paper tray. For more information, see the hardware setup documentation that came with the paper tray, or go to **http://support.lexmark.com** to view the paper tray instruction sheet.

2,000-sheet drawer problems

Check the drawer connection

Make sure the 2,000-sheet drawer is properly connected to the printer.

Load paper

If the tray is empty, then load paper in the tray or feeder

Clear any jams

Open the side door of the tray or feeder, and then remove any jammed paper.

Avoid paper jams

- Flex the paper.
- Make sure the drawer is properly installed.
- Make sure paper is loaded correctly.
- Make sure the paper stack you load does not exceed the maximum stack height indicated in the tray.
- Make sure the paper or specialty media meets specifications and is not damaged.
- Make sure the guides are positioned correctly for the paper size loaded.

Memory card

Make sure the memory card is securely connected to the printer system board.

Cannot detect flash memory card

Make sure the flash memory card is securely connected to the printer system board.

Cannot detect printer hard disk

Make sure the printer hard disk is securely connected to the printer system board.

Internal Solutions Port does not operate correctly

Try one or more of the following:

Check the Internal Solutions Port (ISP) connections

Make sure the ISP is securely connected to the printer system board.

Check the cable

Make sure you are using the correct cable and that it is securely connected to the Internal Solutions (ISP) port.

Make sure the network software is configured correctly

For information on installing the network printing software, see the *Networking Guide* on the *Software and Documentation* CD.

Internal print server does not operate correctly

Try one or more of the following:

Check the print server connections

- Make sure the internal print server is attached securely to the printer system board.
- Make sure you are using the correct cable and that it is securely connected.

Make sure the network software is configured correctly

For more information on installing the network printing software, do the following:

1. Open the *Software and Documentation* CD.
2. Click **Additional**.
3. Under Publications on this CD, select **Networking Guide**.

USB/parallel interface card does not operate correctly

Check the USB/parallel interface card connection

Make sure the USB/parallel interface card is securely connected to the printer system board.

Check the cable

Make sure you are using the correct cable and that it is securely connected.

Solving paper feed problems

Paper frequently jams

These are possible solutions. Try one or more of the following:

Check the paper

Use recommended paper and specialty media. For more information, see the chapter about paper and specialty media guidelines.

Make sure there is not too much paper in the paper tray

Make sure the stack of paper you load does not exceed the maximum stack height indicated in the tray or on the multipurpose feeder.

Check the paper guides

Move the guides in the tray to the correct positions for the paper size loaded.

The paper may have absorbed moisture due to high humidity

- Load paper from a fresh package.
- Store paper in its original wrapper until you use it.

Paper jam message remains after jam is cleared

Check the paper path

The paper path is not clear. Clear jammed paper from the entire paper path, and then touch **Continue**.

Jammed pages are not reprinted

Turn on Jam Recovery

1. From the home screen, navigate to:

   > **Settings** > **General Settings** > **Print Recovery**

2. Touch the arrows next to **`Jam Recovery`** until **`On`** or **`Auto`** appears.

3. Touch .

Solving print quality problems

If the solutions here do not correct the problem, contact customer support. You may have a printer part that requires adjustment or replacement.

Printer is printing blank pages



Try one or more of the following:

Make sure there is no packing material left on the toner or print cartridge

Remove the cartridge and make sure the packing material is properly removed. Reinstall the cartridge.

Make sure the toner or print cartridge is not low on toner

When **88.xx [color] cartridge low** appears, make sure that toner is distributed evenly among all four cartridges:

1. Remove the cartridge.

   Warning—Potential Damage: Be careful not to touch the photoconductor drum. Doing so may affect the print quality of future print jobs.

2. Firmly shake the cartridge side-to-side and front-to-back several times to redistribute the toner.
3. Reinsert the cartridge.

   Note: If print quality does not improve, then replace the cartridge of the color that is not printing.

If the problem continues, then the printer may need to be serviced. For more information, contact customer support.

Characters have jagged or uneven edges



If you are using downloaded fonts, verify that the fonts are supported by the printer, the host computer, and the software program.

Clipped images

Try one or more of the following:

Check the guides

Move the width and length guides in the tray to the correct positions for the paper size loaded.

Check the paper size setting

Make sure the paper size setting matches the paper loaded in the tray:

1. From the printer control panel Paper menu, check the Paper Size setting.
2. Before sending the job to print, specify the correct size setting:
   - For Windows users, specify the size from Print Properties.
   - For Macintosh users, specify the size from the Page Setup dialog.

Fine horizontal lines appear on color pages

You may notice fine, horizontal lines in photographs or pages with a high concentration of color. This can occur when the printer is in Quiet Mode. To fix this, set Quiet Mode to **Off (Image/Photo)**.

Shadow images appear on prints



Check the paper type and weight settings

Make sure the paper type and weight settings match the paper loaded in the tray:

1. From the printer control panel Paper menu, check the Paper Type and Paper Weight settings.
2. Before sending the job to print, specify the correct type setting:
   - For Windows users, specify the type from Print Properties.
   - For Macintosh users, specify the type from the Print dialog.

Make sure the photoconductor unit is not defective

Replace the defective photoconductor unit.

Make sure the toner cartridge is not low on toner

When **88.xx [color] cartridge low** appears, make sure the toner is distributed evenly within the toner cartridge.

1. Remove the toner cartridge.

   Warning—Potential Damage: Be careful not to touch the photoconductor drum. Doing so may affect the print quality of future print jobs.

2. Firmly shake the cartridge side-to-side and front-to-back several times to redistribute the toner.
3. Reinsert the toner cartridge.

Note: If print quality does not improve, replace the toner cartridge.

If the problem continues, the printer may need to be serviced. For more information, contact customer support.

Gray background on prints



Check the background darkness or removal setting

Try one or more of the following:

- Adjust the darkness to a lighter setting.
- Increase the background removal setting.

Make sure there is no worn or defective print cartridge

Replace the worn or defective print cartridge.

Incorrect margins



These are possible solutions. Try one or more of the following:

Check the paper guides

Move the guides in the tray to the correct positions for the paper size loaded.

Check the paper size setting

Make sure the paper size setting matches the paper loaded in the tray:

1. From the printer control panel Paper menu, check the Paper Size setting.
2. Before sending the job to print, specify the correct size setting:
   - For Windows users, specify the size from Print Properties.
   - For Macintosh users, specify the size from the Page Setup dialog.

Light colored line, white line, or incorrectly colored line appears on prints



Try one or more of the following:

Make sure there is no defective toner cartridge

Replace the defective toner cartridge.

Make sure the photoconductor unit is not defective

Replace the defective photoconductor unit.

Make sure the transfer module is not defective

Replace the defective transfer module.

Clean the printhead lenses

1. Open the front door, and then the internal cover.
2. Locate the printhead wipers.
3. Gently pull the printhead wiper out until it stops, and then slowly slide it back into place.
4. Clean the remaining three printhead lenses.

Paper curl

Try one or more of the following:

Check the paper type and weight settings

Make sure the paper type and weight settings match the paper loaded in the tray or feeder:

1. From the printer control panel Paper menu, check the Paper Type and Paper Weight settings.
2. Before sending the print job, specify the correct paper type setting:
   - For Windows users, specify the paper type from Print Properties.
   - For Macintosh users, specify the paper type from the Print dialog.

Load paper from a fresh package

Paper absorbs moisture due to high humidity. Store paper in its original wrapper until you use it.

Print irregularities



Try one or more of the following:

Load paper from a fresh package

The paper may have absorbed moisture due to high humidity. Store paper in its original wrapper until you use it.

Check the paper type and weight settings

Make sure the paper type and weight settings match the paper loaded in the tray or feeder:

1. From the printer control panel Paper menu, check the Paper Type and Paper Weight settings.
2. Before sending the print job, specify the correct paper type setting:
   - For Windows users, specify the paper type from Print Properties.
   - For Macintosh users, specify the paper type from the Print dialog.

Avoid textured paper with rough finishes

Make sure there is no defective print cartridge

Replace the worn or defective print cartridge.

Make sure the transfer belt is not defective

Replace the defective transfer belt. For more information, see the instruction sheet that came with the replacement part.

Make sure the fuser is not defective

Replace the defective fuser. For more information, see the instruction sheet that came with the replacement part.

Print is too dark



Try one or more of the following:

Check the darkness, brightness, and contrast settings

The Toner Darkness setting may be too dark, the Brightness setting may be too dark, or the Contrast setting may be too high.

- Change these settings from the printer control panel Quality menu.
- For Windows users, change these settings from Print Properties.
- For Macintosh users:
  1. Choose **File** > **Print**.
  2. From the “Orientation pictures” menu, choose **Printer Features**.
  3. Choose a lower value for the Toner Darkness, Brightness, and Contrast settings.

Load paper from a fresh package

The paper may have absorbed moisture due to high humidity. Store paper in its original wrapper until you use it.

Avoid textured paper with rough finishes

Check the Paper Type setting

Make sure the paper type setting matches the paper loaded in the tray or feeder:

- From the printer control panel Paper menu, check the Paper Type setting.
- For Windows users, check this setting from Print Properties.
- For Macintosh users, check this setting from the Print dialog.

Print is too light



Try one or more of the following:

Check the darkness, brightness, and contrast settings

The Toner Darkness setting may be too light, the Brightness setting may be too light, or the Contrast setting may be too low.

- Change these settings from the printer control panel Quality menu.
- For Windows users, change these settings from Print Properties
- For Macintosh users:
  1. Choose **File** > **Print**.
  2. From the Orientation pictures drop-down menu, choose **Printer Features**.
  3. Choose a higher value for the Toner Darkness, Brightness, and Contrast settings.

Load paper from a fresh package

The paper may have absorbed moisture from high humidity. Store paper in its original wrapper until you use it.

Avoid textured paper with rough finishes

Check the Paper Type setting

Make sure the Paper Type setting matches the paper loaded in the tray or feeder:

- From the printer control panel Paper menu, check the Paper Type setting.
- For Windows users, check this setting from Print Properties.
- For Macintosh users, check this setting from the Print dialog.

Repeating defects appear on a page

Try one or more of the following:

Make sure the photoconductor unit is not defective

The photoconductor unit may be defective if marks occur repeatedly in only one color and multiple times on a page.

- Replace the photoconductor unit if the defects occur every 94.2 mm (3.71 in.) or 37.68 mm (1.48 in.).

Make sure the fuser is not defective

The fuser may be defective if the marks occur down repeatedly in all colors.

- Replace the fuser if the defects occur every 141 mm (5.55 in.).

Skewed print

Try one or more of the following:

Check the paper guides

Adjust the length and width guides in the tray to the correct positions for the paper size loaded.

- Make sure the guides are not too far from the paper stack.
- Make sure the guides are not pressing too lightly against the paper stack.

Check the paper

Make sure you are using paper that meets the printer specifications.

Make sure the printer is clean or is not contaminated with paper dust

Clean the exterior of the printer

1. Make sure that the printer is turned off and unplugged from the wall outlet.

   Warning—Potential Damage: To avoid the risk of electric shock when cleaning the exterior of the printer, unplug the power cord from the wall outlet and disconnect all cables to the printer before proceeding.

2. Remove paper from the standard exit bin.
3. Dampen a clean, lint-free cloth with water.

   Warning—Potential Damage: Do not use household cleaners or detergents, as they may damage the finish of the printer.

4. Wipe only the exterior of the printer, making sure to include the standard exit bin.

   Warning—Potential Damage: Using a damp cloth to clean the interior may cause damage to your printer.

5. Make sure the paper support and standard exit bin are dry before beginning a new print job.

Make sure the paper feed rollers are clean and are not contaminated with dust

1. Turn the printer off using the power switch, and then unplug the power cord from the wall outlet.
2. Remove the paper feed rollers.

   Note: For instructions on how to remove and reinstall the paper feed rollers, see the setup sheet that came with the rollers inside the compartment box of Tray 1.

3. Dampen a clean, lint-free cloth with water.

4 Clean the paper feed rollers.

Warning—Potential Damage: Do not touch the rubber. Doing so will damage the rollers.

5 Reinstall the paper feed rollers.

Note: Make sure to replace the worn or defective paper feed rollers.

Solid color pages



Make sure the photoconductor is not defective and is installed correctly

Remove and then reinstall the photoconductor. If the problem continues, then the photoconductor may need to be replaced.

Black or white streaks appear on transparencies or paper





Try one or more of the following:

Ensure that the fill pattern is correct

If the fill pattern is incorrect, choose a different fill pattern from your software program.

Check the paper type

- Use only the recommended transparencies.
- Ensure that the Paper Type setting matches what is loaded in the tray or feeder.
- Ensure that the Paper Texture setting is correct for the type of paper or specialty media loaded in the tray or feeder.

Make sure the print cartridge is not low on toner

When **88.xx [color] cartridge low** appears, make sure the toner is distributed evenly within the print cartridge:

1. Remove the print cartridge.

   Warning—Potential Damage: Be careful not to touch the photoconductor drum. Doing so may affect the print quality of future print jobs.

2. Firmly shake the cartridge side-to-side and front-to-back several times to redistribute the toner.
3. Reinsert the print cartridge.

If the problem continues, the printer may need to be serviced. For more information, contact Customer Support.

Streaked horizontal lines appear on prints



Try one or more of the following:

Select another tray or feeder

- From the printer control panel Paper Menu, select Default Source.
- For Windows users, select the paper source from Print Properties.
- For Macintosh users, select the paper source from the Print dialog and pop-up menus.

Make sure there is no worn, defective, or empty print cartridge

Replace the worn, defective, or empty print cartridge.

Toner fog or background shading appears on the page

Try one or more of the following:

Make sure the toner cartridge is installed correctly or is not defective

Reinstall or replace the defective toner cartridge.

Make sure the transfer module is not worn or defective

Replace the worn or defective transfer module.

Make sure the photoconductor unit is not worn or defective

Replace the word or defective photoconductor unit.

Make sure the fuser is not worn or defective

Replace the worn or defective fuser.

Make sure the printer has recalibrated recently

Perform color adjust from the Quality menu.

Make sure the application has not specified an off-white background

Check the application settings.

Make sure no toner is in the paper path

Contact customer support.

Toner rubs off



Try one or more of the following:

Check the paper type and weight settings

Make sure the paper type and weight settings match the paper loaded in the tray or feeder:

1. From the printer control panel Paper menu, check the Paper Type and Paper Weight settings. Change the Paper Weight setting from Normal to Heavy.
2. Before sending the print job, specify the correct paper type setting:
   - For Windows users, specify the paper type from Print Properties.
   - For Macintosh users, specify the paper type from the Print dialog.

Check the paper texture setting

From the printer control panel Paper menu, make sure the Paper Texture setting matches the paper loaded in the tray or feeder. If necessary, change the Paper Texture setting from Normal to Rough.

Make sure the fuser is not worn or defective

Replace the worn or defective fuser. For more information, see the instruction sheet that came with the replacement part.

Transparency print quality is poor

Try one or more of the following:

Check the transparencies

Use only transparencies that meet the printer specifications.

Check the paper type setting

Make sure the paper type setting is set to Transparency:

1. From the printer control panel Paper menu, check the Paper Type setting.
2. Before sending the job to print, specify the correct type setting:
   - For Windows users, specify the type from Print Properties.
   - For Macintosh users, specify the type from the Print dialog.

Solving color quality problems

This section helps answer some basic color-related questions and describes how some of the features provided in the Quality Menu can be used to solve typical color problems.

FAQ about color printing

What is RGB color?

Red, green, and blue light can be added together in various amounts to produce a large range of colors observed in nature. For example, red and green can be combined to create yellow. Televisions and computer monitors create colors in this manner. RGB color is a method of describing colors by indicating the amount of red, green, or blue needed to produce a certain color.

What is CMYK color?

Cyan, magenta, yellow, and black (known as *CMYK color*) inks or toners can be printed in various amounts to produce a large range of colors observed in nature. For example, cyan and yellow can be combined to create green. Printing presses, inkjet printers, and color laser/LED printers create colors in this manner. CMYK color is a method of describing colors by indicating the amount of cyan, magenta, yellow, and black needed to reproduce a particular color.

How is color specified in a document to be printed?

Software applications typically specify document color using RGB or CMYK color combinations. Additionally, they commonly let you modify the color of each object in a document. For more information, see the software application Help section.

How does the printer know what color to print?

When you print a document, information describing the type and color of each object is sent to the printer. The color information is passed through color conversion tables that translate the color into the appropriate amounts of cyan, magenta, yellow, and black toner needed to produce the desired color. The object type information lets different color conversion tables be used for different types of objects. For example, it is possible to apply one type of color conversion table to text while applying a different color conversion table to photographic images.

Should I use PostScript or PCL emulation printer software? What settings should I use for the best color?

The PostScript driver is strongly recommended for best color quality. The default settings in the PostScript driver provide preferred color quality for the majority of printouts.

Why doesn't the printed color match the color that I see on the computer screen?

The color conversion tables used in Auto Color Correction mode generally approximate the colors of a standard computer monitor. However, because of technology differences that exist between printers and monitors, there are many colors that can also be affected by monitor variations and lighting conditions. For recommendations on how the printer color sample pages may be useful in solving certain color-matching problems, see the question, “How can I match a particular color (such as a color in a corporate logo)?”

The printed page appears tinted. Can I slightly adjust the color?

Sometimes you may consider printed pages to appear tinted (for example, everything printed seems to be too red). This can be caused by environmental conditions, paper type, lighting conditions, or user preference. In these instances, adjusting the Color Balance setting may create more preferable color. Color Balance lets you make subtle adjustments to the amount of toner being used in each color plane. Selecting positive (or negative) values for cyan, magenta, yellow, and black under the Color Balance menu will slightly increase (or decrease) the amount of toner used for the chosen color. For example, if you believe the overall printed page to be too red, then decreasing both magenta and yellow could potentially improve color.

My color transparencies seem dark when being projected. Is there anything I can do to improve the color?

This problem most commonly occurs when projecting transparencies with reflective overhead projectors. To obtain the highest projected color quality, transmissive overhead projectors are recommended. If a reflective projector must be used, then adjusting the Toner Darkness setting to 1, 2, or 3 will lighten the transparency.

Make sure to print on the recommended type of color transparencies. For more information about the paper and media specifications, see the *User's Guide* on the *Software and Documentation* CD.

What is manual color correction?

The color conversion tables applied to each object when using the default Auto Color Correction setting generate preferred color for the majority of documents. Occasionally, you may want to apply a different color table mapping. This customization is accomplished using the Manual Color menu and the Manual Color Correction setting.

Manual Color Correction applies to RGB and CMYK color conversion table mappings as defined in the Manual Color menu.

You can select any of the different color conversion tables for RGB or CMYK:

Color conversion table	Settings
RGB	• sRGB Display • Display–True Black • sRGB Vivid • Vivid • Off

Color conversion table	Settings
CMYK	• US CMYK • Euro CMYK • Vivid CMYK • Off

Note: The Manual Color Correction setting is not useful if the software application does not specify colors with RGB or CMYK combinations. It is also not effective in situations where the software application or the computer operating system controls the adjustment of colors.

How can I match a particular color (such as a corporate logo)?

Occasionally, you may have a need for the printed color of a particular object to closely match a specific color. For example, you may need to match the color of a corporate logo. While instances can occur in which the printer cannot exactly reproduce the desired color, you should be able to identify adequate color matches for the majority of cases.

The Color Samples menu item can provide useful information in helping solve this particular type of color-matching problem. The nine Color Samples values correspond to color conversion tables in the printer. Selecting any of the Color Samples values generates a multiple-page printout consisting of hundreds of colored boxes. Either a CMYK or RGB combination is located on each box, depending on the table selected. The observed color of each box is obtained by passing the CMYK or RGB combination labeled on the box through the selected color conversion table.

You can examine the color samples pages and identify the box whose color is the closest to the desired color. The color combination labeled on the box can then be used for modifying the color of the object in a software application. For instructions, see the software application Help. Manual Color Correction may be necessary to utilize the selected color conversion table for the particular object.

Selecting which Color Samples pages to use for a particular color-matching problem depends on the Color Correction setting being used (Auto, Off, or Manual), the type of object being printed (text, graphics, or images), and how the color of the object is specified in the software application (RGB or CMYK combinations). When the printer Color Correction setting is set to Off, the color is based on the print job information; no color conversion is implemented.

Note: The Color Samples pages are not useful if the software application does not specify colors with RGB or CMYK combinations. Additionally, certain situations exist where the software application or the computer operating system adjusts the RGB or CMYK combinations specified in the application through color management. The resulting printed color may not be an exact match of the Color Samples pages.

The following table can help identify which Color Sample pages to use for color matching.

Color specification and object to be printed	Color Correction setting	Sample pages to use
RGB—Text	Auto	sRGB Vivid
	Manual	Manual Color RGB Text Setting
RGB—Graphic	Auto	sRGB Vivid
	Manual	Manual Color RGB Graphic Setting
RGB—Image	Auto	sRGB Display
	Manual	Manual Color RGB Image Setting
CMYK—Text	Auto	US CMYK or Euro CMYK
	Manual	Manual Color CMYK Text Setting

Color specification and object to be printed	Color Correction setting	Sample pages to use
CMYK—Graphic	Auto	US CMYK
	Manual	Manual Color CMYK Graphic Setting
CMYK—Image	Auto	US CMYK
	Manual	Manual Color CMYK Image Setting

What are Detailed Color Samples and how do I access them?

These pages require the use of the Embedded Web Server. The Embedded Web Server is a series of resident pages stored in the network printer firmware. To access these pages, browse to the IP address of the network printer. Click **Configuration Menu**, and then click **Detailed Color Samples**.

For more information about using the Embedded Web Server, see the *User's Guide* on the *Software and Documentation* CD.

Detailed Color Samples are pages similar to the default pages of color samples accessible from the Quality menu using the printer control panel. The default color samples available using this method have an increment value of 10% for red, green, and blue. If you find a value on this page that is close, but would like to scan more colors in a nearby area, then you can use the Detailed Color Samples to select the desired color values and a more specific increment. This provides a way to print multiple pages of colored boxes that surround a specific color of interest.

There are nine conversion tables available with the following three options:

- **Print**—Prints the default pages
- **Detailed**—Lets you enter individual red, green, and blue values and a specific increment of color
- **Reset**—Lets you clear the existing information and enter new values

The process can be duplicated for Cyan (C), Magenta (M), Yellow (Y), and Black (K) color conversion tables, too. Collectively, these values are known as CMYK color. The default increment is 10% for Black and 20% each for Cyan, Magenta, and Yellow.

Embedded Web Server does not open

Try one or more of the following:

Check the network connection

Make sure the printer and computer are turned on and connected to the same network.

Check the address entered in the Web browser

- Depending on the network settings, you may need to type "`https://`" instead of "`http://`" before the printer IP address to access the Embedded Web Server. For more information, contact your system support person.
- Make sure printer IP address is correct.

Temporarily disable Web proxy servers

Proxy servers may block or restrict you from accessing certain Web sites including the Embedded Web Server. For more information, contact your system support person.

Contacting customer support

When you contact customer support, describe the problem you are experiencing, the printer control panel light sequence, and the troubleshooting steps you have already taken to find a solution.

You need to know your printer model type and serial number. For more information, see the label on the inside top front cover of the printer. The serial number is also listed on the menu settings page.

Lexmark has various ways to help you solve your printing problem. Visit the Lexmark Web site at **http://support.lexmark.com**, and then select one of the following:

Tech Library	You can browse our library of manuals, support documentation, drivers, and other downloads to help you solve common problems.
E-mail	You can send an e-mail to the Lexmark team, describing your problem. A service representative will respond and provide you with information to solve your problem.
Live chat	You can chat directly with a service representative. They can work with you to solve your printer problem or provide assistance through Assisted Service where the service representative can remotely connect to your computer through the Internet to troubleshoot problems, install updates, or complete other tasks to help you successfully use your Lexmark product.

Telephone support is also available. In the U.S. or Canada, call 1-800-539-6275. For other countries or regions, visit the Lexmark Web site at **http://support.lexmark.com**.

Notices

Product information

Product name:

Lexmark C950de

Machine type:

5058

Model(s):

030

Edition notice

October 2014

The following paragraph does not apply to any country where such provisions are inconsistent with local law: LEXMARK INTERNATIONAL, INC., PROVIDES THIS PUBLICATION “AS IS” WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. Some states do not allow disclaimer of express or implied warranties in certain transactions; therefore, this statement may not apply to you.

This publication could include technical inaccuracies or typographical errors. Changes are periodically made to the information herein; these changes will be incorporated in later editions. Improvements or changes in the products or the programs described may be made at any time.

References in this publication to products, programs, or services do not imply that the manufacturer intends to make these available in all countries in which it operates. Any reference to a product, program, or service is not intended to state or imply that only that product, program, or service may be used. Any functionally equivalent product, program, or service that does not infringe any existing intellectual property right may be used instead. Evaluation and verification of operation in conjunction with other products, programs, or services, except those expressly designated by the manufacturer, are the user’s responsibility.

For Lexmark technical support, visit **http://support.lexmark.com**.

For information on supplies and downloads, visit **www.lexmark.com**.

2014 Lexmark International, Inc.

All rights reserved.

GOVERNMENT END USERS

The Software Program and any related documentation are "Commercial Items," as that term is defined in 48 C.F.R. 2.101, "Computer Software" and "Commercial Computer Software Documentation," as such terms are used in 48 C.F.R. 12.212 or 48 C.F.R. 227.7202, as applicable. Consistent with 48 C.F.R. 12.212 or 48 C.F.R. 227.7202-1 through 227.7207-4, as applicable, the Commercial Computer Software and Commercial Software Documentation are licensed to the U.S. Government end users (a) only as Commercial Items and (b) with only those rights as are granted to all other end users pursuant to the terms and conditions herein.

Trademarks

Lexmark, Lexmark with diamond design, MarkNet, and MarkVision are trademarks of Lexmark International, Inc., registered in the United States and/or other countries.

PrintCryption is a trademark of Lexmark International, Inc.

Mac and the Mac logo are trademarks of Apple Inc., registered in the U.S. and other countries.

PCL® is a registered trademark of the Hewlett-Packard Company. PCL is Hewlett-Packard Company's designation of a set of printer commands (language) and functions included in its printer products. This printer is intended to be compatible with the PCL language. This means the printer recognizes PCL commands used in various application programs, and that the printer emulates the functions corresponding to the commands.

The following terms are trademarks or registered trademarks of these companies:

Albertus	The Monotype Corporation plc
Antique Olive	Monsieur Marcel OLIVE
Apple-Chancery	Apple Computer, Inc.
Arial	The Monotype Corporation plc
CG Times	Based on Times New Roman under license from The Monotype Corporation plc, is a product of Agfa Corporation
Chicago	Apple Computer, Inc.
Clarendon	Linotype-Hell AG and/or its subsidiaries
Eurostile	Nebiolo
Geneva	Apple Computer, Inc.
GillSans	The Monotype Corporation plc
Helvetica	Linotype-Hell AG and/or its subsidiaries
Hoefler	Jonathan Hoefler Type Foundry
ITC Avant Garde Gothic	International Typeface Corporation
ITC Bookman	International Typeface Corporation
ITC Mona Lisa	International Typeface Corporation
ITC Zapf Chancery	International Typeface Corporation
Joanna	The Monotype Corporation plc
Marigold	Arthur Baker
Monaco	Apple Computer, Inc.
New York	Apple Computer, Inc.
Oxford	Arthur Baker
Palatino	Linotype-Hell AG and/or its subsidiaries
Stempel Garamond	Linotype-Hell AG and/or its subsidiaries
Taffy	Agfa Corporation
Times New Roman	The Monotype Corporation plc

Univers	Linotype-Hell AG and/or its subsidiaries

All other trademarks are the property of their respective owners.

AirPrint and the AirPrint logo are trademarks of Apple, Inc.

Federal Communications Commission (FCC) compliance information statement

This product has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

The FCC Class A limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference, in which case the user will be required to correct the interference at his own expense.

The manufacturer is not responsible for any radio or television interference caused by using other than recommended cables or by unauthorized changes or modifications to this equipment. Unauthorized changes or modifications could void the user's authority to operate this equipment.

Note: To assure compliance with FCC regulations on electromagnetic interference for a Class A computing device, use a properly shielded and grounded cable such as Lexmark part number 1021231 for parallel attach or 1021294 for USB attach. Use of a substitute cable not properly shielded and grounded may result in a violation of FCC regulations.

Modular component notice

This product may contain the following modular component(s):

Lexmark regulatory type/model LEX-M01-003; FCC ID: IYLM01003; IC: 2376A-M01003

Lexmark regulatory type/model LEX-M05-001; FCC ID:IYLLEXM05001; IC:2376A-M05001

Lexmark regulatory type/model LEX-M05-002; FCC ID:IYLLEXM05002; IC:2376A-M05002

Licensing notices

All licensing notices associated with this product can be viewed from the CD:\LEGAL directory of the installation software CD.

Noise emission levels

The following measurements were made in accordance with ISO 7779 and reported in conformance with ISO 9296.

Note: Some modes may not apply to your product.

1-meter average sound pressure, dBA	
Printing	53
Ready	22

Values are subject to change. See **www.lexmark.com** for current values.

Waste from Electrical and Electronic Equipment (WEEE) directive

The WEEE logo signifies specific recycling programs and procedures for electronic products in countries of the European Union. We encourage the recycling of our products. If you have further questions about recycling options, visit the Lexmark Web site at **www.lexmark.com** for your local sales office phone number.

India E-Waste notice

This product complies with the India E-Waste (Management and Handling) Rules, 2011, which prohibit use of lead, mercury, hexavalent chromium, polybrominated biphenyls, or polybrominated diphenyl ethers in concentrations exceeding 0.1% by weight and 0.01% by weight for cadmium, except for the exemption set in Schedule II of the Rules.

Static sensitivity notice

This symbol identifies static-sensitive parts. Do not touch in the areas near these symbols without first touching the metal frame of the printer.

ENERGY STAR

Any Lexmark product bearing the ENERGY STAR emblem on the product or on a start-up screen is certified to comply with Environmental Protection Agency (EPA) ENERGY STAR requirements as configured when shipped by Lexmark.

Temperature information

Ambient temperature	10.0 to 33.0°C (50 to 91.4°F)
Shipping and storage temperature	-40 to 40°C (-40 to 104°F) and 0 to 35°C (32 to 95°F)

Power consumption

Product power consumption

The following table documents the power consumption characteristics of the product.

Note: Some modes may not apply to your product.

Mode	Description	Power consumption (Watts)
Printing	The product is generating hard-copy output from electronic inputs.	680
Copy	The product is generating hard-copy output from hard-copy original documents.	N/A
Scan	The product is scanning hard-copy documents.	N/A
Ready	The product is waiting for a print job.	95
Sleep Mode	The product is in a high-level energy-saving mode.	15
Hibernate	The product is in a low-level energy-saving mode.	1.0
Off	The product is plugged into a wall outlet, but the power switch is turned off.	0.35

The power consumption levels listed in the previous table represent time-averaged measurements. Instantaneous power draws may be substantially higher than the average.

Values are subject to change. See **www.lexmark.com** for current values.

Sleep Mode

This product is designed with an energy-saving mode called *Sleep Mode*. The Sleep Mode saves energy by lowering power consumption during extended periods of inactivity. The Sleep Mode is automatically engaged after this product is not used for a specified period of time, called the *Sleep Mode Timeout*.

Factory default Sleep Mode Timeout for this product (in minutes):	5

By using the configuration menus, the Sleep Mode Timeout can be modified between 1 minute and 120 minutes. Setting the Sleep Mode Timeout to a low value reduces energy consumption, but may increase the response time of the product. Setting the Sleep Mode Timeout to a high value maintains a fast response, but uses more energy.

Hibernate Mode

This product is designed with an ultra-low power operating mode called *Hibernate mode*. When operating in Hibernate Mode, all other systems and devices are powered down safely.

The Hibernate mode can be entered in any of the following methods:

- Using the Hibernate Timeout
- Using the Schedule Power modes
- Using the Sleep/Hibernate button

Factory default Hibernate Timeout for this product in all countries or regions	3 days

The amount of time the printer waits after a job is printed before it enters Hibernate mode can be modified between one hour and one month.

Off mode

If this product has an off mode which still consumes a small amount of power, then to completely stop product power consumption, disconnect the power supply cord from the wall outlet.

Total energy usage

It is sometimes helpful to calculate the total product energy usage. Since power consumption claims are provided in power units of Watts, the power consumption should be multiplied by the time the product spends in each mode in order to calculate energy usage. The total product energy usage is the sum of each mode's energy usage.

Industry Canada compliance statement

This Class A digital apparatus meets all requirements of the Canadian Interference-Causing Equipment Standard ICES-003.

Avis de conformité aux normes de l’industrie du Canada

Cet appareil numérique de classe A est conforme aux exigences de la norme canadienne relative aux équipements pouvant causer des interférences NMB-003.

European Community (EC) directives conformity

This product is in conformity with the protection requirements of EC Council directives 2004/108/EC, 2006/95/EC, and 2011/65/EU on the approximation and harmonization of the laws of the Member States relating to electromagnetic compatibility, safety of electrical equipment designed for use within certain voltage limits, and on the restrictions of use of certain hazardous substances in electrical and electronic equipment.

The manufacturer of this product is: Lexmark International, Inc., 740 West New Circle Road, Lexington, KY, 40550 USA. The authorized representative is: Lexmark International Technology Hungária Kft., 8 Lechner Ödön fasor, Millennium Tower III, 1095 Budapest HUNGARY, A declaration of conformity to the requirements of the Directives is available upon request from the Authorized Representative.

This product satisfies the Class A limits of EN 55022 and safety requirements of EN 60950-1.

Radio interference notice

Warning

This is a product that complies with the emission requirements of EN55022 Class A limits and immunity requirements of EN55024. This product is not intended to be used in residential/domestic environments.

This is a Class A product. In a domestic environment, this product may cause radio interference, in which case the user may be required to take adequate measures.

Regulatory notices for wireless products

This section contains the following regulatory information pertaining to wireless products that contain transmitters, for example, but not limited to, wireless network cards or proximity card readers.

Exposure to radio frequency radiation

The radiated output power of this device is far below the radio frequency exposure limits of the FCC and other regulatory agencies. A minimum separation of 20 cm (8 inches) must be maintained between the antenna and any persons for this device to satisfy the RF exposure requirements of the FCC and other regulatory agencies.

Industry Canada (Canada)

This device complies with Industry Canada specification RSS-210. Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

This device has been designed to operate only with the antenna provided. Use of any other antenna is strictly prohibited per regulations of Industry Canada.

To prevent radio interference to the licensed service, this device is intended to be operated indoors and away from windows to provide maximum shielding. Equipment (or its transmit antenna) that is installed outdoors is subject to licensing.

The installer of this radio equipment must ensure that the antenna is located or pointed such that it does not emit RF fields in excess of Health Canada limits for the general population; consult Safety Code 6, obtainable from Health Canada's Web site www.hc-sc.gc.ca/rpb.

The term "IC:" before the certification/registration number only signifies that the Industry Canada technical specifications were met.

Industry Canada (Canada)

Cet appareil est conforme à la norme RSS-210 d'Industry Canada. Son fonctionnement est soumis aux deux conditions suivantes :

(1) cet appareil ne doit pas provoquer d'interférences et (2) il doit accepter toute interférence reçue, y compris celles risquant d'altérer son fonctionnement.

Cet appareil a été conçu pour fonctionner uniquement avec l'antenne fournie. L'utilisation de toute autre antenne est strictement interdite par la réglementation d'Industry Canada.

En application des réglementations d'Industry Canada, l'utilisation d'une antenne de gain supérieur est strictement interdite.

Pour empêcher toute interférence radio au service faisant l'objet d'une licence, cet appareil doit être utilisé à l'intérieur et loin des fenêtres afin de garantir une protection optimale.

Si le matériel (ou son antenne d'émission) est installé à l'extérieur, il doit faire l'objet d'une licence.

L'installateur de cet équipement radio doit veiller à ce que l'antenne soit implantée et dirigée de manière à n'émettre aucun champ HF dépassant les limites fixées pour l'ensemble de la population par Santé Canada. Reportez-vous au Code de sécurité 6 que vous pouvez consulter sur le site Web de Santé Canada www.hc-sc.gc.ca/rpb.

Le terme « IC » précédant le numéro de d'accréditation/inscription signifie simplement que le produit est conforme aux spécifications techniques d'Industry Canada.

Notice to users in the European Union

Products bearing the CE mark are in conformity with the protection requirements of EC Council directives 2004/108/EC, 2006/95/EC, 1999/5/EC, and 2011/65/EU on the approximation and harmonization of the laws of the Member States relating to electromagnetic compatibility, safety of electrical equipment designed for use within certain voltage limits, radio equipment and telecommunications terminal equipment, and on the restrictions of use of certain hazardous substances in electrical and electronic equipment.

Compliance is indicated by the CE marking.

The manufacturer of this product is: Lexmark International, Inc., 740 West New Circle Road, Lexington, KY, 40550 USA. The authorized representative is: Lexmark International Technology Hungária Kft., 8 Lechner Ödön fasor, Millennium Tower III, 1095 Budapest HUNGARY, A declaration of conformity to the requirements of the Directives is available upon request from the Authorized Representative.

This product satisfies the Class A limits of EN 55022 and safety requirements of EN 60950-1.

Products equipped with 2.4GHz Wireless LAN option are in conformity with the protection requirements of EC Council directives 2004/108/EC, 2006/95/EC, and 1999/5/EC on the approximation and harmonization of the laws of the Member States relating to electromagnetic compatibility, safety of electrical equipment designed for use within certain voltage limits and on radio equipment and telecommunications terminal equipment.

Compliance is indicated by the CE marking.

Operation is allowed in all EU and EFTA countries, but is restricted to indoor use only.

The manufacturer of this product is: Lexmark International, Inc., 740 West New Circle Road, Lexington, KY, 40550 USA. The authorized representative is: Lexmark International Technology Hungária Kft., 8 Lechner Ödön fasor, Millennium Tower III, 1095 Budapest HUNGARY, A declaration of conformity to the requirements of the Directives is available upon request from the Authorized Representative.

This product may be used in the countries indicated in the table below.

AT	BE	BG	CH	CY	CZ	DE	DK	EE
EL	ES	FI	FR	HR	HU	IE	IS	IT
LI	LT	LU	LV	MT	NL	NO	PL	PT
RO	SE	SI	SK	TR	UK			

Česky	Společnost Lexmark International, Inc. tímto prohlašuje, že výrobek tento výrobek je ve shodě se základními požadavky a dalšími příslušnými ustanoveními směrnice 1999/5/ES.
Dansk	Lexmark International, Inc. erklærer herved, at dette produkt overholder de væsentlige krav og øvrige relevante krav i direktiv 1999/5/EF.
Deutsch	Hiermit erklärt Lexmark International, Inc., dass sich das Gerät dieses Gerät in Übereinstimmung mit den grundlegenden Anforderungen und den übrigen einschlägigen Bestimmungen der Richtlinie 1999/5/EG befindet.
Ελληνική	ΜΕ ΤΗΝ ΠΑΡΟΥΣΑ Η LEXMARK INTERNATIONAL, INC. ΔΗΛΩΝΕΙ ΟΤΙ ΑΥΤΟ ΤΟ ΠΡΟΪΟΝ ΣΥΜΜΟΡΦΩΝΕΤΑΙ ΠΡΟΣ ΤΙΣ ΟΥΣΙΩΔΕΙΣ ΑΠΑΙΤΗΣΕΙΣ ΚΑΙ ΤΙΣ ΛΟΙΠΕΣ ΣΧΕΤΙΚΕΣ ΔΙΑΤΑΞΕΙΣ ΤΗΣ ΟΔΗΓΙΑΣ 1999/5/ΕΚ.
English	Hereby, Lexmark International, Inc., declares that this type of equipment is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC.
Español	Por medio de la presente, Lexmark International, Inc. declara que este producto cumple con los requisitos esenciales y cualesquiera otras disposiciones aplicables o exigibles de la Directiva 1999/5/CE.
Eesti	Käesolevaga kinnitab Lexmark International, Inc., et seade see toode vastab direktiivi 1999/5/EÜ põhinõuetele ja nimetatud direktiivist tulenevatele muudele asjakohastele sätetele.
Suomi	Lexmark International, Inc. vakuuttaa täten, että tämä tuote on direktiivin 1999/5/EY oleellisten vaatimusten ja muiden sitä koskevien direktiivin ehtojen mukainen.
Français	Par la présente, Lexmark International, Inc. déclare que l'appareil ce produit est conforme aux exigences fondamentales et autres dispositions pertinentes de la directive 1999/5/CE.
Magyar	Alulírott, Lexmark International, Inc. nyilatkozom, hogy a termék megfelel a vonatkozó alapvetõ követelményeknek és az 1999/5/EC irányelv egyéb elõírásainak.
Íslenska	Hér með lýsir Lexmark International, Inc. yfir því að þessi vara er í samræmi við grunnkröfur og aðrar kröfur, sem gerðar eru í tilskipun 1999/5/EC.
Italiano	Con la presente Lexmark International, Inc. dichiara che questo questo prodotto è conforme ai requisiti essenziali ed alle altre disposizioni pertinenti stabilite dalla direttiva 1999/5/CE.
Latviski	Ar šo Lexmark International, Inc. deklarē, ka šis izstrādājums atbilst Direktīvas 1999/5/EK būtiskajām prasībām un citiem ar to saistītajiem noteikumiem.
Lietuvių	Šiuo Lexmark International, Inc. deklaruoja, kad šis produktas atitinka esminius reikalavimus ir kitas 1999/5/EB direktyvos nuostatas.
Malti	Bil-preżenti, Lexmark International, Inc., jiddikjara li dan il-prodott huwa konformi mal-ħtiġijiet essenzjali u ma dispożizzjonijiet oħrajn relevanti li jinsabu fid-Direttiva 1999/5/KE.
Nederlands	Hierbij verklaart Lexmark International, Inc. dat het toestel dit product in overeenstemming is met de essentiële eisen en de andere relevante bepalingen van richtlijn 1999/5/EG.
Norsk	Lexmark International, Inc. erklærer herved at dette produktet er i samsvar med de grunnleggende krav og øvrige relevante krav i direktiv 1999/5/EF.
Polski	Niniejszym Lexmark International, Inc. oświadcza, że niniejszy produkt jest zgodny z zasadniczymi wymogami oraz pozostałymi stosownymi postanowieniami Dyrektywy 1999/5/EC.
Português	A Lexmark International Inc. declara que este este produto está conforme com os requisitos essenciais e outras disposições da Diretiva 1999/5/CE.
Slovensky	Lexmark International, Inc. týmto vyhlasuje, že tento produkt spĺňa základné požiadavky a všetky príslušné ustanovenia smernice 1999/5/ES.

Slovensko	Lexmark International, Inc. izjavlja, da je ta izdelek v skladu z bistvenimi zahtevami in ostalimi relevantnimi določili direktive 1999/5/ES.
Svenska	Härmed intygar Lexmark International, Inc. att denna produkt står i överensstämmelse med de väsentliga egenskapskrav och övriga relevanta bestämmelser som framgår av direktiv 1999/5/EG.

STATEMENT OF LIMITED WARRANTY FOR LEXMARK LASER PRINTERS, LEXMARK LED PRINTERS, AND LEXMARK MULTIFUNCTION LASER PRINTERS

Lexmark International, Inc., Lexington, KY

This limited warranty applies to the United States and Canada. For customers outside the U.S., refer to the country-specific warranty information that came with your product.

This limited warranty applies to this product only if it was originally purchased for your use, and not for resale, from Lexmark or a Lexmark Remarketer, referred to in this statement as “Remarketer.”

Limited warranty

Lexmark warrants that this product:

—Is manufactured from new parts, or new and serviceable used parts, which perform like new parts

—Is, during normal use, free from defects in material and workmanship

If this product does not function as warranted during the warranty period, contact a Remarketer or Lexmark for repair or replacement (at Lexmark's option).

If this product is a feature or option, this statement applies only when that feature or option is used with the product for which it was intended. To obtain warranty service, you may be required to present the feature or option with the product.

If you transfer this product to another user, warranty service under the terms of this statement is available to that user for the remainder of the warranty period. You should transfer proof of original purchase and this statement to that user.

Limited warranty service

The warranty period starts on the date of original purchase as shown on the purchase receipt and ends 12 months later provided that the warranty period for any supplies and for any maintenance items included with the printer shall end earlier if it, or its original contents, are substantially used up, depleted, or consumed. Fuser Units, Transfer/Transport Units, Paper Feed items, if any, and any other items for which a Maintenance Kit is available are substantially consumed when the printer displays a “Life Warning” or “Scheduled Maintenance” message for such item.

To obtain warranty service you may be required to present proof of original purchase. You may be required to deliver your product to the Remarketer or Lexmark, or ship it prepaid and suitably packaged to a Lexmark designated location. You are responsible for loss of, or damage to, a product in transit to the Remarketer or the Lexmark designated location.

When warranty service involves the exchange of a product or part, the item replaced becomes the property of the Remarketer or Lexmark. The replacement may be a new or repaired item.

The replacement item assumes the remaining warranty period of the original product.

Replacement is not available to you if the product you present for exchange is defaced, altered, in need of a repair not included in warranty service, damaged beyond repair, or if the product is not free of all legal obligations, restrictions, liens, and encumbrances.

As part of your warranty service and/or replacement, Lexmark may update the firmware in your printer to the latest version. Firmware updates may modify printer settings and cause counterfeit and/or unauthorized products, supplies, parts, materials (such as toners and inks), software, or interfaces to stop working. Authorized use of genuine Lexmark products will not be impacted.

Before you present this product for warranty service, remove all print cartridges, programs, data, and removable storage media (unless directed otherwise by Lexmark).

For further explanation of your warranty alternatives and the nearest Lexmark authorized servicer in your area contact Lexmark on the World Wide Web.

Remote technical support is provided for this product throughout its warranty period. For products no longer covered by a Lexmark warranty, technical support may not be available or only be available for a fee.

Extent of limited warranty

Lexmark does not warrant uninterrupted or error-free operation of any product or the durability or longevity of prints produced by any product.

Warranty service does not include repair of failures caused by:

—Modification or unauthorized attachments

—Accidents, misuse, abuse or use inconsistent with Lexmark user’s guides, manuals, instructions or guidance

—Unsuitable physical or operating environment

—Maintenance by anyone other than Lexmark or a Lexmark authorized servicer

—Operation of a product beyond the limit of its duty cycle

—Use of printing media outside of Lexmark specifications

—Refurbishment, repair, refilling or remanufacture by a third party of products, supplies or parts

—Products, supplies, parts, materials (such as toners and inks), software, or interfaces not furnished by Lexmark

TO THE EXTENT PERMITTED BY APPLICABLE LAW, NEITHER LEXMARK NOR ITS THIRD PARTY SUPPLIERS OR REMARKETERS MAKE ANY OTHER WARRANTY OR CONDITION OF ANY KIND, WHETHER EXPRESS OR IMPLIED, WITH RESPECT TO THIS PRODUCT, AND SPECIFICALLY DISCLAIM THE IMPLIED WARRANTIES OR CONDITIONS OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, AND SATISFACTORY QUALITY. ANY WARRANTIES THAT MAY NOT BE DISCLAIMED UNDER APPLICABLE LAW ARE LIMITED IN DURATION TO THE WARRANTY PERIOD. NO WARRANTIES, EXPRESS OR IMPLIED, WILL APPLY AFTER THIS PERIOD. ALL INFORMATION, SPECIFICATIONS, PRICES, AND SERVICES ARE SUBJECT TO CHANGE AT ANY TIME WITHOUT NOTICE.

Limitation of liability

Your sole remedy under this limited warranty is set forth in this document. For any claim concerning performance or nonperformance of Lexmark or a Remarketer for this product under this limited warranty, you may recover actual damages up to the limit set forth in the following paragraph.

Lexmark's liability for actual damages from any cause whatsoever will be limited to the amount you paid for the product that caused the damages. This limitation of liability will not apply to claims by you for bodily injury or damage to real property or tangible personal property for which Lexmark is legally liable. **IN NO EVENT WILL LEXMARK BE LIABLE FOR ANY LOST PROFITS, LOST SAVINGS, INCIDENTAL DAMAGE, OR OTHER ECONOMIC OR CONSEQUENTIAL DAMAGES.**

This is true even if you advise Lexmark or a Remarketer of the possibility of such damages. Lexmark is not liable for any claim by you based on a third party claim.

This limitation of remedies also applies to claims against any Suppliers and Remarketers of Lexmark. Lexmark's and its Suppliers' and Remarketers' limitations of remedies are not cumulative. Such Suppliers and Remarketers are intended beneficiaries of this limitation.

Additional rights

Some states do not allow limitations on how long an implied warranty lasts, or do not allow the exclusion or limitation of incidental or consequential damages, so the limitations or exclusions contained above may not apply to you.

This limited warranty gives you specific legal rights. You may also have other rights that vary from state to state.

Patent acknowledgment

The use of this product or service is subject to the reasonable, non-discriminatory terms in the Intellectual Property Rights (IPR) Disclosure of Certicom Corp. at the IETF for Elliptic Curve Cryptography (ECC) Cipher Suites for Transport Layer Security (TLS) implemented in the product or service.

The use of this product or service is subject to the reasonable, non-discriminatory terms in the Intellectual Property Rights (IPR) Disclosure of Certicom Corp. at the IETF for TLS Elliptic Curve Cipher Suites with SHA-256/382 and AES Galois Counter Mode (GCM) implemented in the product or service.

The use of this product or service is subject to the reasonable, non-discriminatory terms in the Intellectual Property Rights (IPR) Disclosure of Certicom Corp. at the IETF for TLS Suite B Profile for Transport Layer Security (TLS) implemented in the product or service.

The use of this product or service is subject to the reasonable, non-discriminatory terms in the Intellectual Property Rights (IPR) Disclosure of Certicom Corp. at the IETF for Addition of the Camellia Cipher Suites to Transport Layer Security (TLS) implemented in the product or service.

The use of certain patents in this product or service is subject to the reasonable, non-discriminatory terms in the Intellectual Property Rights (IPR) Disclosure of Certicom Corp. at the IETF for AES-CCM ECC Cipher Suites for TLS implemented in the product or service.

The use of this product or service is subject to the reasonable, non-discriminatory terms in the Intellectual Property Rights (IPR) Disclosure of Certicom Corp. at the IETF for IKE and IKEv2 Authentication Using the Eliptic Curve Digital Signature Algorithm (ECDSA) implemented in the product or service.

The use of this product or service is subject to the reasonable, non-discriminatory terms in the Intellectual Property Rights (IPR) Disclosure of Certicom Corp. at the IETF for Suite B Cryptographic Suites for IPSec implemented in the product or service.

The use of this product or service is subject to the reasonable, non-discriminatory terms in the Intellectual Property Rights (IPR) Disclosure of Certicom Corp. at the IETF for Algorithms for Internet Key Exchange version 1 (IKEv1) implemented in the product or service.

Index

Numerics

1565 Emulation error, load emulation option 212
1-tray module
installing 37
2,000-sheet high-capacity feeder
installing 37
2000-sheet high-capacity feeder
loading 61
201–202 paper jams 177
203 paper jam 178
230 paper jam 180
231 paper jam 180
24x paper jam 182
250 paper jam 188
281 paper jam 188
31.xx Missing or Defective [color] cartridge 204
32.xx [color] cartridge part number unsupported by device 204
34 Incorrect paper size, check [paper source] 205
34 Incorrect paper type, check [paper source] 205
35 Insufficient memory to support Resource Save feature 205
37 Insufficient memory for Flash Memory Defragment operation 206
37 Insufficient memory to collate job 206
37 Insufficient memory, some Held Jobs were deleted 205
37 Insufficient memory, some held jobs will not be restored 205
38 Memory full 206
39 Complex page, some data may not have printed 206
3-tray module
installing 37
40 [color] invalid refill, change cartridge 206
455 staple jam 195
4yy.xx paper jams 190
51 Defective flash detected 206
52 Not enough free space in flash memory for resources 206
520-sheet tray (standard or optional)
loading 55
53 Unformatted flash detected 207
54 Network [x] software error 207
54 Serial option [x] error 207
54 Standard network software error 207
55 Unsupported option in slot [x] 207
56 Parallel port [x] disabled 208
56 Serial port [x] disabled 208
56 Standard parallel port disabled 208
56 Standard USB port disabled 208
56 USB port [x] disabled 208
57 Configuration change, some held jobs were not restored 208
58 Too many disks installed 209
58 Too many flash options installed 209
58 Too many trays attached 209
59 Incompatible tray [x] 209
61 Remove defective disk 209
62 Disk full 210
80 Replace paper pick rollers in [paper source] 210
80 Scheduled maintenance [x] 210
82.xx Replace waste toner bottle 210
82.xx Waste toner bottle missing 210
82.xx Waste toner bottle nearly full 210
84 unsupported [color] photoconductor 210
84.xx [color] photoconductor low 211
84.xx [color] photoconductor missing 211
84.xx Replace [color] photoconductor 211
88 Replace [color] cartridge 211
88.xx [color] cartridge low 211

A

accessing the Embedded Web Server 17
accessing the system board 22
Active NIC menu 101
adding hardware options
print driver 42
adjusting brightness
Embedded Web Server 53
printer display 53
adjusting Sleep mode 52
adjusting toner darkness 79
administrator settings
Embedded Web Server 173
An error has occurred with the flash drive 198
AppleTalk menu 106
assigning a custom paper type name 67
attaching cables 39
available internal options 22
avoiding paper jams 175

B

Background and Idle Screen
using 18
Bin 2 is unable to lower 198
Bin Setup menu 99
black-and-white printing 79
blank pages 222
buttons, printer control panel 13
buttons, touch screen
using 15

C

cables
Ethernet 39
USB 39
canceling
print job, from computer 87
canceling a print job
from a computer 87
from the printer control panel 87
cannot open Embedded Web Server 236
card stock
loading, multipurpose feeder 63
tips 85
Change [paper source] to [custom string] 199

Change [paper source] to [custom string] load [orientation] 199
Change [paper source] to [custom type name] 198
Change [paper source] to [custom type name] load [orientation] 199
Change [paper source] to [paper size] [paper type] 199
Change [paper source] to [paper size] [paper type] load [orientation] 199
Check [src] orientation or guides 200
checking an unresponsive printer 198
checking printer status
  on Embedded Web Server 173
checking printer status using the Embedded Web Server 173
checking status of parts and supplies 148
checking the status of parts and supplies 148
checking the virtual display
  using the Embedded Web Server 173
checking virtual display
  using the Embedded Web Server 173
cleaning
  exterior of the printer 142
cleaning the printhead lenses 142
Close cover [x] 200
Close door [x] 200
confidential print jobs 85
  printing from a Macintosh computer 86
  printing from Windows 86
Confidential Print menu 115
configuration information
  wireless network 43
Configure MP menu 94
configuring port settings 48
conservation settings
  brightness, adjusting 53
  conserving supplies 50
  Eco-Mode 51
  Hibernate Mode 52
  Quiet Mode 51
  Sleep mode 52
conserving supplies 50
contacting customer support 237
corrupted printer hard disk 200
Custom Bin Names menu 98
custom name
  configuring 67
Custom Names menu 98
custom paper type
  assigning 67
custom paper type name
  creating 67
Custom Type [x]
  changing name 67
  changing paper type 67
Custom Types menu 98
customer support
  contacting 237

D

Default Source menu 91
directory list
  printing 87
disk wiping 140
display troubleshooting
  display is blank 212
  display shows only diamonds 212
display, printer control panel 13
  adjusting brightness 53
disposing of printer hard disk 139
documents, printing
  from Macintosh 79
  from Windows 79

E

Eco-Mode setting 51
Eco-Settings
  about 19
Embedded Web Server
  accessing 17
  administrator settings 173
  checking printer status 173
  checking the status of parts 148
  checking the status of supplies 148
  networking settings 173
  problem accessing 236
  setting up e-mail alerts 173
Embedded Web Server — Security: Administrator's Guide
  where to find 173
emission notices 240, 243, 244, 245
Empty the hole punch box 200
emptying the hole punch box 146
encrypting the printer hard disk 141
envelopes
  loading, multipurpose feeder 63
  tips 84
environmental settings
  conserving supplies 50
  display brightness, adjusting 53
  Eco-Mode 51
  Hibernate Mode 52
  Quiet Mode 51
  Sleep mode 52
Erase Temporary Data Files menu 115
erasing hard disk memory 140
erasing non-volatile memory 140
erasing volatile memory 139
Error reading USB hub. Remove hub. 200
Ethernet network
  preparing to set up for Ethernet printing 42
Ethernet port 39
Ethernet setup
  preparing for an 42
exit bins 78
  linking 66
exporting a configuration
  using the Embedded Web Server 20
exterior of the printer
  cleaning 142
e-mail alerts
  low supply levels 173
  paper jam 173
  setting up 173

F

factory defaults
  restoring 174
FAQ about color printing 233
FCC notices 240, 244
finding more information about the printer 8
finisher
  exit bins 78
  finishing features 76
  supported paper sizes 76
Finishing menu 124
firmware card
  installing 26

flash drive
printing from 81
Flash Drive menu 137
flash drives
supported file types 82
flash memory card
installing 26
troubleshooting 219
font sample list
printing 86
Forms and Favorites
setting up 18

G

General Settings menu 118
Green settings
Eco-Mode 51
Hibernate Mode 52
Quiet Mode 51

H

hardware options, adding
print driver 42
held jobs 85
printing from a Macintosh computer 86
printing from Windows 86
Help menu 138
Hibernate Mode
using 52
hiding icons on the home screen 17
hole punch box
emptying 146
home screen
buttons, understanding 14
hiding icons 17
showing icons 17
home screen buttons
understanding 14
HTML menu 135

I

icons on the home screen
hiding 17
showing 17
icons, printer control panel 13
Image menu 136
importing a configuration
using the Embedded Web Server 20
Insert hole punch box 201
Insert staple cartridge 200
Install bin [x] 201
installing a memory card 24
installing an Internal Solutions Port 27
installing on a wireless network
using Windows 44
installing options
order of installation 36
installing printer
on wireless network 44
installing printer hard disk 30
installing printer on a wireless network
using Macintosh 45
installing printer software (Windows) 41
installing the 1-tray module 37
installing the 2,000-sheet high-capacity feeder 37
installing the 3-tray module 37
installing the tandem-tray module 37
internal print server
troubleshooting 220
Internal Solutions Port
changing port settings 48
installing 27
troubleshooting 220
IPv6 menu 104

J

jams
avoiding 175
locating jam areas 175
locations 175
numbers 175
jams, clearing
201–202 paper jams 177
203 paper jam 178
230 paper jam 180
231 paper jam 180
24x paper jam 182
250 paper jam 188
281 paper jam 188
455 staple jam 195
4yy.xx paper jams 190
Job Accounting menu 128

L

labels, paper
tips 84
letterhead
loading, 2000-sheet high-capacity feeder 61
loading, multipurpose feeder 83
loading, trays 83
light colored line, white line, or incorrectly colored line appears on prints 225
linking
exit bins 66
linking exit bins 66
linking trays 66
Load Manual Feeder with [custom string] 202
Load Manual Feeder with [custom type name] 202
Load Manual Feeder with [paper size] 202
Load Manual Feeder with [paper type] [paper size] 203
Load staples 203
loading
2000-sheet high-capacity feeder 61
520-sheet tray (standard or optional) 55
card stock, multipurpose feeder 63
envelopes, multipurpose feeder 63
letterhead in 2000-sheet high-capacity feeder 61
multipurpose feeder 63
optional 1,150-sheet tray 58
optional 850-sheet tray 58
transparencies, multipurpose feeder 63
loading letterhead
paper orientation 83
loading the standard tray 55

M

maintenance kit
ordering 150
replacing 151
Manual feeder expects [paper size]. Check [paper source] guides 203

max speed and max yield
using 80
memory
types installed on printer 139
memory card
installing 24
troubleshooting 219
menu settings page
printing 41
menus
Active NIC 101
AppleTalk 106
Bin Setup 99
Confidential Print 115
Configure MP 94
Custom Bin Names 98
Custom Names 98
Custom Types 98
Default Source 91
diagram of 88
Erase Temporary Data Files 115
Finishing 124
Flash Drive 137
General Settings 118
Help 138
HTML 135
Image 136
IPv6 104
Job Accounting 128
Miscellaneous 114
Network [x] 101
Network Card 103
Network Reports 103
Paper Loading 97
Paper Size/Type 91
Paper Texture 95
Parallel [x] 108
PCL Emul 132
PDF 135
PostScript 131
Quality 127
Reports 100
Security Audit Log 116
Serial [x] 110
Set Date and Time 117
Setup 130
SMTP Setup menu 112
Standard Network 101
Standard USB 106
Substitute Size 95
Supplies 89
TCP/IP 103
Universal Setup 99
Wireless 105
XPS 134
menus diagram 88
Miscellaneous menu 114
mobile device
printing from 80
moving the printer 9, 172
multipurpose feeder
loading 63

N

Network [x] menu 101
Network Card menu 103
network options 22
Network Reports menu 103
network settings
Embedded Web Server 173
network setup page
printing 41
Networking Guide
where to find 173
noise emission levels 240
non-volatile memory 139
erasing 140
notices 239, 240, 241, 242, 243, 244, 245

O

optional 1,150-sheet tray
loading 58
optional 850-sheet tray
loading 58
options
1-tray module, installing 37
2,000-sheet high-capacity feeder, installing 37
3-tray module, installing 37
firmware card 26
firmware cards 22
flash memory card 26
Internal Solutions Port, installing 27
list 22
memory card, installing 24
memory cards 22
network 22
order of installation 36
ports 22
printer hard disk, installing 30
printer hard disk, removing 34
tandem-tray module, installing 37
ordering
maintenance kit 150
staple cartridges 150
toner cartridges 149
waste toner bottle 150
ordering photoconductor units 149

P

paper
characteristics 68
finishing features 76
letterhead 70
preprinted forms 70
recycled 70
selecting 69
storing 71
unacceptable 69, 70
Universal size setting 55
using recycled 50
paper feed troubleshooting
message remains after jam is cleared 221
paper jams
avoiding 175
paper jams, clearing
201–202 paper jams 177
203 paper jam 178
230 paper jam 180
231 paper jam 180
24x paper jam 182
250 paper jam 188
281 paper jam 188
4yy.xx paper jams 190
Paper Loading menu 97
paper size
setting 55
Universal 99
Paper Size/Type menu 91
paper sizes
supported 72
Paper Texture menu 95
paper type
setting 55
paper types
duplex support 74
supported by printer 74
supported by the finisher 74
where to load 74
Parallel [x] menu 108
parts
checking status 148

checking, from printer control panel 148
checking, using the Embedded Web Server 148
parts, replacing
maintenance kit 151
PCL Emul menu 132
PDF menu 135
photoconductor unit
replacing 151
photoconductor units
ordering 149
port settings
configuring 48
PostScript menu 131
preparing to set up the printer on an Ethernet network 42
print driver
hardware options, adding 42
print irregularities 226
print job
canceling, from computer 87
print quality
replacing a photoconductor unit 151
print quality troubleshooting
black streaks on a page 230
blank pages 222
characters have jagged edges 222
clipped images 223
fine horizontal lines 223
gray background on prints 224
light colored line, white line, or incorrectly colored line appears on prints 225
poor transparency quality 233
print irregularities 226
print is too dark 227
print is too light 228
repeating defects appear on a page 228
shadow images appear on prints 223
skewed print 229
solid color pages 230
streaked horizontal lines appear on prints 231
toner fog or background shading on the page 231
toner rubs off 232
white streaks on a page 230
print quality, troubleshooting
cleaning the printhead lenses 142
Print quota exceeded. Print job canceled. 204
Print quota exceeded. Print job incomplete. 204
print troubleshooting
error reading flash drive 212
held jobs do not print 213
incorrect characters print 214
incorrect margins 224
jammed pages are not reprinted 221
job prints from wrong tray 214
job prints on wrong paper 214
jobs do not print 212
Large jobs do not collate 215
multiple-language PDF files do not print 212
paper curl 226
paper frequently jams 221
print job takes longer than expected 214
tray linking does not work 214
unexpected page breaks occur 215
printer
basic model 10
fully configured 10
minimum clearances 9
moving 9, 172
selecting a location 9
shipping 172
turning on 21
printer configurations 10
printer control panel
factory defaults, restoring 174
using 13
printer hard disk
disposing of 139
encrypting 141
installing 30
removing 34
troubleshooting 219
wiping 140
printer hard disk encryption 141
printer hard disk memory
erasing 140
printer information
where to find 8
printer messages
1565 Emulation error, load emulation option 212
31.xx Missing or Defective [color] cartridge 204
32.xx [color] cartridge part number unsupported by device 204
34 Incorrect paper size, check [paper source] 205
34 Incorrect paper type, check [paper source] 205
35 Insufficient memory to support Resource Save feature 205
37 Insufficient memory for Flash Memory Defragment operation 206
37 Insufficient memory to collate job 206
37 Insufficient memory, some Held Jobs were deleted 205
37 Insufficient memory, some held jobs will not be restored 205
38 Memory full 206
39 Complex page, some data may not have printed 206
40 [color] invalid refill, change cartridge 206
51 Defective flash detected 206
52 Not enough free space in flash memory for resources 206
53 Unformatted flash detected 207
54 Network [x] software error 207
54 Serial option [x] error 207
54 Standard network software error 207
55 Unsupported option in slot [x] 207
56 Parallel port [x] disabled 208
56 Serial port [x] disabled 208
56 Standard parallel port disabled 208
56 Standard USB port disabled 208
56 USB port [x] disabled 208
57 Configuration change, some held jobs were not restored 208
58 Too many disks installed 209
58 Too many flash options installed 209
58 Too many trays attached 209

59 Incompatible tray [x] 209
61 Remove defective disk 209
62 Disk full 210
80 Replace paper pick rollers in [paper source] 210
80 Scheduled maintenance [x] 210
82.xx Replace waste toner bottle 210
82.xx Waste toner bottle missing 210
82.xx Waste toner bottle nearly full 210
84 Replace black pc unit 151
84 Replace color pc units 151
84 unsupported [color] photoconductor 210
84.xx [color] photoconductor low 211
84.xx [color] photoconductor missing 211
84.xx Replace [color] photoconductor 211
88 Replace [color] cartridge 211
88.xx [color] cartridge low 211
an error has occurred with the flash drive 198
Bin 2 is unable to lower 198
Change [paper source] to [custom string] 199
Change [paper source] to [custom string] load [orientation] 199
Change [paper source] to [custom type name] 198
Change [paper source] to [custom type name] load [orientation] 199
Change [paper source] to [paper size] [paper type] 199
Change [paper source] to [paper size] [paper type] load [orientation] 199
Check [src] orientation or guides 200
Close cover [x] 200
Close door [x] 200
Disk corrupted 200
Empty the hole punch box 200
Error reading USB hub. Remove hub. 200
Insert hole punch box 201
Insert staple cartridge 200
Insert Tray [x] 201
Install bin [x] 201
Load [src] with [custom string] 201
Load [src] with [custom type name] 201
Load [src] with [size] 202
Load [src] with [type] [size] 202
Load Manual Feeder with [custom string] 202
Load Manual Feeder with [custom type name] 202
Load Manual Feeder with [paper size] 202
Load Manual Feeder with [paper type] [paper size] 203
Load staples 203
Manual feeder expects [paper size]. Check [paper source] guides 203
Print quota exceeded. Print job canceled. 204
Print quota exceeded. Print job incomplete. 204
Remove packaging material, [area name] 204
Remove paper from [linked set bin name] 203
Remove paper from all bins 203
Remove paper from bin [x] 203
Remove paper from standard output bin 203
Restore held jobs? 204
Some held jobs were not restored 204
Unsupported camera mode, unplug camera and change mode 204
Unsupported disk 204
Unsupported USB device, please remove 200
Unsupported USB hub, please remove 200
printer options troubleshooting
2,000-sheet drawer problems 219
cannot detect flash memory card 219
cannot detect printer hard disk 219
internal print server 220
Internal Solutions Port 220
memory card 219
option does not work 218
paper tray problems 218
USB/parallel interface card 220
printer problems, solving basic 198
printer software, installing (Windows) 41
printhead lenses
cleaning 142
printing
black-and-white 79
canceling, from the printer control panel 87
directory list 87
font sample list 86
from a mobile device 80
from flash drive 81
from Macintosh 79
from Windows 79
max speed and max yield 80
menu settings page 41
network setup page 41
printing a directory list 87
printing a document 79
printing a font sample list 86
printing a menu settings page 41
printing a network setup page 41
printing confidential and other held jobs
from a Macintosh computer 86
from Windows 86
printing from a flash drive 81
printing from a mobile device 80
printing in black and white 79
publications
where to find 8

Q

Quality menu 127
Quiet Mode
print quality troubleshooting 223

R

recycled paper
using 50, 70
recycling
Lexmark packaging 54
Lexmark products 53
toner cartridges 54
WEEE statement 241
reducing printer noise 51

Remote Operator Panel
setting up 19
Remove packaging material, [area name] 204
Remove paper from [linked set bin name] 203
Remove paper from all bins 203
Remove paper from bin [x] 203
Remove paper from standard output bin 203
removing printer hard disk 34
repeat print jobs 85
printing from a Macintosh computer 86
printing from Windows 86
replacing
maintenance kit 151
replacing a staple cartridge 164
replacing a toner cartridge 156
replacing supplies
staple cartridge 164
toner cartridge 156
waste toner bottle 159
replacing the waste toner bottle 159
reports
viewing 174
Reports menu 100
reserve print jobs 85
printing from a Macintosh computer 86
printing from Windows 86
Restore held jobs? 204
restoring factory default settings 174

S

safety information 6, 7
Security Audit Log menu 116
selecting a location for the printer 9
Serial [x] menu 110
serial printing
setting up 49
Set Date and Time menu 117
setting
TCP/IP address 103
setting the exit bin
finisher 78
setting the paper size 55
setting the paper type 55
setting the Universal paper size 55
setting up e-mail alerts using the Embedded Web Server 173
setting up serial printing 49
Setup menu 130
shadow images appear on prints 223
shipping the printer 172
showing icons on the home screen 17
Showroom
about 19
Sleep mode
adjusting 52
SMTP Setup menu 112
Some held jobs were not restored 204
Standard Network menu 101
standard tray
loading 55
Standard USB menu 106
staple cartridge
replacing 164
staple cartridges
ordering 150
staple jam, clearing
455 staple jam 195
statement of volatility 139
status of parts
checking 148
status of supplies
checking 148
storing
paper 71
supplies 148
storing print jobs 85
streaked horizontal lines appear on prints 231
streaks appear on a page 230
Substitute Size menu 95
supplies
checking status 148
checking, from printer control panel 148
checking, using the Embedded Web Server 148
conserving 50
storing 148
using recycled paper 50
Supplies menu 89
supplies, ordering
maintenance kit 150
photoconductor units 149
staple cartridges 150
toner cartridges 149
waste toner bottle 150
supported flash drives 82
supported paper sizes 72
supported paper types and weights 74
system board
accessing 22
system board cover
reattaching 22

T

tandem-tray module
installing 37
TCP/IP menu 103
tips
card stock 85
envelopes 84
labels, paper 84
on using letterhead 83
on using transparencies 83
tips on using letterhead 83
toner cartridge
replacing 156
toner cartridges
ordering 149
recycling 54
toner darkness
adjusting 79
toner fog or background shading appears on the page 231
toner rubs off 232
touch screen
buttons, using 15
transparencies
loading 83
loading, multipurpose feeder 63
tips on using 83
using 83
trays
linking 66
unlinking 66
troubleshooting
A network destination stopped working or is invalid 217
an application error has occurred 215
cannot open Embedded Web Server 236
checking an unresponsive printer 198

FAQ about color printing 233
Forms are not available or are not working 216
Scan to Network 215, 217
solving basic printer problems 198
troubleshooting, display
display is blank 212
display shows only diamonds 212
troubleshooting, paper feed
message remains after jam is cleared 221
troubleshooting, print
error reading flash drive 212
held jobs do not print 213
incorrect characters print 214
incorrect margins 224
jammed pages are not reprinted 221
job prints from wrong tray 214
job prints on wrong paper 214
jobs do not print 212
Large jobs do not collate 215
multiple-language PDF files do not print 212
paper curl 226
paper frequently jams 221
print job takes longer than expected 214
tray linking does not work 214
unexpected page breaks occur 215
troubleshooting, print quality
black streaks on a page 230
blank pages 222
characters have jagged edges 222
clipped images 223
fine horizontal lines 223
gray background on prints 224
light colored line, white line, or incorrectly colored line appears on prints 225
poor transparency quality 233
print irregularities 226
print is too dark 227
print is too light 228
repeating defects appear on a page 228
shadow images appear on prints 223
skewed print 229
solid color pages 230
streaked horizontal lines appear on prints 231
toner fog or background shading on the page 231
toner rubs off 232
white streaks on a page 230
troubleshooting, printer options
2,000-sheet drawer problems 219
cannot detect flash memory card 219
cannot detect printer hard disk 219
internal print server 220
Internal Solutions Port 220
memory card 219
option does not work 218
paper tray problems 218
USB/parallel interface card 220
turning on the printer 21

U

understanding the home screen 14
Universal Paper Size setting 55
Universal paper size 99
Universal Setup menu 99
unlinking trays 66
Unsupported camera mode, unplug camera and change mode 204
Unsupported USB device, please remove 200
Unsupported USB hub, please remove 200
USB port 39
USB printer port 39
USB/parallel interface card troubleshooting 220
using Eco-Mode 51
using Hibernate Mode 52
using max speed and max yield 80
using Quiet Mode 51
using recycled paper 50
using the printer control panel 13
using the touch-screen buttons 15

V

verify print jobs 85
printing from a Macintosh computer 86
printing from Windows 86
viewing
reports 174
virtual display
checking, using Embedded Web Server 173
volatile memory 139
erasing 139
volatility
statement of 139

W

waste toner bottle
ordering 150
replacing 159
wiping the printer hard disk 140
Wireless menu 105
wireless network
configuration information 43
installation, using Macintosh 45
installation, using Windows 44
wireless network setup
in Windows 44
wireless printer setup
in Macintosh 45

X

XPS menu 134